



[Manuals.plus](#) /

> [Devoko](#) /

> Devoko 97 Gallon Deck Box Instruction Manual (Model 24312DBN)

## Devoko 24312DBN

# Devoko 97 Gallon Deck Box Instruction Manual

Model: 24312DBN

## 1. INTRODUCTION

---

The Devoko 97 Gallon Deck Box is designed for outdoor storage, offering a spacious and durable solution for various items. Constructed from waterproof resin with a rattan pattern, it is built to withstand outdoor elements while maintaining its appearance. This manual provides essential information for assembly, operation, maintenance, and specifications to ensure optimal use of your deck box.



*Image: Devoko 97 Gallon Deck Box in a garden setting, showcasing its capacity and aesthetic appeal.*

## 2. PRODUCT FEATURES

- **Resistant Resin Material:** Made of waterproof resin with a complementing rattan pattern design, effectively preventing fading and rusting, while also maintaining a fresh appearance even with all-weather use.
- **Large Storage Space:** Exceptionally spacious 97-gallon storage capacity, ideal for furniture cushions, gardening tools, and pool supplies.
- **Clever Function Design:** Features handles on both sides for easy mobility. The hydraulic hinge design prevents pinching and ensures safety, allowing for smooth opening and closing. It also comes with a lockable lid for added security.
- **Multi-functional Use:** Can be used as a two-person seating bench, adding versatility to your outdoor space.

## Reinforcement Bars



## Hydraulic Hinge




Ensure safety in use



Open and close slowly



Easy-Grip Handle



Securely locked

*Image: Detailed view of key features: reinforcement bars for stability, a hydraulic hinge for safe operation, an easy-grip handle for portability, and a lockable mechanism for security.*

### 3. SETUP AND ASSEMBLY

The Devoko Deck Box is designed for straightforward assembly, typically requiring no special tools. The panels are engineered to snap together securely. Follow the visual instructions provided in the packaging for the most accurate guidance.

#### Assembly Steps:

1. Unpack all components and verify against the parts list in your manual.
2. Identify the base panel and side panels. Each panel is typically labeled for easy identification.
3. Align the tabs of the side panels with the slots on the base panel. Apply firm, even pressure until each tab clicks securely into place.
4. Continue attaching the remaining side panels, ensuring all connections are tight.
5. Attach the lid, aligning its hinges with the corresponding points on the top edge of the assembled box. The hydraulic hinges should be installed according to the manual's diagrams.

6. Ensure all parts are firmly connected before use.

## Assembly Video Guide:

For a visual walkthrough of the assembly process, please refer to the following video:

*Video: A detailed guide on assembling the Devoko Outdoor Storage Box, demonstrating the ease of snap-together construction.*

## 4. OPERATING INSTRUCTIONS

---

### Opening and Closing the Lid:

To open the deck box, gently lift the lid using the integrated handle. The hydraulic hinges will assist in smoothly raising the lid and holding it open. To close, gently pull the lid down. The hydraulic hinges will ensure a soft and controlled closure, preventing sudden drops or pinching.

### Locking Mechanism:

The deck box features a built-in provision for a padlock (not included). To secure your items, align the holes on the lid and the front panel, then insert a padlock through the aligned holes.

### Using as a Bench:

When the lid is securely closed, the sturdy construction of the deck box allows it to be used as a comfortable two-person seating bench. Ensure the lid is fully closed and latched before sitting.

## 5. MAINTENANCE

---

To ensure the longevity and appearance of your Devoko Deck Box, follow these simple maintenance guidelines:

- **Cleaning:** Regularly wipe down the exterior with a soft cloth and mild soap and water. Avoid abrasive cleaners or harsh chemicals, as these can damage the resin material.
- **Inspection:** Periodically check all connections and hinges for any signs of wear or damage. Ensure the lid closes properly and the locking mechanism functions correctly.
- **Winter Storage:** While the deck box is designed for all-weather use, storing it in a sheltered area during harsh winter conditions can further extend its lifespan. Ensure it is clean and dry before prolonged storage.

## 6. TROUBLESHOOTING

---

If you encounter any issues with your Devoko Deck Box, consider the following:

- **Lid not closing properly:** Check for any obstructions around the hinges or inside the box. Ensure all panels are securely snapped into place.
- **Water inside the box:** While waterproof, extreme weather conditions or improper closure can lead to moisture. Ensure the lid is fully closed and latched. Check for any cracks or damage to the resin material.
- **Difficulty moving the box:** If the box is filled with heavy items, empty it before attempting to move it using the side handles.


## 7. SPECIFICATIONS

---

Below are the detailed specifications for the Devoko 97 Gallon Deck Box:

<b>Feature</b>	<b>Detail</b>
Brand	Devoko
Model Number	24312DBN
Color	Deep Brown
Material	Resin & Polypropylene
Special Feature	Lockable
Style	Modern
Product Dimensions	48"L x 22"W x 24.5"H
Capacity	97 Gallons
Closure Type	Flip Top
Water Resistance Level	Waterproof
Item Weight	37.5 Pounds
Opening Mechanism	Hinge (Hydraulic)
Shape	Rectangular
Pattern	Striped (Rattan-like)

# 100 Gallon Deck Box Dimensions



*Image: Visual representation of the deck box dimensions.*

## 8. WARRANTY AND SUPPORT

The Devoko outdoor storage box is covered by a warranty. If you have any questions, our dedicated team is always here to provide you with full customer support and excellent after-sales service. Please refer to your purchase documentation for specific warranty terms and contact information.