



Manuals.plus /

- › Glückluz /
- › Glückluz Portable Air Conditioner User Manual

## Glückluz Aire Acondicionado Portatil

# Glückluz Portable Air Conditioner User Manual

Model: Aire Acondicionado Portatil

## 1. INTRODUCTION

Thank you for choosing the Glückluz Portable Air Conditioner. This innovative 3-in-1 device functions as an air cooler, a fan, and a humidifier, providing a comfortable environment in your home, bedroom, or small office. Designed for energy efficiency and quiet operation, it offers convenient features like remote control and a timer. Please read this manual carefully before use to ensure proper operation and maintenance.



Figure 1.1: Glückluz Portable Air Conditioner and Remote Control

## 2. SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before using the appliance.
- Do not operate the unit with a damaged cord or plug.
- Do not place the unit near heat sources or in direct sunlight.
- Ensure the power supply matches the voltage specified on the unit's rating label.
- Always unplug the unit before cleaning, filling, or performing maintenance.
- Do not immerse the unit, cord, or plug in water or other liquids.
- Keep out of reach of children and pets.
- Use only on a flat, stable surface to prevent tipping.
- Do not block air inlets or outlets.
- Do not use the unit without water in cooling mode.

### **3. PRODUCT OVERVIEW**

#### **3.1 Components**

- Main Unit (Air Cooler)
- Remote Control
- Ice Boxes (4 included)
- Wheels (4 included)
- User Manual

#### **3.2 Control Panel and Remote Functions**

# Panel de Control y mando a distancia

El suministro de aire de circulación de gran angular refresca cada esquina



Figure 3.1: Control Panel and Remote Control

The unit features an intuitive control panel on top and a convenient remote control for ease of use. Key functions include:

- **TIMER:** Set operation time from 1 to 12 hours.
- **SWING:** Activate 60° automatic horizontal oscillation.
- **MODE:** Select between Normal, Natural, and Sleep modes.
- **COOL:** Enable/disable cooling (evaporative) function.
- **SPEED:** Adjust fan speed (Low, Medium, High).
- **ON/OFF:** Power the unit on or off.

## 4. SETUP

Follow these steps for initial setup:

1. **Attach Wheels:** Carefully turn the unit upside down and insert the four wheels into the designated slots at the bottom. Ensure they are securely fastened.
2. **Prepare Ice Boxes:** Fill the included ice boxes with water and place them in a freezer until completely frozen. These will enhance the cooling effect.
3. **Fill Water Tank:** Open the top lid of the unit. Pour clean water into the 8-liter water tank. You can also place the frozen ice boxes into the designated compartments within the water tank. Ensure the water level is between the 'MIN' and 'MAX' indicators.
4. **Position the Unit:** Place the air cooler on a flat, stable surface in the desired location. Ensure there is adequate space around the unit for proper airflow.
5. **Plug In:** Connect the power cord to a standard 110V electrical outlet.



Figure 4.1: Setup Steps

## 5. OPERATING INSTRUCTIONS

### 5.1 Power On/Off

- Press the **ON/OFF** button on the control panel or remote to turn the unit on or off.

### 5.2 Fan Speed Adjustment

- Press the **SPEED** button repeatedly to cycle through Low, Medium, and High fan speeds.

### 5.3 Mode Selection

# 3 modos & 3 velocidades & oscilación gran angular



Velocidad baja



Velocidad media



Velocidad alta



Figure 5.1: Modes and Speeds

- Press the **MODE** button to select desired operating mode:
  - **Normal Mode:** Constant airflow at selected speed.
  - **Natural Mode:** Simulates natural breeze with varying fan speeds.
  - **Sleep Mode:** Gradually reduces fan speed and operates quietly for undisturbed sleep.

## 5.4 Cooling/Humidifying Function

# 3-En-1 Enfriador de Aire Portátil



Figure 5.2: 3-in-1 Functions

- Press the **COOL** button to activate the evaporative cooling and humidifying function. Ensure the water tank is filled.
- For enhanced cooling, use the frozen ice boxes in the water tank.

## 5.5 Oscillation

# 3 en 1 acondicionador de aire portátil



Figure 5.3: Air Circulation with Oscillation

- Press the **SWING** button to enable 60° automatic horizontal oscillation, distributing air across a wider area.
- Manually adjust the vertical louvers up to 45° for directional airflow.

## 5.6 Timer Function

- Press the **TIMER** button repeatedly to set the desired operating time (from 1 to 12 hours). The unit will automatically turn off after the set time.

## 6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your air cooler.

### 6.1 Cleaning the Exterior

- Always unplug the unit before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.

### 6.2 Cleaning the Water Tank

# Portátil y fácil de limpiar



Figure 6.1: Visible Water Level and Cleaning

- Empty the water tank regularly, especially if the unit will not be used for an extended period.
- Remove the water tank (if detachable) or access the tank opening.
- Clean the inside of the tank with a soft brush and mild detergent. Rinse thoroughly with clean water.
- Ensure the tank is completely dry before refilling or storing.

## 6.3 Air Filter Cleaning

- The unit has an air filter at the back. Regularly check and clean it to maintain airflow efficiency.
- Remove the filter and rinse it under running water. Allow it to air dry completely before reinserting.

## 6.4 Storage

- If storing the unit for a long time, ensure the water tank is empty and clean.
- Clean the entire unit and store it in a cool, dry place, away from direct sunlight.

## 7. TROUBLESHOOTING

If you encounter issues, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit does not turn on	No power supply; Power cord not plugged in; Power button not pressed.	Check power outlet; Ensure cord is securely plugged in; Press the ON/OFF button.
Weak airflow	Air filter is dirty; Air inlet/outlet blocked; Fan speed set too low.	Clean the air filter; Remove any obstructions; Increase fan speed.
No cooling effect	Water tank is empty; COOL function not activated; Ice boxes not used.	Fill water tank; Press the COOL button; Use frozen ice boxes.
Unusual noise	Unit not on a flat surface; Obstruction in fan blades; Water pump issue.	Place on a stable surface; Check for obstructions (unplug first); Contact customer support if pump issue persists.
Water leakage	Water tank overfilled; Unit tilted.	Do not exceed MAX water level; Ensure unit is on a flat surface.

If the problem persists after trying these solutions, please contact customer support.

## 8. SPECIFICATIONS

Feature	Detail
Model Number	Aire Acondicionado Portatil
Functions	Air Cooler, Fan, Humidifier (3-in-1)
Water Tank Capacity	8 Liters
Power Source	Corded Electric
Voltage	110 Volts
Wattage	60 Watts
Air Flow Capacity	800 Cubic Feet Per Minute
Noise Level	50 dB
Dimensions (L x W x H)	32 x 32 x 60 cm (12.6 x 12.6 x 23.6 inches)
Weight	4.3 Kilograms (9.5 lbs)
Special Features	Humidifier, Remote Control, Timer (1-12H), 3 Fan Speeds, 3 Modes (Normal, Natural, Sleep), 60° Auto Oscillation, 45° Manual Vertical Adjustment
Included Components	1 x Air Cooler, 4 x Ice Boxes, 1 x Remote Control, 1 x Manual, 4 x Wheels

## 9. WARRANTY AND SUPPORT

Glückluz products are manufactured to the highest quality standards. This product comes with a standard manufacturer's warranty. For detailed warranty information, please refer to the warranty card included in the packaging or visit our official website.

For technical support, troubleshooting assistance, or any questions regarding your product, please contact Glückluz customer service. Our team is dedicated to providing prompt and helpful assistance.

**Customer Service Contact:** Please refer to the contact information provided on the product packaging or our official website for the most up-to-date support channels.