



[Manuals.plus](#) /

› [BodyHush](#) /

› BodyHush Mini Portable White Noise Machine HB2 User Manual

BodyHush HB2

BodyHush Mini Portable White Noise Machine HB2 User Manual

Model: HB2

1. PRODUCT OVERVIEW

The BodyHush Mini Portable White Noise Machine (Model HB2) is a compact, rechargeable device designed to provide a variety of soothing sounds for relaxation, sleep, and noise masking. Its small size and flexible clip make it suitable for use at home, in the office, or while traveling.



Image: Front view of the BodyHush Mini Portable White Noise Machine, featuring a white grille with a moon and star logo in the center.

2. SAFETY INFORMATION

- To prevent choking hazards, ensure children do not place the device in their mouth.

3. GETTING STARTED (SETUP)

1. **Charge the Device:** Connect the device to a power source using the provided USB cable. Ensure the device is fully charged before first use for optimal battery life.
2. **Power On:** Slide the power switch to the 'ON' position to turn on the device.

USB-Rechargeable

used up to 22h



Image: The BodyHush sound machine connected to a USB charging cable, illustrating its rechargeable feature.

4. OPERATING INSTRUCTIONS

1. **Turn On/Off:** Slide the ON/OFF switch located on the side of the device. To turn off, press and hold the power button for 3 seconds.
2. **Select Sound:** Use the dedicated sound selection buttons to cycle through the 30 available sounds. Sounds are categorized into white noise, baby sounds, and nature sounds.
3. **Adjust Volume:** Press the '+' button to increase the volume and the '-' button to decrease it. There are 32 adjustable volume levels.
4. **Set Timer:** Press the timer button to set an auto-off timer for 30, 60, or 90 minutes. The device can also play continuously.
5. **Memory Function:** The device automatically remembers the last sound and volume setting used, eliminating the need to reset preferences for subsequent uses.
6. **Attach Device:** Utilize the flexible clip to attach the device to strollers, car seats, cribs, or bags for convenient portability.



Better Sleep for Baby

Image: Visual representation of the 30 soothing sounds available on the device, grouped by type.



Power Up Your Sleep

4 Timers & Memory Function



Image: The sound machine on a nightstand next to a sleeping person, highlighting the timer and memory functions.

5. FEATURES

- **30 Soothing Sounds:** Includes white noise, brown noise, pink noise, baby hushing sound, lullabies, fan, rain, thunder rain, wave, bird, fire, meditation, and more.
- **32 Volume Levels:** Allows for precise control over sound output to effectively mask environmental noises.
- **Rechargeable Battery:** Equipped with a Lithium Polymer battery, offering extended use on a single charge.
- **Auto-Off Timer:** Options for continuous play or automatic shut-off after 30, 60, or 90 minutes.
- **Memory Function:** Retains the last selected sound and volume setting for convenience.
- **Flexible Clip:** Integrated clip for easy attachment to various objects, enhancing portability.
- **Compact Design:** Small and lightweight, making it ideal for travel and on-the-go use.



Image: The sound machine attached to luggage, demonstrating its suitability for travel.

Super Loudspeaker Driver

32 Adjustable Volume Level



Image: An internal diagram of the sound machine's speaker, illustrating its capacity for 32 adjustable volume levels.

6. SPECIFICATIONS

Attribute	Detail
Product Dimensions	2.63 x 2.63 x 1.57 inches
Item Weight	5.93 ounces
Item Model Number	HB2
Batteries	1 Lithium Polymer batteries required (included)
Manufacturer	BodyHush
Material	Plastic
Power Source	Battery Powered

7. MAINTENANCE

To ensure optimal performance and longevity of your BodyHush Mini Portable White Noise Machine, follow these maintenance guidelines:

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Charging:** Charge the device regularly, even if not in frequent use, to maintain battery health.

8. TROUBLESHOOTING

If you encounter any issues with your device, please refer to the following common troubleshooting steps:

- **Device Not Turning On:** Ensure the device is fully charged. Connect it to the USB cable and allow it to charge for at least 30 minutes before attempting to power on again.
- **No Sound Output:** Check the volume level using the '+' button. Ensure the device is not muted.
- **Sound Quality Issues:** Ensure the device is not obstructed. Try cycling through different sound options to see if the issue persists with all sounds.
- **Battery Draining Quickly:** Ensure the device is fully charged. Avoid extreme temperatures during use and charging.

If the problem persists after attempting these steps, please contact customer support.

9. WARRANTY AND SUPPORT

The BodyHush Mini Portable White Noise Machine (Model HB2) comes with an **18-month warranty**. This warranty covers manufacturing defects and quality-related issues.

For warranty claims, technical support, or any other inquiries, please contact BodyHush customer service. Please have your purchase details and model number (HB2) ready when contacting support.