



Manuals.plus /

› TTARTISAN /

› TtArtisan 10mm F2 APS-C Ultra-Wide Camera Lens for Fuji X Mount Cameras Instruction Manual

## TTARTISAN 10mm F2 APS-C

# TTArtisan 10mm F2 APS-C Ultra-Wide Camera Lens Instruction Manual

For Fuji X Mount Cameras

## INTRODUCTION

---

This manual provides essential information for the proper use and care of your TTArtisan 10mm F2 APS-C Ultra-Wide Camera Lens. Please read these instructions carefully before using the lens to ensure optimal performance and longevity. This lens is designed for Fuji X Mount APS-C cameras.

## PRODUCT FEATURES

---

- **105° Angle of View:** The ultra-wide-angle design allows for capturing expansive scenes, suitable for landscapes and cityscapes.
- **Nearly Zero Distortion:** Engineered to minimize barrel or pincushion distortions, providing realistic visual effects for architectural and indoor photography.
- **Create Amazing Portraits:** Effective for portraits by including background context and utilizing wide-angle perspective for attractive results.
- **Ideal for Starry Sky Photography:** Ultra-wide view, large F2 aperture for lower ISO and improved image quality, and reduced coma for rounder star shapes.
- **Capture Dark Scenes:** The F2.0 aperture allows significant light intake, beneficial for low-light environments like starry nights.
- **Starburst Effect:** Features 8 aperture blades to produce an attractive 8-spike starburst effect from light sources.
- **Professional Mode with Filter Holder:** Includes a 72mm circular filter holder and lens cap, compatible with ND, graduated ND, and circular polarizer filters for enhanced outdoor shooting.

## WHAT'S IN THE BOX

---

- 1 x TTArtisan 10mm F2 Lens
- 1 x Front Lens Cap

- 1 x Rear Lens Cap
- 1 x User Manual
- 1 x Box

## SETUP

---

### Attaching the Lens

1. Ensure your camera is powered off.
2. Remove the rear lens cap from the TTArtisan 10mm F2 lens and the body cap from your camera.
3. Align the red dot on the lens barrel with the corresponding red dot on your camera's lens mount.
4. Gently insert the lens into the camera mount and rotate it clockwise until it clicks into place. Do not force the lens.



The TTArtisan 10mm F2 lens securely attached to a Fuji X-mount camera body.

### Removing the Lens

1. Ensure your camera is powered off.
2. Press and hold the lens release button on your camera body.
3. While holding the button, rotate the lens counter-clockwise until it detaches from the camera mount.
4. Immediately attach the rear lens cap to the lens and the body cap to your camera to protect the sensor and lens elements from dust.

## OPERATING INSTRUCTIONS

---

### Manual Focus

This is a manual focus lens. To achieve sharp focus:

1. Set your camera to manual focus (MF) mode.
2. Look through the viewfinder or use the LCD screen.
3. Rotate the focus ring on the lens until your subject appears sharp. Utilize your camera's focus peaking or magnification assist features for precise focusing.



The focus and aperture rings on the TTArtisan 10mm F2 lens.

## Aperture Control

The lens features a manual aperture ring. Rotate the aperture ring to select your desired f-stop (from F2 to F16). A wider aperture (smaller f-number like F2) allows more light and creates a shallower depth of field, while a narrower aperture (larger f-number like F16) allows less light and creates a greater depth of field.



mechanical components.

## TROUBLESHOOTING

---

### Lens Not Attaching Securely

Ensure the lens is correctly aligned with the camera mount's red dot and rotated clockwise until it clicks. Check for any obstructions on the lens mount or camera body. Do not force the lens.

### Images Are Blurry

This is a manual focus lens. Ensure you are manually focusing correctly using your camera's focus peaking or magnification assist. Check your camera's shutter speed and ISO settings, especially in low light, to avoid motion blur or noise. Verify the aperture setting is appropriate for your desired depth of field.

### No Image Displayed

Ensure your camera is set to shoot without a lens attached (often called 'Release Shutter without Lens' or similar, found in your camera's custom settings menu). This is common for manual lenses without electronic contacts.

## SPECIFICATIONS

---

Feature	Specification
Brand	TTARTISAN
Focal Length	10mm
Lens Type	Wide Angle, Prime
Compatible Mountings	Fujifilm X
Maximum Aperture	F2
Minimum Aperture	F16
Focus Type	Manual Focus
Number of Diaphragm Blades	8
Real Angle Of View	105 Degrees
Image Stabilization	Optical (Camera dependent)
Lens Coating Description	ZERO Coating
Water Resistance Level	Not Water Resistant
Exposure Control Type	Manual

## WARRANTY

---

This TTArtisan 10mm F2 APS-C Ultra-Wide Camera Lens comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accident, unauthorized repair, or normal wear and tear.

## SUPPORT

---

For further assistance, technical support, or warranty inquiries, please contact TTArtisan customer service through their official website or the retailer where the product was purchased. Always refer to your camera's instruction manual for specific settings related to using manual lenses.

You can visit the official TTArtisan store for more information: [TTArtisan Store on Amazon](#)