

[Manuals.plus](#) /

› [AIPER](#) /

› AIPER Scuba SE Robotic Pool Cleaner User Manual

AIPER Scuba SE

AIPER Scuba SE Robotic Pool Cleaner User Manual

Model: Scuba SE | Brand: AIPER

1. INTRODUCTION

The AIPER Scuba SE is a compact, cordless robotic pool cleaner designed for efficient and hassle-free maintenance of flat-bottom pools. Its hydrodynamic design ensures thorough cleaning, while features like automatic self-parking and quick drainage enhance user convenience. Enjoy a cleaner pool with minimal effort.



Figure 1: The AIPER Scuba SE Robotic Pool Cleaner.

Your browser does not support the video tag.

Video 1: Overview of the AIPER Scuba SE Robotic Pool Cleaner in action.

2. SAFETY INFORMATION

Please read all safety instructions carefully before operating the device. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Ensure the charging port is completely dry before connecting the charger.
- Do not operate the cleaner when people or pets are in the pool.
- Use only the original charger provided by AIPER.
- Keep the device out of reach of children.
- Store the cleaner in a cool, dry place when not in use.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- AIPER Scuba SE Robotic Pool Cleaner
- Power Adapter
- Retrieval Hook
- User Manual

4. SETUP

4.1 Charging the Device

Before first use, fully charge the AIPER Scuba SE. The device is powered by a Lithium-Ion battery, providing up to 90 minutes of cleaning time on a full charge.

1. Locate the charging port on the device. Ensure it is clean and dry.
2. Connect the power adapter to the charging port.
3. Plug the power adapter into a wall outlet.
4. The LED indicator on the charger will show the charging status. It typically takes 3 hours for a full charge.

Volle Leistung Garantiert

Niemand will beim Reinigen warten

3 Stunden



Figure 2: Connect the charger to the device and a power outlet. The LED indicates charging status.

5. OPERATION

5.1 One-Click Activation

The AIPER Scuba SE features simple one-click activation for immediate cleaning.

1. Ensure the device is fully charged.
2. Press the power button located on the underside of the cleaner to activate it.
3. Gently submerge the cleaner into the pool. It will begin its cleaning cycle automatically.

Kabellos & Einfach zu Bedienen

Genießen Sie eine sicherere und stressfreie Reinigungserfahrung



Figure 3: The cordless design and one-click activation make the Scuba SE easy to use.

5.2 Cleaning Process

The Scuba SE utilizes a new hydrodynamic design and dual bottom brushes for efficient cleaning of flat-bottom pools up to 80 m² (860 sq. ft.). It effectively picks up debris and filters the water.

Neues Hydrodynamisches Design

Widmet mehr Leistung der Reinigung



Figure 4: The hydrodynamic design allows the cleaner to glide efficiently, focusing energy on cleaning.

Your browser does not support the video tag.

Video 2: Demonstrates the cleaning capabilities and hydrodynamic movement of the Scuba SE.

5.3 Automatic Self-Parking

When the battery is low, the Scuba SE will automatically park near the edge of your pool for easy retrieval, preventing you from getting wet.

Automatische Parktechnologie

Mühelose Rückholung



Figure 5: The automatic parking feature ensures effortless retrieval of the cleaner.

5.4 Retrieval

Use the provided retrieval hook to easily lift the cleaner from the pool once its cleaning cycle is complete or it has self-parked.

1. Attach the retrieval hook to a standard pool pole (not included).
2. Hook the cleaner's handle and gently lift it out of the water.

6. MAINTENANCE

6.1 Quick Drainage

The Scuba SE features an advanced water drainage system that allows up to 80% of stored water to be released in just 15 seconds, making it lighter and easier to handle after use.

Ultraportabilität

Schnelle Wasserfreisetzung
für einfache Anwendung



Figure 6: The quick drainage system facilitates easy removal from the pool.

6.2 Filter Cleaning

Regular cleaning of the filter is essential for optimal performance.

1. Open the cleaner's cover to access the filter basket.
2. Remove the filter basket.
3. Empty any collected debris.
4. Rinse the filter basket thoroughly with a hose until clean.
5. Reinsert the clean filter basket and close the cover securely.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Cleaner does not turn on.	Low battery; Power button not pressed correctly.	Charge the device fully; Ensure the power button is pressed firmly.
Cleaner stops mid-cycle.	Low battery; Impeller blocked; Excessive debris in filter.	Recharge the device; Check for and remove any blockages from the impeller; Clean the filter basket.
Poor cleaning performance.	Full or dirty filter; Impeller blocked; Device not suitable for pool type (e.g., sloped bottom).	Clean the filter basket; Clear any impeller blockages; Ensure pool is flat-bottomed as specified.
Cleaner does not self-park at edge.	Obstructions in pool; Sensor interference.	Remove any large objects from the pool; Ensure clear path to pool edge.

8. SPECIFICATIONS

Feature	Detail
Model	Scuba SE
Power Source	Battery Powered
Battery Type	Lithium-Ion (1 battery required, included)
Battery Energy Content	28.08 Watt-hours
Item Weight	3.4 Kilograms
Product Dimensions	20.32 x 30.48 x 40.64 cm (34.3L x 28W x 17H cm)
Special Features	Cordless, Ultra-portability
Control Method	Touch
Material Type	Plastic
Capacity	2 Liters
Cleaning Time	Up to 90 minutes
Max Pool Area	Up to 80 m² (860 sq. ft.)

9. WARRANTY AND SUPPORT

The AIPER Scuba SE comes with a 2-year warranty. For any questions, technical support, or warranty claims, please contact AIPER customer service. You can find contact information on the official AIPER website or through your purchase platform.

- **Warranty Type:** Limited
- **Return Policy:** 30 days (refund/replacement)
- **Customer Service:** Available 24/7
- **EU Repair Center:** For quick reaction and solution

For more information, visit the [AIPER Store](#).

© 2024 AIPER. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question