

NYXI NK33

NYXI Hyperion 2 Carrying Case Instruction Manual

Model: NK33

1. INTRODUCTION

This manual provides essential information for the proper use and care of your NYXI Hyperion 2 Carrying Case. Designed for the Nintendo Switch, Switch OLED, and Switch Lite, especially when paired with NYXI Hyperion 2 controllers, this case offers robust protection and convenient storage for your gaming console and accessories.

2. PRODUCT FEATURES

- **Secure & Stylish Design:** Constructed from high-quality nylon cloth material for durability and comfort, providing protection for your Switch/Switch 2/OLED.
- **Organized Gaming Storage:** Features multicassette storage for up to 12 game cards, keeping your games accessible.
- **Controller-Friendly Expansion:** Specifically designed with expanded size to accommodate the NYXI Hyperion 2 controllers attached to your Switch.
- **Travel-Ready Protection:** EVA complex cases offer robust protection for your Nintendo Switch during travel and daily use.
- **Enthusiast-Driven Design:** Tailored for Switch/Switch OLED game enthusiasts, ensuring a secure, convenient, and versatile storage solution.

Extra Large Storage Capacity



12 x Game Card



HDMI Cable



NYXI Hyperion 2



Nintendo Switch/Switch
OLED/Lite

Figure 2.1: Extra Large Storage Capacity. The case is designed to hold a Nintendo Switch with NYXI Hyperion 2 controllers attached, along with 12 game cards and other small accessories.


Water-Resistant

High quality density fabric avoid water or pests damage



Anti-Collision

Anti-friction lining decrease the impact of bump,safely protect console



Anti-Scratch

Holding console screen from being crushed and scratches





Figure 2.2: Protective Features. The case features water-resistant fabric, anti-collision design with anti-friction lining, and anti-scratch properties to protect the console screen.



Screen Protection

Protect your screen from direct friction, no scratches or crushing

Smooth Zippers

Dual zipper pulls, sturdy and durable, not easy to break

Sturdy Handle

Silicone handle, easy to carry, reinforced braided tape, no breakage

Figure 2.3: Design Details. The case includes screen protection, smooth dual zippers for secure closure, and a sturdy silicone handle for comfortable carrying.

3. SETUP

1. **Open the Case:** Unzip the case completely using the dual zippers.
2. **Insert Console:** Carefully place your Nintendo Switch, Switch OLED, or Switch Lite (with or without attached NYXI Hyperion 2 controllers) into the main compartment. Ensure it fits snugly into the molded interior.
3. **Store Game Cards:** Insert up to 12 game cards into the dedicated slots on the flap.
4. **Add Accessories:** Utilize the mesh pocket in the lid for small accessories such as charging cables, earbuds, or additional Joy-Cons.
5. **Close the Case:** Gently close the lid and zip up both zippers to secure the contents.



Figure 3.1: Interior Layout. The case interior is designed to securely hold the console, game cards, and small accessories.

4. OPERATING INSTRUCTIONS

The NYXI Hyperion 2 Carrying Case is designed for straightforward use:

- **Carrying:** Use the sturdy silicone handle to transport the case. Ensure the zippers are fully closed to prevent accidental opening.
- **Accessing Contents:** Unzip the case completely to access your console and accessories. The dual zippers allow for smooth opening and closing.
- **Screen Protection:** The internal flap provides a soft barrier to protect your console's screen from scratches and friction when the case is closed.



Figure 4.1: Product in Use. The case provides convenient storage and protection for your gaming setup.

5. MAINTENANCE

To ensure the longevity and appearance of your carrying case, follow these maintenance guidelines:

- **Cleaning:** Wipe the exterior with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by wiping with a clean, damp cloth. Allow to air dry completely.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the material.
- **Storage:** Store the case in a cool, dry place away from direct sunlight when not in use.
- **Zipper Care:** Keep zippers free from dirt and debris. If zippers become stiff, a small amount of zipper lubricant can be applied.

6. TROUBLESHOOTING

- **Case does not close properly:** Ensure all items inside are correctly placed and not overfilling the case. Check for any obstructions in the zipper path.

- **Zippers are stiff:** Apply a small amount of zipper lubricant or a graphite pencil lead along the zipper teeth to improve smoothness.
- **Minor spills on exterior:** Due to its water-resistant properties, most minor spills can be wiped off immediately with a dry cloth. For larger spills, follow the cleaning instructions in Section 5.

7. SPECIFICATIONS

Feature	Detail
Model Number	NK33
Case Material	Nylon
Closure Type	Zipper
Handle Type	Top Handle (Silicone)
Number of Compartments	1 (Main compartment with game card slots and mesh pocket)
Item Weight	9.6 ounces
Package Dimensions	11.65 x 5.83 x 2.56 inches

8. WARRANTY AND SUPPORT

For warranty information or product support, please refer to the official NYXI website or contact their customer service directly. Keep your purchase receipt as proof of purchase.
