

PZL D51 D51-H

PZL D51/D51-H Remote Control Instruction Manual

Model: D51 D51-H

For Vizio 2.1/5.1 Soundbar Home Sound Bar Systems

1. INTRODUCTION

This manual provides comprehensive instructions for the use and maintenance of your new PZL D51/D51-H replacement remote control. This remote is designed to be a direct replacement for various Vizio soundbar models, offering reliable control without the need for complex programming.

2. COMPATIBILITY

The PZL D51/D51-H remote control is compatible with a wide range of Vizio soundbar models. It is specifically designed to work with Vizio V-Series and M-Series sound bars, including 2.1, 5.1, 5.1.2, and 4.1 channel systems.

Compatible Vizio Soundbar Models:

- M51aH6
- SB3241nH6
- V21H8R
- M512aH6
- M215aJ6
- M21dH8R
- P514H6
- P514aH6
- V51-H6
- M51ax-J6
- M512a-H6
- V51x-J6
- V21-H8R
- SB3241n-H6

- V51xJ6
- V51H6
- M51axJ6
- M215a-J6
- M21d-H8R
- P514-H6
- P514a-H6
- M51a-H6
- V21x-J8
- Vizio Elevate sound bar
- Vizio 5.1.4 Channel Soundbar

This remote also replaces Vizio soundbar remotes with model numbers D512-H, D510-H, D20, and D21-H.

3. FEATURES

- **Backlit Display:** Features a backlit display for easy visibility and operation in low-light conditions.
- **Ergonomic Design:** Constructed from high-quality ABS material with an ergonomic arc design for a comfortable and secure grip.
- **Responsive Buttons:** Keys are designed for responsiveness and tactile feedback, ensuring precise control.
- **Wide Operating Range:** Provides precise control over distances of up to 12 meters (40 feet).
- **Quick Response Time:** Delivers a response time of less than 0.2 seconds to the connected device.
- **Durability:** Supports over 120,000 click approval tests, indicating long-term reliability.
- **No Programming Required:** Operates immediately upon battery installation; no pairing or setup is necessary.




Remote Detail

Bluetooth

Backlit Design

Backlit design for easy control
even in the dark



ABS Material

The remote is made of
high-quality ABS materials.



Comfortable Grip

Compact size makes this
remote easy to grip

Image: The remote control features a backlit display and is made from durable ABS material, ensuring a comfortable grip and responsive buttons.

The infrared technology gives you a stable connection

*no need to worry about signal interference.
And the precise control works up to 32ft/10m*



32FT
Far From

120°
Multi Angle Control

Image: The remote utilizes infrared technology for a stable connection, providing reliable control from up to 32 feet away and at various angles.

4. SETUP

The PZL D51/D51-H remote control is designed for immediate use. No programming or pairing is required. Simply install the batteries, and the remote will be ready to operate your compatible Vizio soundbar.

Battery Installation:

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two (2) 1.5V AAA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

Note: Batteries are not included with the remote control and must be purchased separately.

Requires Two 1.5V AAA Batteries

(Batteries are not included)



Image: The remote requires two AAA batteries for operation. The battery compartment is located on the back, with clear markings for correct battery insertion.



Image: This remote operates immediately after battery installation, requiring no complex pairing or setup procedures.

5. OPERATING INSTRUCTIONS

Once batteries are installed, point the remote control directly at your Vizio soundbar. The remote uses infrared (IR) technology to communicate with your device.

Key Functions:



Image: Front and back views of the remote, illustrating the button layout and the input key guide.

- **Power Button ():** Turns the soundbar on or off.
- **INPUT Button:** Cycles through available audio input sources (e.g., AUX, Optical, HDMI ARC, Bluetooth, USB). Refer to the "INPUT KEY" guide on the back of the remote for specific input types.

- **BT Button:** Directly switches to Bluetooth input mode.
- **OK Button:** Confirms selections within menus.
- **Directional Pad (Up/Down/Left/Right):** Navigates through menus or adjusts settings.
- **EQ Button:** Accesses Equalizer settings to adjust audio profiles.
- **LEVEL Button:** Adjusts various audio levels (e.g., bass, treble, subwoofer).
- **SETUP Button:** Enters the soundbar's setup menu.
- **EFFECT Button:** Cycles through audio effects or sound modes.
- **Volume Up (+):** Increases the soundbar's volume.
- **Volume Down (-):** Decreases the soundbar's volume.
- **Mute Button ():** Mutes or unmutes the soundbar's audio.

Backlight Function:

The remote features a backlit display for enhanced visibility in dark environments. The backlight will automatically activate when buttons are pressed and will turn off after a short period of inactivity to conserve battery life.



Image: The remote's backlit display illuminates the buttons, making it easy to operate in dimly lit rooms.

6. MAINTENANCE

To ensure the longevity and optimal performance of your PZL D51/D51-H remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control regularly with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or the backlight dims significantly. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** When not in use for extended periods, remove the batteries to prevent leakage, which can damage the remote. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** While durable, avoid dropping the remote control, as this can damage internal components or the casing.
- **Liquid Exposure:** Keep the remote away from liquids. If it comes into contact with liquid, immediately remove the batteries and allow it to dry completely before reinserting them.

7. TROUBLESHOOTING

If you experience issues with your PZL D51/D51-H remote control, refer to the following troubleshooting steps:

Remote Not Responding:

- **Check Batteries:** Ensure batteries are inserted correctly with the proper polarity. Replace old or depleted batteries with new 1.5V AAA batteries.
- **Line of Sight:** Confirm there is a clear line of sight between the remote control and the soundbar's IR receiver. Obstructions can block the signal.
- **Distance:** Ensure you are within the effective operating range (up to 12 meters or 40 feet) of the soundbar.
- **Soundbar Power:** Verify that your Vizio soundbar is powered on and functioning correctly.

Backlight Not Working:

- **Battery Level:** A low battery level can affect backlight performance. Replace batteries if necessary.
- **Button Press:** The backlight activates only when a button is pressed. Ensure you are pressing a button firmly.

Interference:

- **Other Devices:** Other electronic devices emitting infrared signals or strong light sources (like direct sunlight) can sometimes interfere with the remote's operation. Try operating the remote in a different environment or by blocking interfering light.

If the issue persists after following these steps, please refer to the "Warranty & Support" section for further assistance.

8. SPECIFICATIONS

Feature	Detail
Model Number	D51 D51-H
Brand	PZL

Feature	Detail
Special Features	Backlit, Digital Display
Color	Black
Max Supported Devices	1 (Vizio Soundbar)
Compatible Devices	Home Theater (Vizio Soundbars)
Power Source	2 x 1.5V AAA Batteries (Not Included)
Operating Range	Up to 12 meters (40 feet)
Item Weight	1.76 ounces
Package Dimensions	6.02 x 1.97 x 0.55 inches



Image: Detailed dimensions of the remote control, providing a clear understanding of its physical size.

9. WARRANTY & SUPPORT

PZL is committed to providing high-quality products and professional after-sales service. While specific warranty details are not provided in this manual, if you encounter any questions regarding your order or the compatibility of your remote control, please contact the seller directly.

Customer support is typically available to respond to inquiries within 12 hours on weekdays.