

[Manuals.plus](#) /

> [TEETHEORY](#) /

> TEETHEORY Rotating Electric Toothbrush User Manual

TEETHEORY 199AB

TEETHEORY Rotating Electric Toothbrush User Manual

Model: 199AB

INTRODUCTION

Thank you for choosing the TEETHEORY Rotating Electric Toothbrush. This manual provides essential information for the safe and effective use of your new toothbrush. Please read it thoroughly before first use and keep it for future reference.

SAFETY INFORMATION

Warning: Not suitable for young children due to choking hazard. Use exclusively for oral hygiene.

Product packaging may contain information different from that shown on our website. Always read the label, warnings, and instructions provided with the product before use.

- Do not immerse the charging base in water.
- Ensure the charging port is dry before connecting the USB cable.
- Keep out of reach of children.
- Consult a dentist before use if you have severe gum disease or oral surgery.

PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x TEETHEORY Electric Toothbrush Handle
- 1 x USB Charging Cable
- 1 x Protective Cap
- 4 x Precise Cleaning Brush Heads
- 4 x Whitening and Deeper Cleaning Brush Heads
- 1 x User Manual

TEETHEORY Protect Your Teeth and Gums.



Image: Contents of the TEETHEORY Electric Toothbrush package, showing the main unit, charging cable, and various brush heads.

PRODUCT OVERVIEW

The TEETHEORY Rotating Electric Toothbrush is designed for effective oral hygiene, offering multiple cleaning modes and a smart timer for optimal brushing.

Key Features:

- **Rotating Brush Head:** Provides superior plaque removal compared to manual toothbrushes.
- **8 Brush Heads Included:** Comes with 4 Precise Cleaning heads and 4 Whitening and Deeper Cleaning heads, offering up to 24 months of use (based on 3-month replacement).
- **4 Cleaning Modes:** White, Clean, Polish, and Massage for customized brushing.
- **Smart Timer:** 2-minute auto-timer with 30-second quadrant reminders to ensure thorough cleaning.
- **Long Battery Life:** 1200mAh battery provides up to 25 days of use on a 4-hour charge.
- **IP67 Waterproof:** Suitable for use in the bath or shower.

SMART TOOTHBRUSH

2 Types x 4 = 8 Brush Heads

30s
2 MINS

2 Min Smart Timer Reminder

Precise Cleaning Heads x4

Floss-like Whitening Heads x4

40,000 Vpm
Maglev Motor

WHITE

Image: Illustration of the rotating brush head mechanism for effective cleaning.

SETUP

1. Charging the Toothbrush

1. Before first use, fully charge the toothbrush for approximately 4 hours.
2. Connect the USB charging cable to the charging port at the bottom of the toothbrush handle.
3. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a computer USB port.
4. The charging indicator light will illuminate during charging and turn off when fully charged.



Image: The toothbrush handle connected to a USB power source for charging, indicating a 4-hour charge provides 25 days of use.

2. Attaching the Brush Head

1. Align the brush head with the metal shaft on the toothbrush handle.
2. Push the brush head down firmly until it clicks into place.
3. To remove, pull the brush head straight up from the handle.



Image: Detailed view of the two types of brush heads included: Precise Standard Cleaning and Deeper Cleaning and Whitening heads.

OPERATING INSTRUCTIONS

1. Brushing Your Teeth

1. Wet the brush head and apply a small amount of toothpaste.
2. Place the brush head against your teeth at a slight angle towards the gumline.

3. Press the power button to turn on the toothbrush. It will start in the last used mode.
4. Gently guide the brush head slowly from tooth to tooth, allowing the rotating bristles to clean each surface. Do not scrub.
5. The toothbrush will pause briefly every 30 seconds to indicate it's time to move to the next quadrant of your mouth.
6. After 2 minutes, the toothbrush will automatically turn off, signaling the completion of the recommended brushing time.
7. Press the power button again to turn off the toothbrush manually at any time.



Image: Visual guide to the smart timer, showing how to divide brushing into four 30-second quadrants for a total of 2 minutes.

2. Changing Cleaning Modes

The toothbrush features 4 distinct cleaning modes:

- **White:** Stronger cleaning mode for removing plaque and dislodging tartar, aiding in teeth whitening.
- **Clean:** Standard daily cleaning mode for effective plaque removal and reducing oral bacteria.
- **Polish:** Designed to increase tooth gloss and help remove surface stains.
- **Massage:** Gentle mode to stimulate and massage gums, promoting gum health.

To switch between modes, press the mode button (usually the same as the power button, or a dedicated mode button if present) while the toothbrush is on. The indicator light for the selected mode will illuminate.



Image: The toothbrush handle displaying the four adjustable modes and their respective functions.

CLEANING AND MAINTENANCE

1. After Each Use

- Rinse the brush head thoroughly under running water while the toothbrush is still briefly on to remove any remaining toothpaste or debris.
- Turn off the toothbrush.
- Remove the brush head and rinse both the brush head and the metal shaft of the handle separately under running water.
- Wipe the handle dry with a soft cloth.
- Store the toothbrush and brush heads in a clean, dry place.

2. Replacing Brush Heads

For optimal cleaning performance and hygiene, replace your brush head every 3 months, or sooner if the bristles become frayed or worn. The package includes 8 brush heads (4 Precise Cleaning and 4 Whitening and Deeper Cleaning) for approximately 24 months of use.

Precise Cleaning & Whitening in One
TEETHEORY Toothbrush,
Create good oral hygiene!

8 Brush Heads
2 Type Brush Heads
4 Hours Charge = 25 Days Use
4 Modes

Image: Display of 8 brush heads, illustrating their longevity for up to 24 months of use.

BATTERY INFORMATION

- **Battery Type:** Rechargeable (Non-standard battery type)
- **Capacity:** 1200mAh
- **Charging Time:** Approximately 4 hours for a full charge.
- **Operating Time:** Up to 25 days of regular use on a single full charge.
- **Charging Method:** USB cable.

To preserve battery life, avoid fully discharging the battery frequently. Recharge when the battery indicator shows low power.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Toothbrush does not turn on.	Battery is depleted.	Charge the toothbrush for at least 4 hours.
Brush head rotation stops or slows down under light pressure.	Excessive pressure applied during brushing.	Reduce pressure. The toothbrush is designed to clean effectively with minimal pressure. If the issue persists, the brush head may be worn or incorrectly attached. Replace the brush head or reattach it firmly.
Toothbrush turns on by itself after being turned off.	Internal malfunction.	Contact customer support for assistance.
Charging indicator not working.	Cable or power source issue; toothbrush already fully charged.	Check USB cable connection and power source. If fully charged, the light may turn off. If not, contact support.

SPECIFICATIONS

Feature	Detail
Model	199AB
Brand	TEETHEORY
Dimensions	23.3 x 10.9 x 3.9 cm
Weight	240 grams
Age Range	Adults
Power Source	Battery Powered (Rechargeable)
Battery Capacity	1200mAh
Charging Time	Approx. 4 hours
Operating Time	Up to 25 days
Waterproof Rating	IP67
Bristle Texture	Extra soft
Brush Head Shape	Round/Rotary
Number of Brush Heads Included	8 (4 Precise Cleaning, 4 Whitening)

WARRANTY AND SUPPORT

TEETHEORY is committed to providing quality products. If you encounter any issues with your electric toothbrush, please do not hesitate to contact us.

For support, please log in to your Amazon account, navigate to "Your Orders," find your order ID, and click "Contact Seller." Our customer service team will assist you promptly.



© 2026 TEETHEORY. All rights reserved.