

[Manuals.plus](#) /

› [PSIDE](#) /

› PSIDE Silvercrest Kitchen Tools Monsieur Cuisine Connect SKMC 1100 A1 Food Processor User Manual

PSIDE SILVERCREST® SKMC 1100 A1

PSIDE Silvercrest Kitchen Tools Monsieur Cuisine Connect SKMC 1100 A1 User Manual

Your comprehensive guide to operating and maintaining your multi-functional food processor.



The PSIDE Silvercrest Monsieur Cuisine Connect food processor, ready for use in a modern kitchen setting.

1. SETUP

1.1 Unpacking and Initial Inspection

Carefully remove all components from the packaging. Inspect for any damage. Keep packaging materials for future transport or storage.

1.2 Included Components

- Main unit with 7-inch touchscreen
- 3-liter stainless steel mixing bowl
- Mixing blade
- Steamer attachment (two parts)
- Steamer basket
- Lid for mixing bowl
- Other standard accessories (e.g., spatula, whisk)



An exploded view illustrating the various components of the food processor, including the main unit, mixing bowl, and steamer attachments.

1.3 Assembly

1. Place the main unit on a stable, flat surface. Ensure the 4 suction cup feet are securely attached to prevent movement.
2. Insert the mixing blade into the bottom of the mixing bowl.

3. Place the mixing bowl into the designated slot on the main unit, ensuring it clicks into place.
4. Attach the lid securely to the mixing bowl.
5. For steaming, assemble the steamer attachment and basket on top of the mixing bowl lid as required by your recipe.

2. OPERATING INSTRUCTIONS

2.1 Control Panel Overview

The Monsieur Cuisine Connect features an intuitive 7-inch touchscreen display and a central rotary dial for easy navigation and control.



The clear 7-inch touchscreen provides access to all functions and recipes.

2.2 Basic Functions

The appliance offers 11 versatile functions:

- **Cooking:** Prepare various dishes directly in the mixing bowl.
- **Frying:** Sauté ingredients with precision.
- **Kneading:** Powerful 1050W motor for heavy doughs like bread or pizza.
- **Mixing:** Combine ingredients thoroughly.
- **Stirring:** Gentle stirring for soups and stews.
- **Chopping:** Finely chop vegetables, herbs, or nuts.

- **Pureeing:** Create smooth purees and baby food.
- **Emulsifying:** Prepare sauces and dressings.
- **Ice Crushing:** Efficiently crush ice for beverages.
- **Weighing:** Integrated kitchen scale for direct weighing up to 5 kg.
- **Steaming:** Use the included steamer attachment for healthy cooking.

2.3 Automatic Programs

The Monsieur Cuisine Connect includes 3 automatic cooking programs for convenience. Select a program from the touchscreen, and the appliance will guide you through the process.

2.4 Speed and Temperature Control

- **Speed:** Adjust the mixing speed in 10 levels. A turbo function is available for particularly powerful mixing.
- **Temperature:** Set the cooking temperature from 37°C to 130°C in 5°C increments for precise cooking.
- **Timer:** The integrated timer can be set for up to 99 minutes.

2.5 Wi-Fi and App Connectivity

Connect your appliance to Wi-Fi to access the free Monsieur Cuisine app. The app provides approximately 200 free recipes and regular updates. Utilize the integrated Cooking Pilot feature on the large screen to follow step-by-step instructions for various dishes.

2.6 Reverse Rotation

The appliance features a reverse rotation function (counter-clockwise movement). This is ideal for kneading dough or gently stirring soups and stews without crushing the ingredients.

3. MAINTENANCE AND CLEANING

3.1 Cleaning the Appliance

- Always unplug the appliance before cleaning.
- Wipe the main unit with a damp cloth. Do not immerse the main unit in water.
- Ensure no liquids enter the internal components.

3.2 Dishwasher Safe Components

All supplied accessories, including the mixing bowl, mixing blade, steamer attachment, and steamer basket, are dishwasher safe for easy cleaning.



The durable stainless steel mixing bowl is designed for easy cleaning.

4. TROUBLESHOOTING

Refer to the table below for common issues and their potential solutions.

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet issue; main switch off.	Ensure power cord is securely plugged in. Check power outlet with another device. Turn on main power switch.
Mixing bowl not recognized.	Mixing bowl not correctly seated.	Remove and re-insert the mixing bowl, ensuring it clicks securely into place.
Error message on screen.	Specific operational error.	Note the error code/message and consult the detailed troubleshooting section in the full digital manual via the app or manufacturer's website.

Problem	Possible Cause	Solution
Wi-Fi connection issues.	Incorrect password; weak signal; router issue.	Verify Wi-Fi password. Move appliance closer to router. Restart router.

5. TECHNICAL SPECIFICATIONS

Feature	Specification
Brand	PSIDE
Model Number	SILVERCREST® SKMC 1100 A1
Dimensions (L x W x H)	49.5 x 31 x 37.5 cm
Power	1100 Watts
Voltage	230 Volts (AC)
Material	Stainless steel
Number of Speeds	10
Mixing Bowl Volume	3 Liters
Integrated Scale Capacity	Up to 5 kg
Temperature Range	37°C to 130°C (in 5°C increments)
Timer	Up to 99 minutes
Special Features	Adjustable speed, Wi-Fi function with free app, 3 automatic cooking programs, integrated kitchen scale, reverse and right rotation, precise temperature control.

6. WARRANTY INFORMATION

Specific warranty details for the PSIDE Silvercrest Kitchen Tools Monsieur Cuisine Connect SKMC 1100 A1 are not provided in this manual. Please refer to the warranty card included with your purchase or contact the retailer/manufacturer directly for information regarding warranty coverage and terms.

7. SUPPORT

For further assistance, technical support, or to inquire about spare parts, please:

- Visit the official Silvercrest or PSIDE website for FAQs and support resources.
- Contact the customer service department of your retailer.
- Check the Monsieur Cuisine Connect app for additional guides and community support.