

TEGERDEGER 022

TegerDeger 12FT 2-Person Hammock Instruction Manual

Model: 022 | Brand: TEGERDEGER

INTRODUCTION

This manual provides essential instructions for the safe and proper assembly, operation, and maintenance of your TegerDeger 12FT 2-Person Hammock. Please read this manual thoroughly before use and retain it for future reference.

SAFETY INFORMATION

WARNING: Failure to follow these safety guidelines may result in serious injury or property damage.

- Maximum weight capacity is 450 lbs. Do not exceed this limit.
- Securely anchor the hammock to stable supports.
- Do not use the hammock without the spreader bars properly installed.
- Keep children away from the hammock unless supervised by an adult.
- Always inspect the hammock and all hardware (ropes, chains, spreader bars) before each use for any signs of wear or damage.
- Ensure anchors are level, stable, and sturdy.
- Do not use the hammock if any part is damaged.

PRODUCT FEATURES

- **Anti-flip Over Design:** Features a "V" curved hardwood spreader bar designed to concentrate the center of gravity, reducing the risk of flipping. Reinforced bolts and nuts secure the V-shape for enhanced safety.
- **Advanced Hardwood Spreader Bar:** Made from durable hardwood with a dark reddish-brown color and distinct grain patterns, ensuring long service life.
- **Strong & Durable Nylon Rope:** Constructed from 100% nylon, offering excellent abrasion resistance and weather-resistant properties for outdoor use.
- **Premium Weather-Resistant Polyester Fabric:** Two-layer quilted fabric, filled with soft padding,

provides comfort and durability.



2 Person Hammock
450 LB Capacity

100% Nylon Durable Rope
Wear-resistant, Long service time in outdoor

Premium Hardwood
Spreader Bar

Convenient Side
Pocket

Image: Detailed view of the two-layer quilted polyester fabric, highlighting its soft padding.

- **Super Large Hammock:** Measures 55 inches wide by 79 inches long, comfortably accommodating two people with a maximum capacity of 450 lbs.
- **Detachable Side Pocket:** Includes a convenient side pocket for storing items like phones, books, or cups.
- **Extended Pillow:** The pillow is lengthened to 35.4 inches, suitable for two people.

SETUP INSTRUCTIONS

This hammock is designed for use with a 12ft hammock stand (not included) or suitable sturdy anchor points. Ensure all components are present and undamaged before beginning assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify you have the hammock fabric, spreader bars, ropes, and any included hardware (bolts, nuts, chains).
2. **Assemble Spreader Bars:** Attach the V-shaped hardwood spreader bars to the ends of the hammock fabric using the provided reinforced bolts and nuts. Ensure they are securely fastened.



Image: Close-up of the V-shaped hardwood spreader bar, showing its angled design for stability.

- 3. Attach Nylon Ropes:** Connect the durable nylon ropes to the spreader bars and then to the hanging chains or anchor points. Ensure the ropes are evenly distributed and securely tied or clipped.



Comfortable




Breathable

A Perfect Place to Relax

Image: A person relaxing in the TegerDeger hammock, showcasing the full setup with ropes and spreader bars.

- 4. Hang Hammock:** If using a hammock stand, ensure it is stable and rated for the hammock's length and weight capacity. Attach the hammock chains to the stand's hooks. If hanging between trees or posts, use appropriate heavy-duty straps or hardware (not included) and ensure the anchor points are strong enough to support the maximum weight.

Product Dimension Suitable for 1-2 Person Use



Notice: 12ft hammock only fit for 12ft or smaller hammock stand

Image: Product dimension diagram, indicating the 12ft length and 55-inch width, suitable for 1-2 person use.

5. **Attach Pillow and Side Pocket:** Secure the detachable pillow to the hammock as desired. Attach the side pocket to the edge of the hammock for convenient storage.

**Two layers advanced polyester fabric,
filled with soft padding.**



Image: Detailed view of the convenient side pocket, designed to hold books, cups, or other small items.

6. **Final Check:** Before first use, gently test the hammock's stability and ensure all connections are secure.

OPERATING INSTRUCTIONS

1. **Entering the Hammock:** Approach the hammock carefully. Sit down slowly in the center, distributing your weight evenly. For two people, both individuals should enter and exit cautiously to maintain balance.
2. **Relaxing:** Once seated, gently recline. The V-shaped spreader bar is designed to provide stability and prevent tipping. Adjust the detachable pillow for optimal comfort.
3. **Using the Side Pocket:** Place personal items such as books, magazines, or beverages in the detachable side pocket for easy access.
4. **Exiting the Hammock:** Slowly sit upright, then carefully swing your legs to the side and stand up, maintaining balance.

Your browser does not support the video tag.

Video: Demonstrates the TegerDeger Strip Fabric Hammock in use, highlighting its features and comfort.

Your browser does not support the video tag.

Video: Showcases individuals enjoying the TegerDeger hammock, emphasizing its relaxing qualities and design.

MAINTENANCE

- **Cleaning Fabric:** The weather-resistant polyester fabric can be spot cleaned with mild soap and water. For deeper cleaning, the fabric may be hand-washed. Allow to air dry completely.
- **Hardwood Care:** Periodically inspect the hardwood spreader bars for any signs of wear or damage. To maintain the wood's finish and prolong its life, you may apply a wood sealant or oil as needed, especially if exposed to harsh weather conditions.
- **Rope Inspection:** Regularly check the nylon ropes for fraying, cuts, or excessive wear. Replace ropes if any damage is observed.
- **Storage:** During prolonged periods of non-use or inclement weather, it is recommended to remove the hammock and store it in a dry, protected area to extend its lifespan.

TROUBLESHOOTING

- **Hammock feels unstable:** Ensure the spreader bars are correctly installed and all ropes/chains are securely attached to stable anchor points. Verify the hammock stand (if used) is on a level surface.
- **Fabric appears dirty:** Refer to the "Cleaning Fabric" section under Maintenance for instructions on spot cleaning or hand washing.
- **Ropes show wear:** Inspect ropes for damage. If significantly worn or frayed, replace them immediately for safety.

SPECIFICATIONS

Feature	Detail
Brand	TEGERDEGER
Model Number	022
Material	Polyester
Color	Fall Yellow Stripes
Product Dimensions (L x W)	126"L x 55"W (12FT x 55in)
Maximum Weight Recommendation	450 Pounds
Seating Capacity	2
Item Weight	13 Pounds

WARRANTY & SUPPORT

For warranty information, product support, or to purchase replacement parts, please contact TEGERDEGER customer service through the retailer where the product was purchased or visit the official TEGERDEGER store online.

Official TEGERDEGER Store: [TegerDeger Store on Amazon](#)