

[manuals.plus](#) /

› [4smarts](#) /

› [4smarts Mini Portable USB-C Charger \(Model E08\) - 4500mAh User Manual](#)

## 4smarts E08

# 4smarts Mini Portable USB-C Charger (Model E08) - 4500mAh User Manual

Brand: 4smarts | Model: E08

## 1. INTRODUCTION

---

Thank you for choosing the 4smarts Mini Portable USB-C Charger. This compact and stylish power bank is designed to provide convenient on-the-go charging for your USB-C compatible devices. Please read this manual carefully to ensure proper use and optimal performance.



Figure 1: The 4smarts Mini Portable USB-C Charger connected to a smartphone, illustrating its direct plug-in functionality.

The 4smarts Mini Portable USB-C Charger features a built-in USB-C connector for direct plug-in charging, eliminating the need for extra cables. Its 4500mAh capacity provides reliable backup power, and its compact, lipstick-sized design makes it easy to carry.

## 2. PACKAGE CONTENTS

Upon unboxing your 4smarts Mini Portable USB-C Charger, please ensure all the following items are present:

- 1 x 4smarts Mini Portable USB-C Charger (Model E08)
- 1 x USB-C to USB-C Charging Cable
- 1 x Soft Pouch
- 1 x User Manual (this document)




Figure 2: Included items in the 4smarts Mini Portable USB-C Charger package.

### 3. SETUP AND INITIAL USE

---

#### 3.1 Charging the Power Bank

Before first use, fully charge your 4smarts Mini Portable USB-C Charger. Use the provided USB-C to USB-C cable and connect it to a compatible USB-C power adapter (not included). The four LED indicators on the side will show the charging progress and current battery level.

# Pass-Through Technology

Charge your phone while recharging power bank



Figure 3: Recharging the power bank using a USB-C cable and a wall adapter.

## 3.2 Checking Battery Level

The power bank features four LED indicators to display its remaining charge:

- **4 LEDs:** 75-100% charged
- **3 LEDs:** 50-75% charged
- **2 LEDs:** 25-50% charged
- **1 LED:** 0-25% charged (recharge soon)

## 4. OPERATING INSTRUCTIONS

### 4.1 Charging Your Device (Direct Plug-in)

1. Remove the protective cap from the built-in USB-C connector.
2. Align the USB-C connector with your device's charging port and firmly plug it in.
3. The power bank will automatically begin charging your device. The LED indicators will show the power bank's remaining charge.



Figure 4: Direct plug-in charging of a smartphone using the built-in USB-C connector.

## 4.2 Charging a Second Device (Two-Way Convenience)

While your primary device is charging via the built-in connector, you can also charge a second device. Connect the provided USB-C to USB-C cable to the USB-C input port on the power bank and to your second device. This allows for simultaneous charging.

## 4.3 Compatibility

This power bank is designed for USB-C compatible devices, including:

- iPhone 16/16 Pro/16 Pro Max/16 Plus
- iPhone 15 series
- Samsung Galaxy S24/S23/S22/S21/S20, Z Flip/Ultra
- Google Pixel 8/7/6
- Other USB-C Android smartphones

**Note:** This device is not compatible with iPhones that use Lightning ports.

## What's in the Box ?

- 1 \* Cordless Portable Charger
- 1 \* USB C to USB C cable
- 1 \* Delicate Storage Bag
- 1 \* Welcome Guide



Figure 5: Device compatibility overview for the 4smarts Mini Portable USB-C Charger.

### 4.4 Fitting with Phone Cases

The design of the built-in USB-C connector allows for charging even when your phone has a protective case, ensuring a secure connection without needing to remove the case.

### Perfectly Fit for Your Case

Support your phone case keep on while charging



Figure 6: The charger is designed to fit with most phone cases.

## 5. MAINTENANCE AND SAFETY

### 5.1 Cleaning

Wipe the power bank with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.

### 5.2 Storage

Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures. Use the provided soft pouch to protect it from scratches.

# Nice Backup, When Out and About!



Figure 7: The compact charger fits easily into a handbag for convenient storage.

## 5.3 Safety Precautions

- Do not expose the power bank to water or moisture.
- Avoid dropping or subjecting the device to strong impacts.
- Do not disassemble, modify, or attempt to repair the power bank.
- Keep out of reach of children.
- Do not use if the device is damaged or shows signs of overheating.

## 6. TROUBLESHOOTING

If you encounter any issues with your 4smarts Mini Portable USB-C Charger, please refer to the following common solutions:

Problem	Solution
Device not charging	Ensure the power bank is charged. Check the connection between the power bank and your device. Try a different USB-C cable if using the two-way charging feature.

Problem	Solution
Slow charging	Ensure your device and the power bank are properly connected. Verify that the power bank itself is fully charged.
LED indicators not working	Press the power button to activate the indicators. If they still do not light up, the power bank may be fully depleted or require service.

## 7. SPECIFICATIONS

---

- **Model Number:** E08
- **Battery Capacity:** 4500 Milliamp Hours (mAh)
- **Product Dimensions:** 3.15 x 1.9 x 1.17 inches
- **Item Weight:** 3.52 ounces
- **Connector Type:** USB Type C (built-in)
- **Input/Output:** USB-C
- **Special Features:** Lightweight, Pocket Size, Slim, Super Mini, Ultra Compact
- **Manufacturer:** Jiangsu Cooostar Technology Co.,Ltd
- **Date First Available:** June 4, 2024

## 8. WARRANTY AND SUPPORT

---

4smarts is committed to delivering innovative, quality electronic accessories. For warranty information or technical support, please refer to the contact details provided in the original product packaging or visit the official 4smarts website. You can also reach out to customer service via the following:

- **Support Email:** [support@iwalkworld.com](mailto:support@iwalkworld.com)
- **Service Phone (US):** 1-888-801-8888 (M-F 9:00-17:00 PST)
- **Service Phone (UK):** +44-808-175-0000 (M-F 9:00-17:00 GMT)