

Claiks P1.01.001.0004.JP

Claiks Electric Standing Desk Instruction Manual

Model: P1.01.001.0004.JP

1. INTRODUCTION

Thank you for purchasing the Claiks Electric Standing Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions carefully before use and retain them for future reference.



Image 1.1: The Claiks Electric Standing Desk, illustrating its dimensions (120cm width, 60cm depth, 72-118cm height) and integrated features like storage hooks and cable clips.

2. SAFETY INFORMATION

To ensure safe operation and prevent injury or damage, please observe the following safety guidelines:

- Keep children and pets away from the desk during height adjustment.
- Ensure no obstacles are in the path of the desk's movement (up or down).
- Do not overload the desk. The maximum load capacity is 80 kg (176.4 lbs).
- Do not sit or stand on the desk.
- Only use the provided power adapter and cable.
- If the desk makes unusual noises or movements, discontinue use immediately and contact customer support.
- Avoid placing liquids directly on the control panel or near electrical components.

3. PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact Claiks customer support.



Image 3.1: All components included in the Claiks Electric Standing Desk package, laid out for assembly. This includes the tabletop (in two sections), leg frames, motor, control panel, screws, and tools.

List of Components:

- Tabletop (2 sections)
- Leg Frames (2)

- Crossbar/Support Beam
- Motor and Control Box
- Control Panel
- Power Adapter and Cable
- Storage Hooks (2)
- Cable Clips
- Assembly Hardware (screws, washers, Allen wrench)

4. SETUP AND ASSEMBLY

Assembly typically requires one person. An electric drill (not included) is recommended for faster and more secure screw fastening, especially for the tabletop.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Leg Frames:** Attach the feet to the bottom of each leg column using the provided screws.
3. **Connect Crossbar:** Secure the crossbar/support beam between the two leg columns. Ensure all screws are tightened.
4. **Attach Motor and Control Box:** Mount the motor and control box to the designated positions on the frame, typically under the tabletop area. Connect the motor cables to the control box.
5. **Position Tabletop:** Place the tabletop sections upside down on a soft surface. Carefully align the assembled frame onto the tabletop.
6. **Secure Tabletop:** Fasten the tabletop to the frame using the provided screws. Ensure the tabletop sections are flush and securely joined.
7. **Install Control Panel:** Mount the control panel to the front edge of the tabletop, typically on the right side, and connect its cable to the control box.
8. **Attach Accessories:** Install the storage hooks and cable clips as desired.
9. **Connect Power:** Plug the power adapter into the control box and then into a wall outlet.
10. **Initial Calibration (if necessary):** Refer to the operating instructions for initial setup or calibration steps if the desk does not respond immediately.

5. OPERATING INSTRUCTIONS

Your Claiks Electric Standing Desk features intuitive controls for height adjustment and memory functions.



Image 5.1: The multi-function control panel with LED display, memory buttons (1, 2, 3), and up/down adjustment buttons.

5.1 Height Adjustment

- **Up/Down Buttons:** Use the **Up (▲)** and **Down (▼)** arrow buttons to adjust the desk height. The desk will move smoothly at a speed of 20 mm/s.
- The adjustable height range is from 72 cm (28.3 inches) to 118 cm (46.5 inches).
- The current height is displayed on the LED screen.



Image 5.2: Two Claiks Electric Standing Desks demonstrating the adjustable height range, suitable for various uses.

5.2 Memory Function

The desk can store up to three preferred height settings.

1. **Set a Memory Position:** Adjust the desk to your desired height using the Up/Down buttons.
2. Press the "**M**" button. The LED display will flash.
3. Within 3 seconds, press one of the number buttons ("**1**", "**2**", or "**3**") to save the current height to that position. The display will show "S-1", "S-2", or "S-3" to confirm.
4. **Recall a Memory Position:** Simply press the corresponding number button ("**1**", "**2**", or "**3**"). The desk will automatically move to the saved height.

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Claiks Electric Standing Desk.

- **Cleaning:** The tabletop is made of melamine resin, which is resistant to water, heat, and dirt. Wipe the surface with a soft, damp cloth and mild detergent. Avoid abrasive cleaners or harsh chemicals.
- **Cable Management:** Regularly check and organize cables to prevent tangling or damage, especially during height adjustments. Use the provided cable clips.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Retighten if necessary.
- **Motor Care:** The motor is designed for durability. Avoid obstructing its movement or attempting to disassemble it.

7. TROUBLESHOOTING

If you encounter issues with your desk, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Desk does not move.	Power cable disconnected; Overload; Motor error.	Check power connections. Reduce weight on desk. Unplug for 10 seconds, then plug back in to reset.
Desk moves unevenly or makes unusual noise.	Loose connections; Obstruction; Uneven weight distribution.	Check all assembly screws. Ensure no objects are interfering with leg movement. Redistribute weight evenly.
Error code displayed on control panel.	Specific system error.	Refer to the specific error code in a more detailed troubleshooting guide (if available) or contact customer support. Often, a power cycle (unplug and replug) can resolve temporary errors.

If the problem persists after attempting these solutions, please contact Claiks customer support for assistance.

8. SPECIFICATIONS

- **Brand:** Claiks
- **Model Number:** P1.01.001.0004.JP
- **Product Dimensions:** 120 cm (Width) x 60 cm (Depth) x 70 cm (Height, minimum static)
- **Adjustable Height Range:** 72 cm - 118 cm (28.3 inches - 46.5 inches)
- **Lifting Speed:** 20 mm/s (0.8 inches/s)
- **Maximum Load Capacity:** 80 kg (176.4 lbs)
- **Item Weight:** 20.8 kg
- **Tabletop Material:** Melamine Resin
- **Base Material:** Carbon Steel
- **Color:** Black
- **Special Features:** Height Adjustment, Memory Function (3 presets), Compact, Scratch Resistant
- **Room Type:** Study Room, Home Office



Image 8.1: The Claiks Electric Standing Desk demonstrating its robust 80kg load capacity.



Image 8.2: Illustration of the desk's quiet operation, comparing its 45dB noise level to common sounds.

9. WARRANTY AND SUPPORT

Claiks provides a **3-year manufacturer warranty** for this product. This warranty covers repairs or exchanges for manufacturing defects during the warranty period.

For customer support, repairs, or exchanges, please contact Claiks directly. Our customer support team is available in multiple languages, including English and Japanese, to assist you with any inquiries or issues.

Please retain your proof of purchase for warranty claims.