



B0CPXK18X2

Generic 80-inch Convertible Sectional Sofa Couch User Manual

Model: B0CPXK18X2

1. INTRODUCTION

Thank you for purchasing the Generic 80-inch Convertible Sectional Sofa Couch. This manual provides essential information for the safe assembly, proper use, and effective maintenance of your new furniture. Please read these instructions carefully before assembly and retain them for future reference.

2. PRODUCT OVERVIEW

The Generic 80-inch Convertible Sectional Sofa Couch is designed for comfort and versatility. It features a convertible L-shape design, allowing for flexible arrangement in various living spaces. The sofa includes removable cushions for easy cleaning and a convenient side pocket for storage.



Image 2.1: Overall view of the Convertible Sectional Sofa Couch with chaise and side pocket.

Key Features:

- **Convertible Design:** Allows for flexible L-shape configuration.
- **Removable Cushions:** Seat and back cushions can be removed for cleaning and adjustment.
- **Integrated Side Pocket:** Provides convenient storage for small items.
- **Durable Construction:** Built with sturdy materials and rubber wood legs for stability.
- **Chenille Fabric:** Soft and comfortable upholstery.

3. COMPONENTS LIST

Before assembly, please ensure all components are present and undamaged. If any parts are missing or damaged, contact customer support.

- Sofa Base Sections (2-3 pieces, depending on configuration)
- Chaise/Ottoman Section (1 piece)
- Back Cushions (3 pieces)
- Seat Cushions (3 pieces)
- Rubber Wood Legs (Set of 8-10, depending on configuration)
- Assembly Hardware (Bolts, washers, Allen wrench)

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is required for this product. It is recommended to have two people for assembly. Ensure you have enough space and a soft, clean surface to prevent damage during assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to identify each component and ensure nothing is missing.
2. **Attach Legs:** For each sofa base section and the chaise/ottoman section, locate the pre-drilled holes on the underside. Attach the rubber wood legs using the provided bolts and Allen wrench. Ensure all legs are securely tightened.
3. **Connect Sofa Sections:** Align the metal brackets on the sides of the sofa base sections. Slide the sections together until they lock securely. Depending on your desired configuration, you may connect two or three main sections.
4. **Position Chaise/Ottoman:** Place the chaise/ottoman section next to either end of the main sofa sections to form the L-shape. The chaise is designed to be movable, allowing you to switch its position.
5. **Place Cushions:** Position the seat cushions onto the sofa base and the back cushions against the backrest. Adjust as needed for comfort.



Image 4.1: Illustration of sofa sections connecting at the rear.



Image 4.2: The sofa with the ottoman separated, highlighting its convertible nature.

5. OPERATING INSTRUCTIONS

5.1 Converting the L-Shape Configuration

The chaise section of your sofa is designed to be movable, allowing you to easily change the L-shape orientation to suit your room layout or preference.

- To change the L-shape, simply lift and move the chaise section to the desired end of the main sofa.
- Ensure the chaise is placed flush against the main sofa for stability and a seamless appearance.



Image 5.1: Sofa configured with the chaise on the right.



Image 5.2: Sofa configured with the chaise on the left.

5.2 Utilizing the Side Pocket

A fabric pocket is integrated into the side of one of the sofa arms. This pocket is suitable for storing remote controls, magazines, or other small items.

5.3 Removable Cushions

The seat and back cushions are removable. This allows for easy adjustment, rotation, and cleaning.

6. MAINTENANCE AND CARE

6.1 Chenille Fabric Care

- **Regular Cleaning:** Vacuum the sofa regularly using an upholstery attachment to remove dust and loose debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. Do not rub, as this can spread the stain. For stubborn stains, use a mild fabric cleaner specifically designed for chenille, testing on an inconspicuous area first.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading. Position your sofa away

from direct sunlight or use curtains/blinds.

- **Professional Cleaning:** For deep cleaning, consider professional upholstery cleaning services.

6.2 Rubber Wood Legs Care

- Wipe wooden legs with a soft, damp cloth. Avoid harsh chemicals.
- Check leg tightness periodically and re-tighten if necessary.

6.3 Cushion Care

- Rotate and fluff cushions regularly to maintain their shape and extend their lifespan.

7. TROUBLESHOOTING

- **Sofa feels wobbly:** Check that all legs are securely tightened. Ensure sofa sections are properly interlocked.
- **Cushions appear flat:** Fluff and rotate cushions regularly. Over time, some compression is normal.
- **Fabric pilling:** This can occur with chenille. Use a fabric shaver to gently remove pills.
- **Stains:** Refer to the spot cleaning instructions in the Maintenance section. Act quickly on spills.

8. SPECIFICATIONS

Feature	Detail
Brand	Generic
Model Number	B0CPXK18X2
Assembly Required	Yes
Product Dimensions (D x W x H)	74"D x 69"W x 51"H
Seat Depth	20.5 inches
Seat Height	17.3 inches
Type	Sofa Chaise
Color	Light Grey
Special Feature	Space Saving, Convertible
Room Type	Living Room
Arm Style	Track
Material Type	Chenille
Seating Capacity	4.00

9. WARRANTY AND SUPPORT

This product is manufactured by SeeTruth. For any questions, concerns, or support needs regarding your sofa, please contact the seller or manufacturer directly.

Please note that specific warranty details are not provided in this manual. It is recommended to refer to your purchase documentation or contact the seller for warranty information.

Returns are generally accepted within a specified period from the purchase date. Please check your purchase details for the exact return policy applicable to your order.