HOTO QWQJS001-GRAY

HOTO Electric Spin Scrubber

INSTRUCTION MANUAL

Introduction

The HOTO Electric Spin Scrubber is designed to simplify your cleaning tasks with powerful performance and versatile functionality. Its robust motor and intelligent design make it an essential tool for maintaining a spotless home, from bathrooms and kitchens to floors and tiles. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and longevity of your device.

What's in the Box

Carefully unpack all components and ensure you have the following items:

- 1 x HOTO Electric Spin Scrubber (Main Unit)
- 1 x Removable Extension Pole
- 1 x Flat Brush
- 1 x Small Flat Brush
- 1 x Pointed Brush
- 1 x Velcro Adapter for Pads
- 1 x Sponge Pad
- 1 x Scour Pad
- 1 x Cloth Pad
- 1 x Storage Bag
- 1 x Type-C Charging Cable



Figure 1: Overview of the HOTO Electric Spin Scrubber and its included accessories.

Product Features

Powerful Cleaning Performance

The HOTO Electric Spin Scrubber is equipped with a robust motor providing a strong cleaning torque of 2.5 N·m. This ensures substantial power for thorough cleaning without risking damage to surfaces. It operates at two adjustable speeds: a Soft & Slow option at 220 r/min for daily cleaning and a Strong & Fast option at 300 r/min for deep cleaning.




Figure 2: The powerful spin motor provides efficient cleaning.

Full Body Waterproof Design

With an IPX7 waterproof rating, the HOTO cordless shower scrubber is safe for use even when fully immersed in sinks or bathtubs. This feature ensures durability and reliability in wet cleaning environments.



Figure 3: The IPX7 waterproof design allows for safe use in wet conditions.

Versatile Brush Heads and Easy-Buckle Design

The scrubber includes six durable and high-quality brush heads designed for various surfaces and cleaning needs. The easy-buckle design allows for quick and secure replacement of brush heads, preventing detachment during use.

- **Dome Brush:** Ideal for bathtubs and curved surfaces.

- **Flat Brush & Small Flat Brush:** Suitable for large flat surfaces like floors, walls, and tiles.
- **Pointed Brush:** Excellent for cleaning grout lines, corners, and hard-to-reach crevices.
- **Sponge Pad, Scour Pad, Cloth Pad:** Used with the Velcro Adapter for polishing, scrubbing, and gentle cleaning on various surfaces.




Figure 4: Different brush heads for various cleaning applications.



Figure 5: Specialized pads for polishing and gentle cleaning.



Figure 6: The easy-buckle design allows for quick and secure brush head replacement.

Extendable Handle for Ergonomic Cleaning

The telescoping extension pole adjusts from 37 to 51 inches, allowing you to reach high and low areas without bending or

kneeling. This ergonomic design reduces strain and makes cleaning more comfortable and efficient.




Figure 7: The extendable handle provides comfortable reach for various cleaning heights.

Setup

Charging the Scrubber

Before first use, fully charge the HOTO Electric Spin Scrubber. It features a built-in 4000 mAh lithium battery that provides

90-110 minutes of usage on a full charge. Use the included Type-C charging cable to connect the scrubber to a power source.

Attaching Brush Heads and Extension Pole

1. **Attach Brush Head:** Match the socket and connector to attach the desired brush head. Press the unlock buttons on the side of the main unit to release or secure the brush head.
2. **Attach Extension Pole:** Align the socket of the extension rod with the spin scrubber. Insert and rotate clockwise to lock it securely.
3. **Adjust Pole Length:** To adjust the rod length, turn the rear handle counter-clockwise, pull to the desired length, then turn it clockwise to lock.



Figure 8: Step-by-step guide for setting up the scrubber.

Operating Instructions

Powering On and Speed Selection

Long-press the power switch on the main unit to turn on the device. Press the mode switch to change between the two available speeds (220 r/min and 300 r/min) based on your cleaning needs.

Using Different Brush Heads

Select the appropriate brush head for the surface you are cleaning. For example, use the dome brush for bathtubs, flat brushes for large surfaces, and the pointed brush for corners and grout. Always ensure the brush head is securely attached before operation.

Wet Cleaning and Immersion

Thanks to its IPX7 waterproof rating, the scrubber can be safely used in wet environments and even fully immersed in water for up to 30 minutes. This makes it ideal for cleaning sinks, bathtubs, and other areas requiring water and cleaning solutions.

Maintenance

Cleaning the Scrubber and Accessories

After each use, detach the brush head and rinse it thoroughly with water to remove any debris or cleaning solution residue. Wipe down the main unit and extension pole with a damp cloth. Ensure all parts are dry before storing.

Charging and Storage

Recharge the battery as needed. Store the scrubber and its accessories in the provided storage bag in a cool, dry place away from direct sunlight and extreme temperatures. This helps maintain battery health and product longevity.

Troubleshooting

Scrubber Stops During Use

If the scrubber stops unexpectedly during use, especially under pressure, it may be a safety feature to prevent motor overload. Reduce the applied force and ensure the battery is sufficiently charged. If the issue persists after charging, contact customer support.

Brush Head Detaches During Use

Ensure the brush head is properly attached using the easy-buckle design. Listen for a secure click when attaching. If it continues to detach, inspect the connection points for any damage or debris.

Specifications

Feature	Specification
Brand	HOTO
Model Number	QWQJS001-GRAY
Product Dimensions	6.69"L x 2.44"W x 28.74"H
Item Weight	1.76 pounds (0.8 Kilograms)
Material	Metal, Acrylonitrile Butadiene Styrene (ABS)
Waterproof Rating	IPX7 (Full Body Waterproof)
Torque	Max 2.5 N·m
RPM (Speeds)	220 r/min (Soft & Slow), 300 r/min (Strong & Fast)
Battery Capacity	4000 mAh (Approx. 90-110 min runtime)
Charging Type	Type-C
Extension Pole Length	Adjustable from 37-51 inches

Warranty and Support

Your HOTO Electric Spin Scrubber is Verified by Transparency, ensuring authenticity and quality. For any product-related inquiries, technical support, or warranty claims, please contact HOTO customer service through their official channels. Refer to the product packaging or official HOTO website for specific contact information and warranty details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question