

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [CHUWI](#) /
- > [CHUWI AuPad Android 14 Tablet User Manual](#)

CHUWI AuPad

CHUWI AuPad Android 14 Tablet User Manual

Model: AuPad x

1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your CHUWI AuPad Android 14 Tablet. Please read this guide thoroughly to ensure proper use and to maximize the performance of your device.

2. PRODUCT OVERVIEW

The CHUWI AuPad is a 10.95-inch tablet featuring the Android 14 operating system and powered by a Snapdragon 685 processor. It offers a 2K IPS display, 8GB RAM, 128GB internal storage (expandable up to 1TB via TF card), and a 7000mAh battery. The tablet supports 4G LTE cellular connectivity, dual-band Wi-Fi, Bluetooth 5.0, and GPS.



Image: The CHUWI AuPad tablet highlighting its 8GB LPDDR4 RAM, 128GB ROM, and 1TB TF card expansion capability, along with 4G LTE Dual SIM Dual Standby feature.

Your browser does not support the video tag.

Video: An overview of the CHUWI AuPad tablet's features, including its slim design, 10.95-inch display, Widevine L1 support, Snapdragon 685 processor, 7000mAh battery, cameras, and Android 14 operating system.

3. SETUP GUIDE

3.1 Initial Charging

Before first use, fully charge the tablet using the provided Type-C cable and an 18W PD fast charger. The 7000mAh battery provides extended usage time.



Image: The CHUWI AuPad tablet being charged via its Type-C port, illustrating the 7000mAh battery and 18W fast charging capability.

3.2 Inserting SIM and TF Cards

1. Locate the SIM/TF card tray on the side of the tablet.
2. Use the provided SIM ejector tool to open the tray.
3. Carefully place your 4G LTE Nano SIM card(s) and/or a TF (Micro SD) card (up to 1TB) into the designated slots.
4. Gently push the tray back into the tablet until it clicks into place.

3.3 Powering On and Initial Setup

1. Press and hold the power button until the CHUWI logo appears.
2. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google account.
3. Review and adjust privacy settings as guided by the Android 14 operating system.

3.4 Connecting the Detachable Magnetic Keyboard

If your package includes a detachable magnetic keyboard, align the magnetic connectors on the keyboard with those on the tablet. The keyboard will snap into place and connect automatically. No additional pairing is required.

4. OPERATING INSTRUCTIONS

4.1 Android 14 Features

The AuPad runs on Android 14, offering enhanced privacy controls, improved app permissions, and a more personalized user experience. Explore features like:

- **Enhanced Privacy:** Manage app access to your data and device features.
- **Personalized Interface:** Customize themes, widgets, and notifications.
- **Multi-Window Mode:** Use two apps simultaneously for improved multitasking.

Ample Storage for All Your Needs

Aupad effortlessly running more apps and switching different tasks. There is plenty of space for your files, photos, and videos. Add a Micro SD card up to 1TB card to save even more.

 **8GB LPDDR4**
RAM

 **128GB**
ROM

 **1TB**
Micro SD expansion



Image: The CHUWI AuPad tablet showcasing the new features of Android 14, including smoother system performance, personalization options, privacy and security enhancements, and parental control capabilities.

4.2 Display and Visual Experience

The 10.95-inch 2K (1920x1200) IPS display provides clear and vibrant visuals. It supports Google Widevine L1 certification for high-definition streaming from services like Netflix, YouTube, and Amazon Prime Video.

- **Split-Screen Mode:** Activate by swiping up from the bottom of the screen and holding, then dragging an app to one side.
- **Eye Protection Mode:** Access through Quick Settings or Display settings to reduce blue light emission.
- **3-Finger Screenshots:** Swipe down with three fingers on the screen to capture a screenshot.



Image: The CHUWI AuPad tablet's 10.95-inch 2K display, highlighting its 1920x1200 resolution, 16:10 aspect ratio, and Widevine L1 certification for high-quality streaming.

4.3 Camera Usage

The tablet is equipped with a 5MP front camera and a 13MP rear camera with a 0.3MP depth sensor and flashlight. To use the camera:

1. Open the Camera application from the home screen or app drawer.
2. Tap the shutter button to take photos or switch to video mode for recording.
3. Utilize the flashlight for low-light conditions.

Android 14--New features and humanized experience

More personalised settings, data encryption, user rights and notification management for better protection of your privacy.



Android 14
Made for you



Privacy and security
Authority management



Taskbar
Convenient multitasking



Managing permissions
controlling screen time



Image: The CHUWI AuPad tablet featuring its HD Triple Cameras, including a 13MP autofocus rear camera, 0.3MP depth camera, 5MP front camera, and a flashlight for low-light shooting.

4.4 Connectivity

The AuPad offers various connectivity options:

- **Wi-Fi:** Supports 2.4G and 5G dual-band Wi-Fi (802.11 ac) for stable and fast internet access.
- **Bluetooth 5.0:** For connecting wireless accessories like headphones or speakers.
- **4G LTE:** Dual SIM card slots allow for cellular data and calls on supported GSM carriers.
- **GPS:** Built-in support for GPS, GLONASS, BDS, and Galileo for accurate navigation.

5. MAINTENANCE

5.1 Cleaning the Device

To clean your tablet, use a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water or a screen cleaner designed for electronics. Avoid using harsh chemicals or abrasive materials.

5.2 Battery Care

To prolong battery life:

- Avoid exposing the tablet to extreme temperatures.
- Do not let the battery completely drain frequently.
- Use the original charger or a certified compatible charger.

5.3 Software Updates

Regularly check for and install system updates to ensure your tablet has the latest security patches and performance improvements. Navigate to **Settings > System > System update** to check for available updates.

6. TROUBLESHOOTING

6.1 Common Issues and Solutions

- **Tablet not powering on:** Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again.
- **Apps crashing or freezing:** Close background apps. Clear the cache of the problematic app (Settings > Apps

> [App Name] > Storage > Clear cache). If the issue persists, restart the tablet.

- **Wi-Fi connection issues:** Restart your Wi-Fi router and the tablet. Forget the network in tablet settings and reconnect.
- **Keyboard not responding:** Ensure the magnetic keyboard is securely attached. Detach and reattach it. Check tablet settings for external keyboard recognition if the issue persists.
- **Slow performance:** Close unnecessary apps. Clear storage space. Consider a factory reset as a last resort (backup data first).

7. SPECIFICATIONS

Feature	Specification
Model Name	AuPad x
Operating System	Android 14
Processor	Snapdragon 685, 2.8 GHz Octa-Core
Graphics Coprocessor	Adreno 610 @ 1.26GHz
RAM	8 GB LPDDR4
Internal Storage	128 GB SSD (UFS 2.2)
Expandable Storage	Up to 1 TB via TF Card (not included)
Screen Size	10.95 Inches
Screen Resolution	1920 x 1200 (2K) IPS
Widevine Certification	L1
Rear Camera	13 MP (Autofocus) + 0.3 MP (Depth) with Flashlight
Front Camera	5 MP
Battery Capacity	7000 mAh
Charging	Type-C, 18W PD Fast Charging
Wi-Fi	2.4G + 5G Dual-band (802.11ac)
Bluetooth	Bluetooth 5.0
Cellular	4G LTE (Dual SIM slots, GSM Carriers)
Navigation	GPS/GLONASS/BDS/Galileo
Dimensions (LxWxH)	10.2 x 6.6 x 0.31 inches
Weight	1.09 pounds (493g)
Color	Gray

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your product or visit the official CHUWI website. You may also contact the seller directly for assistance.