

[Manuals.plus](#) /

> [SONGMICS](#) /

> SONGMICS HSR107B01V1 Double-Rod Garment Rack Instruction Manual

SONGMICS HSR107B01V1

SONGMICS HSR107B01V1 Double-Rod Garment Rack Instruction Manual

Model: HSR107B01V1

1. PRODUCT OVERVIEW

The SONGMICS HSR107B01V1 is a sturdy, double-rod garment rack designed for efficient clothing storage and organization. It features a robust steel frame, two hanging rods for ample capacity, a bottom shelf for additional storage, and four casters for easy mobility, two of which are lockable for stability.




Image 1.1: Fully assembled SONGMICS HSR107B01V1 Double-Rod Garment Rack, showcasing its storage capacity with various garments, bags, and storage boxes.

2. PACKAGE CONTENTS

Before assembly, please verify that all components are present and undamaged. Refer to the assembly diagram for part identification.

- Steel Pipes (various lengths and shapes, labeled A-J)
- Bottom Shelf Bars
- Casters (4 pieces, 2 with locks)
- Screws and Bolts
- Assembly Tool (e.g., Allen wrench)
- Instruction Manual



ご注意：

ネジ、ボトルは位置に合わせてながら仮止めして下さい。ネジ、ボトルを締め終わられる際に力を入れすぎると空回りする恐れがございますのでご注意ください。また、ネジを締めつける際に斜めにねじ込まないようにご注意ください。すべてのネジ、ボトルが合った事をご確認の上、最後にしっかりとネジ、ボトルを締めて下さい。




Image 2.1: Exploded view of all components required for assembly, with each part labeled for easy identification. A caution note regarding screw tightening is also visible.

3. SETUP AND ASSEMBLY

Follow these steps carefully to assemble your garment rack. It is recommended to assemble on a soft, clean surface to prevent scratches.

- 1. Identify Parts:** Lay out all components and match them with the labels (A-J) in the assembly diagram (Image 2.1).
- 2. Initial Fastening:** Begin by loosely attaching screws and bolts to their designated positions. Do not fully tighten any screws until all parts are correctly aligned.

3. **Assemble Base:** Connect the base frame components (e.g., parts B, D) using the provided screws. Ensure the caster attachment points are correctly oriented.
4. **Attach Casters:** Securely attach the four casters to the base. Ensure the two lockable casters are placed on the same side for convenient access.
5. **Install Vertical Supports:** Connect the vertical support pipes (e.g., parts E, J) to the base.
6. **Attach Hanging Rods:** Secure the upper hanging rods (e.g., parts C, H) to the vertical supports. Note the 42cm width between the front and back poles for optimal hanging space.
7. **Install Bottom Shelf:** Place the bottom shelf bars onto their designated supports.
8. **Final Tightening:** Once all parts are correctly assembled and aligned, gradually tighten all screws and bolts securely. Avoid overtightening, which can strip the threads, and ensure screws are inserted straight, not at an angle.

厚さ25.4mmの鋼管 安定性を高めるためネジで固定します



Image 3.1: Detail of the 25.4mm thick steel pipe connection, secured with screws for enhanced stability. This design minimizes deformation compared to standard push-fit connections.

4. OPERATING INSTRUCTIONS

The SONGMICS HSR107B01V1 garment rack is designed for versatile use in organizing your clothing and accessories.

4.1 Hanging Garments

- Utilize the two hanging rods to organize a large volume of clothes. The front rod is suitable for shorter items like shirts and pants (141 cm clearance), while the back rod accommodates longer garments such as coats and dresses (155 cm clearance).

- The 42 cm width between the front and back poles provides ample space, making it easy to hang and retrieve clothes without crowding.
- Use the integrated hooks on the side for hanging bags, scarves, hats, or other accessories.



Image 4.1: The double-rod design allows for hanging garments of varying lengths, with side hooks for accessories. The front rod offers 141 cm height, and the back rod offers 155 cm height.

4.2 Using the Bottom Shelf

- The sturdy bottom shelf provides additional storage for items such as shoes, storage boxes, folded clothes, or other accessories.
- There is approximately 18 cm of clearance beneath the bottom shelf, allowing for easy cleaning underneath the rack, even with a robotic vacuum.



キャスター付き

移動と固定がスムーズに



Image 4.2: The bottom shelf provides practical storage for shoes and boxes, with sufficient clearance for cleaning devices.

4.3 Mobility and Stability

- The four smooth-rolling casters allow you to easily move the garment rack, even when fully loaded, making it convenient for rearranging your space or cleaning.
- Two of the casters are equipped with locking mechanisms. To stabilize the rack, press down on the lock levers on these casters. To move, release the locks.

5. MAINTENANCE

To ensure the longevity and optimal performance of your garment rack, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the steel frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Inspection:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary to maintain stability.
- **Weight Distribution:** Distribute the weight of your garments evenly across both rods to prevent strain on the frame. Do not exceed the maximum weight capacities.
- **Caster Care:** Keep the casters free of dust and debris to ensure smooth movement.

6. TROUBLESHOOTING

If you encounter any issues with your garment rack, refer to the following common solutions:

- **Rack is Wobbly:**
 - Ensure all screws and bolts are fully tightened. Refer to the assembly instructions for proper tightening technique.
 - Verify that the rack is placed on a flat, even surface.
 - Check that the casters are locked when stationary.
- **Difficulty Assembling / Screws Not Fitting:**
 - Ensure you are using the correct screws for each part as indicated in the assembly diagram.
 - Make sure parts are aligned correctly before attempting to insert and tighten screws. Do not force screws if they do not fit easily; this can strip the threads.
 - Loosely assemble all parts first, then tighten them securely once the entire structure is in place.
- **Casters Not Rolling Smoothly:**
 - Check for any hair, dust, or debris caught in the caster wheels and remove them.
 - Ensure the caster locks are disengaged.

7. SPECIFICATIONS

Feature	Detail
Model Number	HSR107B01V1
Brand	SONGMICS
Material	Alloy Steel
Color	Black
Overall Dimensions (approx.)	103.5 cm (Width) x 52.5 cm (Depth) x 141-155 cm (Height)
Product Weight	5.6 kg
Top Rod Weight Capacity	Up to 30 kg
Bottom Shelf Weight Capacity	Up to 20 kg
Features	Double hanging rods, bottom shelf, 4 casters (2 lockable)
Assembly Required	Yes (Customer Assembly)

Country of Origin

China



Image 7.1: Detailed diagram illustrating the dimensions (width 103.5cm, depth 52.5cm, height 141-155cm) and weight capacities (30kg for top rods, 20kg for bottom shelf) of the garment rack.

8. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or customer support, please refer to the retailer's policy where the product was purchased or visit the official SONGMICS website. Please retain your proof of purchase for any warranty claims.

