

Saved from manuals.plus.

Open the live page for links to other documents and user manuals.

[Manuals.plus](#) /

› [iPhanmis](#) /

› iPhanmis XS15 3G Mini Smartphone User Manual

iPhanmis XS15

iPhanmis XS15 3G Mini Smartphone User Manual

Model: XS15

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your iPhanmis XS15 3G Mini Smartphone. Please read this manual thoroughly to ensure proper use and to maximize the performance of your device.



Image: Front and back view of the iPhanmis XS15 Mini Smartphone, showcasing its compact design and camera module.

1. SETUP

1.1 Package Contents

Verify that your package contains the following items:

- 1 x XS15 Mini 3G Smartphone
- 1 x Charging Cable
- 1 x User Manual (this document)

1.2 Inserting SIM and TF Cards

The XS15 supports dual SIM cards and a TF (microSD) card for expandable storage up to 128GB.

1. Locate the SIM/TF card tray on the side of the device.
2. Use the provided SIM ejector tool (if included) or a small paperclip to open the tray.
3. Carefully place your SIM card(s) and TF card into the designated slots. Ensure correct orientation.
4. Gently push the tray back into the phone until it clicks into place.



Image: Illustration of the dual SIM card and TF card slots, indicating where to insert the cards.

Important Note on Network Compatibility: This is a 3G smartphone. Some mobile carriers have discontinued 2G and 3G networks. Before using, please confirm that your SIM card supports one or more of the following frequencies: 2G GSM 850/900/1800/1900; 3G WCDMA/B1/B2/B5/B8.

1.3 Initial Charging and Power On

1. Connect the charging cable to the phone's charging port and the other end to a compatible USB power adapter.
2. Allow the phone to charge for at least 30 minutes before first use, or until the battery indicator shows sufficient charge.
3. Press and hold the Power button (usually on the side) until the screen lights up and the device vibrates.
4. Follow the on-screen prompts to complete the initial setup, including language selection, Wi-Fi connection, and Google account setup.



Image: The XS15 Mini Smartphone connected to a charger, illustrating the charging process.

2. OPERATING YOUR SMARTPHONE

2.1 Basic Navigation

Your XS15 Mini Smartphone runs on Android 8.1. Navigation is primarily done via the 3.0-inch touchscreen.

- **Tap:** Select an item or open an app.
- **Swipe:** Scroll through screens or lists.
- **Pinch:** Zoom in or out on photos and web pages.
- **Long Press:** Access contextual menus or move app icons.



Image: The compact XS15 Mini Smartphone held in a hand, displaying various application icons on its screen.

2.2 Connectivity

- **Wi-Fi:** Connect to wireless networks for internet access. Go to **Settings > Network & Internet > Wi-Fi**.
- **Bluetooth:** Pair with headphones, speakers, or other Bluetooth devices. Go to **Settings > Connected devices > Bluetooth**.
- **Hotspot Sharing:** Share your phone's mobile data connection with other devices. Go to **Settings > Network & Internet > Hotspot & tethering**.
- **GPS:** Utilize location services for navigation and location-based apps.

2.3 Camera Functions

The XS15 features a front 0.3 Mpx camera (with beautifying effects) and a back 2.0 Mpx camera.

- Open the **Camera** app from your home screen or app drawer.
- Tap the shutter button to take a photo.
- Switch between front and rear cameras using the camera toggle icon.
- **Note:** The device has multiple lenses on the back, but only one rear camera is functional. The others are decorative.

Illuminate you and me, beauty in every moment

High definition camera presenting highlights

Every beat touches the heart, and with each press of the shutter, delicate colors and moving moments are presented. Amidst the distant light, the night reaches a time of confusion, restoring a pure perspective.



Image: A detailed view of the smartphone's rear camera array, highlighting its design.

Camera

The freeze frame is beautiful, the color style is unique, and it forms a unique shot.



It's more natural to take photos if you want to

Born on camera, you shine brighter

How to take photos, how to be beautiful, so that your beauty can be clearly presented anytime and anywhere, no matter how far or near, always pursuing your charming figure and face.



2.4 Other Features

Your smartphone includes several pre-installed applications and features:

- **App Store:** Download and install new applications.
- **WhatsApp:** Messaging application.
- **GPRS:** General Packet Radio Service for mobile data.
- **Alarm clock, Calendar, Memorandum, Calculator:** Standard utility apps.
- **Facial Recognition:** For unlocking your device.
- **Dual Sim Dual Standby:** Allows two SIM cards to be active simultaneously.

3. MAINTENANCE

3.1 Battery Care

The XS15 is equipped with a 1000mAh battery. To prolong battery life:

- Avoid extreme temperatures.
- Do not overcharge the device; disconnect once fully charged.
- Use only the provided or certified charging accessories.
- Close unused applications running in the background to conserve power.

3.2 Storage Management

The device comes with 16GB of internal storage. You can expand this using a TF card up to 128GB.

- Regularly clear cache and unnecessary files to free up space.
- Transfer large files (photos, videos) to your TF card or cloud storage.
- Uninstall apps you no longer use.



Image: A visual representation of the smartphone's storage capabilities, showing space for apps, photos, and videos.

3.3 Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your smartphone. Avoid using harsh chemicals or abrasive materials.

4. TROUBLESHOOTING

Problem	Possible Solution
No Network Signal / Cannot Make Calls	• Ensure your SIM card is correctly inserted. • Verify your SIM card supports 3G networks (2G GSM 850/900/1800/1900; 3G WCDMA/B1/B2/B5/B8). • Check if you are in an area with network coverage. • Restart the phone.
Phone is Slow / Apps Crashing	• Close background applications. • Clear app caches (Settings > Apps & notifications > [App Name] > Storage & cache > Clear cache). • Ensure sufficient storage space is available. • Restart the device.

Problem	Possible Solution
Battery Drains Quickly	• Reduce screen brightness. • Disable Wi-Fi, Bluetooth, GPS when not in use. • Limit background app activity. • Check for apps consuming excessive power (Settings > Battery).
Camera Not Working as Expected	• Ensure the camera lens is clean. • Remember that only one rear camera is functional; others are decorative. • Restart the camera app or the phone.

5. SPECIFICATIONS

Feature	Detail
Model Name	XS15
Operating System	Android 8.1
CPU Model	MediaTek Helio Quad Core
CPU Speed	1.3 Hz
RAM Memory	2 GB
Internal Storage	16 GB
Expandable Storage	Supports TF card up to 128 GB (not included)
Screen Size	3.0 Inches
Resolution	1280 x 720
Rear Camera	2.0 Mpx (Note: Only one functional rear camera)
Front Camera	0.3 Mpx (with Beautifying)
Battery Capacity	1000 Milliamp Hours
Connectivity	3G (WCDMA/B1/B2/B5/B8), 2G (GSM 850/900/1800/1900), Wi-Fi, Bluetooth, GPS
SIM Support	Dual SIM Dual Standby
Product Dimensions	3.48 x 1.78 x 0.43 inches (88.40 x 45.20 x 11 mm)
Item Weight	1.6 ounces
Audio Jack	No headphone jack
Color	Black

6. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or contact the retailer/manufacturer directly. Keep your proof of purchase for warranty claims.

Manufacturer: Soyes

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CPY2YKNS>

More documents and user manuals: <https://manuals.plus/>