Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tosuny Tosuny5ut8y4cikz

Tosuny Ultra-Thin Magnetic Light Box Slide Viewer and Negative Film Scanner

Model: Tosuny5ut8y4cikz

Introduction

This instruction manual provides detailed guidance for using your Tosuny Ultra-Thin Magnetic Light Box Slide Viewer and Negative Film Scanner. This device is designed to help you view and digitize your old slides and negative films, preserving your precious memories in a digital format. Please read this manual thoroughly before operating the device to ensure proper usage and optimal results.




Figure 1: Top-down view of the Tosuny Ultra-Thin Magnetic Light Box Slide Viewer.

Product Features

- **Slide and Negative Film Compatibility:** Designed for viewing and digitizing both slides and negative films.
- **Ultra-Thin and Lightweight Design:** The compact and portable design allows for easy handling and storage.
- **Large Viewing Area:** Sufficiently sized to accommodate multiple slides or film strips simultaneously for efficient

viewing and scanning.

- **3-Level Brightness Adjustment:** Easily adjust the LED light source to one of three brightness levels with a gentle touch of the on/off switch.
- **Even and Soft LED Illumination:** The LED light source provides uniform and soft light distribution, crucial for accurate color reproduction during digitization.
- **Mobile App Integration:** Supports dedicated mobile applications like SlideScan (for slides) and FilmBox (for negatives) for scanning, editing, and sharing digital images.
- **USB-C Power Supply:** Conveniently powered via a USB-C cable, allowing connection to a power adapter, power bank, or laptop.

Setup

1. **Unpack the Device:** Carefully remove the light box, USB cable, and user manual from the packaging.
2. **Connect Power:** Connect the provided USB-C cable to the light box's power port. Plug the other end of the USB cable into a compatible power source (e.g., USB power adapter, power bank, or computer USB port).
3. **Power On:** Gently touch the power button on the light box once to turn it on. The LED light will illuminate.
4. **Adjust Brightness:** Press and hold the power button to cycle through the 3 brightness levels (low, medium, high). Release the button when the desired brightness is reached.




Figure 2: Dimensions of the Tosuny Ultra-Thin Magnetic Light Box.

Operating Instructions

Viewing Slides and Negatives

1. Place your slides or negative films directly onto the illuminated surface of the light box.
2. Adjust the brightness as needed for optimal viewing.
3. The large surface allows for arranging multiple items for comparison or batch viewing.

Digitizing with Mobile Apps

To digitize your slides and negative films, you will need to download the appropriate mobile application from your device's App Store.

- For slides: Download the **SlideScan** app.
- For negative films: Download the **FilmBox** app.

General Scanning Steps:

1. Ensure the light box is powered on and set to an appropriate brightness level.
2. Place the slide(s) or negative film(s) flat on the light box surface. For negative films, use the included magnets to secure them if they tend to curl.
3. Open the relevant scanning app (SlideScan for slides, FilmBox for negatives) on your mobile phone.
4. Position your mobile phone camera horizontally above the slide/negative, ensuring it is centered and focused.
5. Follow the in-app instructions to capture the image. The app will typically invert colors for negatives and enhance image quality.
6. Use the app's editing features to further refine your digitized images.
7. Save and share your newly digitized memories!

Your browser does not support the video tag.

Video 1: Demonstration of the LED Light Panel for scanning slides and negatives, highlighting its 5600K color temperature for natural light simulation and high Color Rendering Index (CRI) for accurate color restoration. The video also compares it to an ordinary light box.

Your browser does not support the video tag.

Video 2: Step-by-step scanning instructions using the light box with a mobile phone and the FilmBox app for negatives, and the SlideScan app for slides. It demonstrates connecting the power, adjusting brightness, securing negatives with magnets, and scanning multiple items.

Your browser does not support the video tag.

Video 3: Tutorial on how to digitize negatives using a mobile phone and the Snapseed app. It covers turning on the light box, placing the negative, taking a photo, and using Snapseed's curve tools to invert and adjust colors for a positive image.

Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the light box. Avoid abrasive cleaners or solvents that could damage the acrylic.
- **Storage:** Store the light box in a cool, dry place away from direct sunlight and extreme temperatures when not in

use.

- **Handling:** Handle the device with care to prevent scratches or damage to the illuminated surface.

Troubleshooting

- **Light Box Not Turning On:** Ensure the USB-C cable is securely connected to both the light box and the power source. Try a different USB port or power adapter.
- **Uneven Illumination:** Check for any obstructions on the light box surface. If the issue persists, contact customer support.
- **Poor Scan Quality:** Ensure your mobile phone camera is clean, focused, and positioned directly above the film/slide. Adjust the light box brightness. Refer to the mobile app's instructions for optimal settings.
- **App Issues:** Ensure your mobile app is updated to the latest version. Restart the app or your mobile device if it's not functioning correctly.

Specifications

Attribute	Detail
Item Type	Slide Viewer
Material	Acrylic
Color	Black
Product Dimensions	34.9 x 24.8 x 0.7 cm (13.7 x 9.8 x 0.3 inches)
Item Thickness	7 mm
Power Source	DC Powered (USB-C)
Light Source Type	Light Emitting Diode (LED)
Brightness Adjustment	3 Levels
Model Name	Tosuny5ut8y4cikz
Manufacturer	Tosuny
Country of Origin	China

Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Tosuny website. Keep your purchase receipt as proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CPYF49L7

More documents and user manuals: **https://manuals.plus/**