

- Manuals.plus /
- › YESHOMY /
- › User Manual for YESHOMY Glass Fireplace TV Stand

YESHOMY 1

User Manual for YESHOMY Glass Fireplace TV Stand

Model: 1
Brand: YESHOMY

PRODUCT OVERVIEW

The YESHOMY Glass Fireplace TV Stand is designed to accommodate televisions up to 65 inches, serving as a versatile media entertainment center. This console table features a stunning 26-inch three-sided panoramic electric fireplace, offering ultra-realistic flames and customizable heat settings for a cozy ambiance. It includes closed storage compartments with glass doors, providing ample space for media devices and accessories. Crafted with durable materials, this stand combines modern aesthetics with robust construction for long-lasting use.



Image: The YESHOMY Glass Fireplace TV Stand, showcasing its design and integrated electric fireplace, positioned in a living room environment.


SETUP AND ASSEMBLY

This TV stand is designed for fast and stress-free setup, with modular construction enabling assembly in approximately 15 minutes. The item ships in two shockproof packages, which may arrive on different days. It is recommended to unpack all components and verify against the included parts list before beginning assembly.

Assembly Steps:

1. Carefully unbox all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify all hardware and panels using the provided instruction manual.
3. Follow the step-by-step instructions for connecting the main frame and shelves.
4. Install the glass doors and the electric fireplace unit into their designated slots.
5. Attach the anti-tip hardware to the stand and secure it to a wall for enhanced stability, especially on uneven surfaces.

6. Adjust the feet as needed to ensure the stand is level.



COME IN 2 BOXES

(May not arrive
at the same time)



Image: A diagram illustrating the overall dimensions of the TV stand and the packaging details, indicating shipment in two separate boxes.



Image: The TV stand with its glass doors open, showcasing the interior storage compartments and the central fireplace section.

OPERATING INSTRUCTIONS

The integrated 26-inch electric fireplace provides both aesthetic appeal and functional heating. It features ultra-realistic flames and customizable heat settings to suit your comfort needs.

Fireplace Operation:

- **Power On/Off:** Locate the power button on the fireplace unit or use the remote control to turn the unit on or off.
- **Flame Settings:** Adjust the flame brightness and color (if applicable) using the dedicated controls. The fireplace offers multiple flame models for varied visual effects.
- **Heat Control:** Set your desired temperature within the range of 62°F-82°F. The unit provides 5118 BTU heating, suitable for areas up to 400 sq.ft.
- **Timer Function:** Utilize the built-in timer for automatic shut-off, with a maximum setting of 6 hours.
- **Wattage:** The fireplace operates at 900W.

24" 3D PANORAMIC FIREPLACE

with remote-controlled, 5118 BTU, heating for up to 400 sq.ft.



62F-82F



3 Model



Timer
(Maximum 6 Hours)



900W



NOTE: The item arrives in 2 packages,
possibly not on the same day



Image: A detailed graphic illustrating the features of the 24-inch 3D panoramic electric fireplace, including temperature control, flame models, timer, and power consumption.



Image: A visual guide demonstrating the compatibility of the TV stand with different television sizes, confirming support for TVs up to 65 inches.

MAINTENANCE AND CARE

Proper care ensures the longevity and appearance of your YESHOMY TV stand. The tempered glass features an anti-fingerprint coating for easy cleaning, and the nano-coated, waterproof base resists spills and stains.

Cleaning Instructions:

- For general cleaning, dust the surfaces with a soft, dry microfiber cloth.
- For smudges or spills on the glass or base, wipe immediately with a damp microfiber cloth.
- Avoid using harsh chemical cleaners, abrasive materials, or ammonia-based products, as these can damage the finish and coatings.
- Ensure liquids do not seep into the electrical components of the fireplace.

ALL-GLASS SURFACE



Image: A close-up shot highlighting the all-glass surface of the TV stand and the detailed, realistic flame effect of the electric fireplace.

TROUBLESHOOTING

This section provides guidance for common issues you might encounter with your TV stand and electric fireplace.

General Safety and Usage Tips:

- **Caution:** Handle the glass components with care to avoid breakage.
- **Stability:** Always ensure the stand is stable and level to prevent tipping. Use the adjustable feet and anti-tip hardware as instructed during assembly.
- **Overload:** Do not exceed the maximum weight capacity of the shelves (33 lbs per shelf) and top surface (132 lbs).

Fireplace Not Operating:

- Check if the power cord is securely plugged into a functional electrical outlet.

- Ensure the power switch on the fireplace unit is in the 'ON' position.
- Verify that the remote control batteries are not depleted and are inserted correctly.
- If the unit overheats, it may have an automatic shut-off feature. Unplug, wait 15 minutes, and plug back in.

SPECIFICATIONS

Feature	Detail
Brand	YESHOMY
Model Number	1
Product Dimensions (L x W x H)	18.7 x 59 x 31.6 inches
Item Weight	88 pounds
Material	Glass, E1 Particleboard, Steel
Color	Black
Number of Shelves	2
Special Feature	Storage Compartments, Electric Fireplace
TV Size Compatibility	Up to 65 inches
Fireplace Size	26 inches (panoramic)
Fireplace Heating Output	5118 BTU
Fireplace Heating Area	Up to 400 sq.ft.
Fireplace Wattage	900W
Weight Capacity (Top)	132 lbs (60 KG)
Weight Capacity (Shelf)	33 lbs (15 KG)
Product Care Instructions	Dust With Soft Dry Cloth

WARRANTY AND SUPPORT

YESHOMY provides a 365-day warranty for this product, covering manufacturing defects and ensuring peace of mind. For any assistance, including replacements, setup help, or styling tips, round-the-clock customer support is available.

For support, please refer to the contact information provided with your purchase or visit the official YESHOMY store on Amazon.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CQ2814MM>

More documents and user manuals: <https://manuals.plus/>