

[Manuals.plus](#) /

› [Bomieux](#) /

› Bomieux Kids Digital Watch User Manual

## Bomieux T15E

# Bomieux Kids Digital Watch User Manual

Model: T15E

### INTRODUCTION

This manual provides detailed instructions for the Bomieux Kids Digital Watch, a multi-functional device designed for children aged 5-12. It features a clock, alarm clock, step counter, stopwatch, calorie tracking, and mileage tracking. The watch is designed for ease of use without requiring a mobile phone connection or app downloads.



Image: Front view of the Bomieux Kids Digital Watch in light blue, displaying the time.

## KEY FEATURES

- **Multi-functionality:** Integrates clock, alarm clock, step counter, stopwatch, calories, and mileage.
- **Simple Operation:** No mobile phone or app required for use.
- **Fitness Tracking:** Built-in pedometer tracks steps, distance, and calories burned.
- **Silent Alarm Clock:** Vibrating alarm for discreet reminders.
- **Rechargeable Battery:** Built-in 50 mAh battery, charges via USB interface.
- **Water Resistance:** Resistant to splashing water (not for swimming/diving).
- **LED Display:** Clear and concise digital display.



Image: An infographic highlighting the watch's various features, including date/time, water resistance, backlight, USB charging, alarm, stopwatch, distance, calories, and pedometer.

## SETUP

### Initial Charging

Before first use, fully charge the watch. The watch dial has a built-in USB interface. Simply remove the watch dial from the strap and plug it into any standard USB adapter (e.g., phone charger, computer USB port, power bank).



Image: Two watch units detached from their straps, shown plugged into a laptop USB port and a power bank for charging.



Image: A close-up view of the watch's main unit, detached from the strap, being inserted into a laptop's USB port for charging. A full charge can last for more than 15 days, depending on usage. The screen will light up when charging is complete or when a button is pressed to wake it up.

### **Time and Date Setting**

Detailed instructions for setting time and date are typically found in the included quick start guide. Generally, this involves pressing and holding a specific button (often labeled 'SET' or 'MODE') to enter setting mode, then using other buttons to adjust values and confirm.

## **OPERATING INSTRUCTIONS**

### **Waking the Screen**

To conserve battery, the watch screen will turn off automatically. Press any button to wake the screen and view the time or other functions.

### **Time Display**

The default display shows the current time. The watch features a clear LED display.

### **Using the Pedometer (Step Counter)**

The watch automatically tracks steps, distance, and calories burned throughout the day. Ensure the watch is worn securely on the wrist for accurate tracking.

# NO APP KIDS FITNESS TRACKER WATCH



Image: Children participating in various activities like running, playing tennis, and cycling, illustrating the watch's ability to track pedometer, calories, and distance without an app.

## Setting and Using the Alarm Clock

The watch allows setting up to two silent vibrating alarms. This feature is ideal for discreet reminders without disturbing others, such as for school or daily tasks.



Image: A child sleeping peacefully with the watch on their wrist, emphasizing the silent vibrating alarm feature.



Image: A child stretching and waking up in bed, with an alarm clock icon and a digital watch displaying the time, illustrating the alarm function.

## Using the Stopwatch

The stopwatch function can be activated by pressing the appropriate button. It provides accurate timing for various activities.



Image: Children preparing to run on a track, with a stopwatch icon and a digital watch displaying 00:00:00, indicating the stopwatch function.

## Video Demonstration

Your browser does not support the video tag.

Video: A demonstration of the Bomieux Kids Digital Watch's multifunctional features, including how to check time and interact with the watch.

## MAINTENANCE

### Cleaning

Wipe the watch clean with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials.

### Water Resistance

The watch is resistant to splashing water, making it suitable for hand washing and face washing. It is **not recommended** for use during underwater activities such as swimming, diving, or showering, as this may damage the watch.



Image: A close-up of the watch face and strap with water droplets, illustrating its splash-resistant design.

## Battery Care

To maximize battery life, avoid extreme temperatures. Charge the watch regularly to maintain optimal performance.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch screen is blank/does not turn on.	Battery is depleted or watch is in power-saving mode.	Press any button to wake the screen. If it remains blank, charge the watch fully.
Watch not charging.	Improper connection or faulty USB port/adaptor.	Ensure the watch dial is correctly inserted into a working USB port. Try a different USB adaptor or port.
Time/Date is incorrect after charging.	Watch may not retain settings if battery is completely drained (as per some customer reviews).	Reset the time and date after each full discharge and recharge. Try to avoid complete battery depletion.
Pedometer not tracking accurately.	Watch is not worn securely or movement is not consistent.	Ensure the watch is worn snugly on the wrist. Consistent arm movement is required for accurate step counting.

## SPECIFICATIONS

**Model Number:** T15E

**Brand:** Bomieux

**Display Type:** LED Digital

**Battery:** Built-in 50 mAh rechargeable battery

**Charging Method:** USB direct charge (integrated into watch dial)

**Water Resistance:** Splash-proof (not for swimming/diving)

**Functions:** Time, Alarm Clock, Step Counter (Pedometer), Stopwatch, Calories, Mileage

**Watch Weight:** 20g

**Dial Dimensions:** 4.5cm x 4.1cm

**Strap Width:** 2.1cm

**Watch Circumference:** 13-19.5cm



Watch weight: 20g

Battery capacity: 50mAh

Dial: 4.5x4.1cm

Strap width: 2.1cm

Circumference of the watch: 13-19.5cm

Image: A diagram illustrating the physical dimensions of the watch, including dial size, strap width, and overall circumference, along with weight and battery capacity.

**WARRANTY AND SUPPORT**

For any questions, concerns, or support needs regarding your Bomieux Kids Digital Watch, please contact our customer service team. Refer to the product packaging or the retailer's website for specific contact information. Bomieux is committed to providing quality products and customer satisfaction. We encourage you to reach out if you encounter any issues.