SIFENE JS3304

SiFENE Cold Press Juicer Machine User Manual

Model: JS3304

1. Product Overview

The SiFENE Cold Press Juicer Machine is designed to extract maximum nutrients and flavor from fruits and vegetables through its slow masticating process. This manual provides essential information for safe and efficient operation, maintenance, and troubleshooting.



Image: The SiFENE Cold Press Juicer in black, actively juicing celery and an apple, with a glass of green juice and a pulp cup visible.

Key Features:

- **Cold Press Technology:** Minimizes oxidation for higher nutrient retention.
- **Dual Feed Chutes:** Allows for continuous juicing of various fruit and vegetable sizes.
- **Quiet Operation:** Operates at a low noise level (as low as 60dB).
- **Easy to Clean:** Removable, dishwasher-safe parts (except motor base).
- **Compact Design:** Space-saving footprint for convenient storage.

2. Safety Information

Please read all safety instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the juicer is properly assembled before operation.
- Do not immerse the motor base in water or any other liquid.
- Keep hands and utensils out of the feed chute during operation. Always use the provided pusher.
- Unplug the juicer from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not operate the juicer if the power cord or plug is damaged.
- This appliance is for household use only. Do not use outdoors.
- Keep out of reach of children.
- Avoid juicing hard items like pits, seeds, or frozen fruits unless specifically designed for it, as this can damage the auger.

3. Parts List

Familiarize yourself with all components of your SiFENE Cold Press Juicer Machine:



Image: A visual breakdown of all components included with the juicer, numbered for easy identification.

1. Machine Body (Motor Base)
2. Juicing Body
3. Juice Cup
4. Pulp Cup

5. Cleaning Brush
6. Pusher
7. Spiral Presser (Auger)
8. Fine Strainer
9. Juicing Body Cover

4. Setup and Assembly

Follow these steps to assemble your juicer before first use:

1. Place the Motor Base (1) on a stable, flat surface.
2. Insert the Spiral Presser (7) into the Juicing Body (2).
3. Place the Fine Strainer (8) over the Spiral Presser within the Juicing Body.
4. Attach the Juicing Body Cover (9) to the front of the Juicing Body, ensuring it clicks into place securely.
5. Align the assembled Juicing Body with the Motor Base and twist clockwise until it locks securely. You should hear a click.
6. Position the Juice Cup (3) under the juice spout and the Pulp Cup (4) under the pulp outlet.



Image: A visual guide showing the simple assembly process of the juicer's main components and the ease of cleaning under running water.

5. Operating Instructions

Preparation:

- Wash all fruits and vegetables thoroughly.
- Cut ingredients into pieces that fit easily into the dual feed chutes (e.g., celery into 1.5-inch pieces, apples into 2.0-inch pieces). Remove large seeds, pits, and hard skins.

Juicing Process:

1. Ensure the juicer is properly assembled and the juice and pulp cups are in place.
2. Plug the power cord into a grounded electrical outlet.
3. Turn the control knob to the 'ON' position. The motor will start.
4. Slowly feed the prepared ingredients into the appropriate feed chute. Use the pusher (6) only when necessary to guide ingredients down, do not force them.
5. The juicer's slow masticating action will extract juice into the juice cup and separate pulp into the pulp cup.
6. For continuous juicing, utilize both feed chutes as needed.
7. Once juicing is complete, turn the control knob to the 'OFF' position and unplug the appliance.



Image: The juicer's dual feed chutes, illustrating how they accommodate both long vegetables (like celery) and wider fruits (like apples) for efficient juicing.

Reverse Function:

If ingredients become jammed or the juicer stops during operation, turn the control knob to the 'REV' (Reverse) position and hold for a few seconds. This will reverse the auger's rotation to clear the blockage. Release the knob to return to the 'OFF' position, then switch back to 'ON' to resume juicing.

Your browser does not support the video tag.

Video: Demonstrates the assembly, operation, and cleaning process of the SiFENE Slow Masticating Juicer, highlighting its dual feed chutes and ease of use.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your juicer. Clean the juicer immediately after each use.

Disassembly for Cleaning:

1. Ensure the juicer is unplugged.
2. Remove the juice and pulp cups.
3. Twist the Juicing Body counter-clockwise to unlock it from the Motor Base and remove it.
4. Disassemble the Juicing Body Cover, Fine Strainer, and Spiral Presser.

Cleaning Steps:

- Rinse all detachable parts (Juicing Body, Juicing Body Cover, Spiral Presser, Fine Strainer, Juice Cup, Pulp Cup, Pusher) under running water to remove pulp residue.
- Use the provided Cleaning Brush (5) to thoroughly clean the Fine Strainer and any hard-to-reach areas.
- All detachable parts are dishwasher safe. For best results, place them on the top rack.
- Wipe the Motor Base (1) with a damp cloth.**Never immerse the motor base in water.**
- Allow all parts to dry completely before reassembling or storing.

7. Troubleshooting

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; improper assembly; power outage.	Ensure plug is securely in outlet. Check assembly, reassemble if necessary. Check household circuit breaker.
Motor stops during operation.	Overload/jammed ingredients; overheating protection activated.	Switch to 'REV' to clear blockage. If still stuck, disassemble and remove ingredients. Allow motor to cool down for 20-30 minutes before restarting.
Low juice yield or excessive pulp.	Ingredients too hard or fibrous; improper cutting; strainer clogged.	Ensure ingredients are cut to appropriate size. Clean the strainer thoroughly. For very fibrous ingredients, consider re-juicing the pulp.
Loud noise or vibration.	Improper assembly; foreign object inside; worn parts.	Check that all parts are securely locked. Disassemble and check for foreign objects. If problem persists, contact customer service.

8. Specifications

Feature	Detail
Brand	SIFENE
Model Name	Slow Masticating Cold Press Juicer
Model Number	JS3304
Color	Black
Product Dimensions	9.06"D x 5.12"W x 11.02"H
Item Weight	4.3 pounds
Capacity	280 Milliliters (Juice Cup)
Maximum Power	150 Watts
Voltage	120 Volts
Control Type	Knob
Blade Material	Stainless Steel
Special Features	Cold Press Technology, Juice Blend with Smart Juice Cap, Reverse Function, Compact Design, Dual Feed Chutes, Quiet Motor

9. Warranty and Customer Support

SiFENE stands behind its products and offers lifelong customer service and a satisfaction guarantee. For any questions, concerns, or to request a replacement or reimbursement, please contact SiFENE customer service directly.

For additional support and information, you may refer to the official SiFENE store or product page:

Visit the SIFENE Store

Download User Guide (PDF)

© 2024 SiFENE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question