

- Manuals.plus /
- › Bewinner /
- › Bewinner BT 5.3 Noise Canceling Cordless Headphones User Manual

Bewinner Bewinner08enoy7m2c

Bewinner BT 5.3 Noise Canceling Cordless Headphones User Manual

Model: Bewinner08enoy7m2c

1. INTRODUCTION

This manual provides instructions for the proper use and care of your Bewinner BT 5.3 Noise Canceling Cordless Headphones. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.



Image 1.1: Bewinner BT 5.3 Noise Canceling Cordless Headphones and Charging Case.

2. PRODUCT OVERVIEW

2.1 Key Features

- **Clear Sound Quality:** Provides an immersive sound experience with distinct layers and rich audio details.
- **Bluetooth 5.3:** Ensures stable signal transmission and reduced standby power consumption for seamless connectivity.
- **Active Noise Cancellation (ANC):** Advanced ANC technology with a complex acoustic structure effectively reduces ambient noise.
- **Easy Pairing:** Automatic pairing upon removal from the charging case, with simple Bluetooth connection to your device.
- **Long Battery Life:** Offers 4 to 5 hours of continuous playback and up to 230 hours of standby time. The charging case provides an additional 30 hours of music playback after a 1.5-hour charge.

SUPERIOR SOUND QUALITY

Bluetooth earbuds with HIFI surging bass, rich layers, so that the sound is more sensory, sound quality is pure and excellent, enjoy the feast of hearing.



Image 2.1: Illustration of the headphones' superior sound quality.

BLUETOOTH 5.3

This wireless earbuds can be connected to cell phones, computers and other devices through Bluetooth technology without the use of wires.




Image 2.2: Depiction of Bluetooth 5.3 technology.

IPX4 LIFE WATERPROOF

This wireless earbuds can be connected to cell phones, computers and other devices through Bluetooth technology without the use of wires.



Soak in a hot spring



Sports & Work out

Image 2.3: Visual representation of Active Noise Cancellation (ANC).

Long endurance 16 hours

2 times longer than the same levels

Live long and enjoy an immersive music experience

Super poly lithium battery for music and sports



Image 2.4: The headphones and case demonstrating extended battery life.

2.2 What's in the Box

- Bewinner BT 5.3 Noise Canceling Cordless Headphones (Left and Right Earbuds)
- Charging Case
- USB Charging Cable
- Multiple Sizes of Ear Tips



Image 2.5: Package contents including earbuds, charging case, cable, and ear tips.

3. SETUP

3.1 Initial Charging

1. Place both earbuds into the charging case.
2. Connect the USB charging cable to the charging port on the case and a power source.
3. Allow the earbuds and case to charge fully before first use. The charging indicator lights will provide status.

3.2 Pairing with a Device

1. Ensure the charging case is charged and both earbuds are inside.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, laptop), navigate to the Bluetooth settings.
4. Select "Bewinner08enoy7m2c" (or similar name) from the list of available devices.
5. Once connected, a confirmation sound or message may be heard/displayed.

For subsequent use, the earbuds will automatically connect to the last paired device when removed from the case, provided Bluetooth is enabled on the device.

Your browser does not support the video tag.

Video 3.1: A brief demonstration of the Bewinner Heartbuds BT 5.3 headphones in use, showcasing their design and wearability.

4. OPERATING INSTRUCTIONS

4.1 Basic Controls (Touch Sensitive)

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call or active call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earbud.
- **Toggle ANC/Transparency Mode:** Press and hold either earbud for 3 seconds.

4.2 Power On/Off

- **Power On:** Open the charging case, or press and hold the touch area on both earbuds for 3 seconds if they are outside the case and powered off.
- **Power Off:** Place the earbuds back into the charging case and close the lid, or press and hold the touch area on both earbuds for 5 seconds.

5. MAINTENANCE

5.1 Cleaning

- Use a soft, dry, lint-free cloth to clean the earbuds and charging case.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.
- Gently remove earwax or debris from the ear tips and speaker mesh using a small, soft brush or cotton swab.

5.2 Storage

- Store the headphones in their charging case when not in use to protect them and keep them charged.
- Avoid storing in extreme temperatures or high humidity.

ANC active noise reduction technology

Using the active noise reduction technology with complex acoustic structure, even in a very noisy environment, after the noise reduction is turned on, it is just like in the study



Image 5.1: The headphones are designed with IPX4 water resistance, suitable for light splashes.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Earbuds not pairing with device	Bluetooth off, earbuds not in pairing mode, device already connected to another Bluetooth accessory.	Ensure Bluetooth is enabled on your device. Place earbuds in case, close, then open to re-enter pairing mode. Forget previous connections on your device.
No sound or low volume	Volume too low on device/earbuds, earbuds not properly seated, earwax blockage.	Adjust volume on both your device and the earbuds. Ensure earbuds are correctly placed in your ears. Clean ear tips and speaker mesh.
Earbuds not charging	Charging cable/port issue, dirty charging contacts, case battery depleted.	Check cable and power source. Clean charging contacts on earbuds and case. Ensure charging case is charged.

Problem	Possible Cause	Solution
ANC not working effectively	ANC mode not activated, improper fit, very high-frequency noise.	Ensure ANC is toggled on (press and hold for 3 seconds). Adjust earbud fit for a better seal. ANC is less effective against sudden, high-pitched sounds.

7. SPECIFICATIONS

Feature	Detail
Model Name	Bewinner08enoy7m2c
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Bluetooth Range	15 Meters
Noise Control	Active Noise Cancellation
Battery Life (Earbuds)	4-5 Hours (continuous playback)
Standby Time	Up to 230 Hours
Charging Time (Case)	1.5 Hours (for additional 30 hours playback)
Material	Acrylonitrile Butadiene Styrene (ABS)
Earpiece Shape	Heart-shaped
Color	Lake Green
Item Weight	3.52 ounces
Compatible Devices	Smartphones, Laptops, Tablets, Smart Speakers

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact the retailer. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CQ4ZJ1FS>

More documents and user manuals: <https://manuals.plus/>