

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [VOOMY](#) /

> [VOOMY 3-in-1 Wireless Charging Station with LED Light - User Manual](#)

VOOMY VOOMY 3-in-1 Wireless Charger

VOOMY 3-in-1 Wireless Charging Station with LED Light

Model: VOOMY 3-in-1 Wireless Charger

INTRODUCTION

Thank you for choosing the VOOMY 3-in-1 Wireless Charging Station. This device is designed to provide convenient and efficient charging for your compatible smartphone, smartwatch, and wireless earbuds simultaneously. It also features an integrated LED desk lamp with adjustable brightness and an additional USB-A port for wired charging.

Please read this manual carefully before use to ensure proper operation and to maximize the lifespan of your product.

PRODUCT OVERVIEW

The VOOMY 3-in-1 Wireless Charging Station combines multiple functionalities into a single, elegant unit.



Image: The VOOMY 3-in-1 Wireless Charging Station, showcasing a smartphone charging vertically, a smartwatch on its dedicated pad, and wireless earbuds on the base, alongside the included power adapter.

Key Features:

- **3-in-1 Wireless Charging:** Simultaneously charge a smartphone, smartwatch, and wireless earbuds.
- **15W Fast Wireless Charging:** Optimized for quick charging of compatible devices.
- **Integrated LED Desk Lamp:** Features 3 adjustable brightness levels for versatile use.
- **Additional USB-A Output:** For charging other devices via a wired connection.
- **Universal Compatibility:** Supports Qi-enabled devices, MagSafe compatible phones, Apple Watch, and AirPods.
- **Advanced Safety Features:** Built-in protection against overcharge, overvoltage, short-circuit, and lightning.

Station de recharge sans fil 5 en 1



3X sans fil
Chargeurs



15W



Éclairage
3 positions



Image: An illustration highlighting the station's capabilities: three wireless charging zones, 15W fast charging, and a 3-position LED light.

PACKAGE CONTENTS

- VOOMY 3-in-1 Wireless Charging Station
- USB-C Charging Cable
- User Manual

Note: A power adapter (wall charger) is required and may be included depending on your purchase. Ensure the adapter provides sufficient power (e.g., 9V/2A or 12V/1.5A) for optimal performance.

SETUP INSTRUCTIONS

1. **Connect Power:** Insert the USB-C end of the provided charging cable into the USB-C input port on the back of the charging station. Plug the other end of the cable into a compatible power adapter (not always included) and then into a wall outlet.
2. **Power On:** The LED indicator on the base will briefly light up, indicating the station is powered on and ready for use.



Image: A detailed view of the charging station's side, showing the USB-C input port for power and an additional USB-A output port for wired charging.

OPERATING INSTRUCTIONS

1. Charging Your Smartphone:

- Place your MagSafe-compatible smartphone onto the vertical charging stand. The phone will magnetically align.
- Ensure the phone screen displays the charging indicator.
- The stand supports both vertical and horizontal (landscape) charging orientations.



Image: A smartphone charging on the MagSafe-compatible stand, demonstrating both vertical and horizontal charging positions.

2. Charging Your Smartwatch:

- Place your compatible smartwatch onto the dedicated magnetic charging pad located on the side of the stand.

- The smartwatch should magnetically snap into place and begin charging.




Image: A close-up of a smartwatch being wirelessly charged on its designated magnetic pad on the station.

3. Charging Your Wireless Earbuds:

- Place your Qi-compatible wireless earbud case onto the charging pad located on the base of the station.
- Ensure the earbud case is centered on the charging area for optimal contact.

Chargeur sans fil

Pour vos écouteurs sans fil



Image: A wireless earbud case placed on the charging base of the station, indicating wireless charging in progress.

4. Using the LED Desk Lamp:

- The charging station features a touch-sensitive control for the LED light.
- **To Turn On/Off:** Lightly tap the touch control area on the base.
- **To Adjust Brightness:** Tap the control area repeatedly to cycle through the 3 brightness levels (Dim, Medium, Bright) and off.




Image: A hand touching the designated area on the charging station's base, indicating the touch-controlled LED light function.

3 positions Éclairage



Gedimd



Moyens



Lumineux

Image: A visual representation of the three adjustable brightness levels of the integrated LED light: Dim, Medium, and Bright.

5. Using the USB-A Output Port:

- Connect any device that charges via a standard USB-A cable (e.g., fitness trackers, older phones) to the USB-A output port on the side of the charging station.
- This port provides an additional option for wired charging.

MAINTENANCE

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the surface of the charging station. Do not use abrasive cleaners, solvents, or immerse the device in water.

- **Storage:** When not in use for extended periods, store the charging station in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or crimping the charging cable excessively.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not charging wirelessly.	<ul style="list-style-type: none"> ◦ Device not Qi-compatible or MagSafe-compatible. ◦ Device not properly aligned on the charging pad. ◦ Thick phone case interfering with charging. ◦ Power adapter not sufficient or not connected. 	<ul style="list-style-type: none"> ◦ Verify device compatibility. ◦ Adjust device position to ensure proper contact with the charging coil. ◦ Remove phone case or use a thinner, wireless charging compatible case. ◦ Ensure power adapter is connected and provides adequate power (e.g., 9V/2A or 12V/1.5A).
LED light not working.	<ul style="list-style-type: none"> ◦ Not powered on. ◦ Touch control not activated correctly. 	<ul style="list-style-type: none"> ◦ Ensure the charging station is connected to power. ◦ Lightly tap the touch control area on the base to cycle through brightness levels.
Slow charging.	<ul style="list-style-type: none"> ◦ Insufficient power input from the adapter. ◦ Device not optimally aligned. 	<ul style="list-style-type: none"> ◦ Use a Quick Charge (QC 3.0) or Power Delivery (PD) compatible adapter with at least 18W output. ◦ Re-align the device on the charging pad.

SPECIFICATIONS

Feature	Detail
Brand	VOOMY
Model Number	VOOMY 3-in-1 Wireless Charger (B0CQ5DMWTY)
Color	Black
Input Voltage	240 Volts (via USB-C)
Input Connector	USB Type C
Output Connector	USB Type A (1 port)

Feature	Detail
Wireless Charging Output	Up to 15W (Phone), 5W (Earbuds), 2.5W (Smartwatch)
Special Features	Auto-stop, Fast charging, Wireless charging, MagSafe compatible, LED Desk Lamp (3 levels), Braided cable (for included cable)
Compatible Devices	Qi-enabled smartphones (iPhone 8-15 series, Samsung Galaxy S series), Apple Watch (Ultra/SE/8/7/6/5/4), AirPods (2/3/Pro), other Qi-compatible earbuds, devices charging via USB-A.
Certifications	CE-ROHS

2.5X **Chargement plus rapide**
 Recharge de 50% en 30 minutes

Station de charge normale 5W

VOOMY Station de charge 15W



Image: A visual comparison illustrating that 15W charging is 2.5 times faster than 5W charging, reaching 50% charge in 30

minutes.

SAFETY INFORMATION

Your VOOMY 3-in-1 Wireless Charging Station is designed with multiple safety features to protect your devices and ensure safe operation.

- **Overcharge Protection:** Prevents damage to batteries from excessive charging.
- **Overvoltage Protection:** Safeguards against power surges.
- **Short-Circuit Protection:** Automatically cuts power in case of a short circuit.
- **Lightning Protection:** Offers defense against electrical spikes.
- Keep the device away from water, moisture, and high temperatures.
- Do not disassemble or attempt to repair the device yourself. Contact customer support for assistance.
- Use only the provided or a certified compatible power adapter and cable.

Sicherheit geht vor

Schützt alle Ihre Geräte



Foudre
Protection



Court-circuit
Protection



Surcharge
Protection



Surtension
Protection



Image: An infographic detailing the built-in safety mechanisms of the charging station, including protection against lightning, short-circuits, overcharging, and overvoltage.

WARRANTY AND SUPPORT

VOOMY products are designed for reliability and performance. For warranty information or technical support, please refer to the warranty card included with your purchase or visit the official VOOMY website.

If you encounter any issues not covered in this manual, please contact VOOMY customer service for assistance.