Manuals+

Q & A | Deep Search | Upload

VOLT PLUS TECH XG01

Wireless V5.3 Bluetooth Earbuds User Manual

Model: XG01

INTRODUCTION

Thank you for choosing the VOLT PLUS TECH Wireless V5.3 Bluetooth Earbuds. This manual provides detailed instructions on how to set up, operate, and maintain your new earbuds, ensuring you get the best audio experience. Please read this manual thoroughly before using the product.

WHAT'S IN THE BOX

Your package should contain the following items:

- Two (2) Wireless Bluetooth Earbuds
- One (1) Portable Charging Case
- One (1) USB-C Charging Cable
- Three (3) Pairs of Ear Adapters (Small, Medium, Large)
- One (1) User Manual



Image: The main components of the earbud set, showing the two earbuds and the open charging case.

PRODUCT FEATURES

• **Bluetooth V5.3 Technology:** Provides a stable and efficient wireless connection with low power consumption and less than 6ms response time.

- Noise Isolation: Earbuds are designed to isolate external noise, enhancing audio clarity.
- Built-in Microphones: Quad microphones ensure clear communication during calls.
- Voice and Al Notifications: Receive alerts for incoming calls, battery levels, and pairing status.
- Multi-functional Touch Controls: Intuitive touch controls on each earbud for music playback, call management, and voice assistant activation (Google, Siri, Alexa).
- Extended Battery Life: Up to 8 hours of talk time, 10+ hours of music playback, and 240 hours of standby time. The charging case provides over 24 hours of additional listening time.
- Wide Compatibility: Compatible with any Bluetooth 4.0+ enabled device, including smartphones, laptops, tablets, and other audio devices.
- **IPX6 Water Resistance:** Provides protection against strong jets of water, making them suitable for workouts and outdoor activities.



Image: An earbud comfortably placed in an ear, illustrating its compact and lightweight design for comfortable wear.

COMPATIBLE TO

IPHONE II, II PRO, II PRO MAX XS MAX, XS, XR, 8/8 PLUS, SAMSUNG GALAXY NOTE 9, NOTE 8, GALAXY SID/SID PLUS/ SIDE, LG V3DS THIN Q, LG V3D, GOOGLE PIXEL 2, PIXEL 2 XL, IPODS, IPADS, TABLETS AND OTHER WIRELESS ENABLED DEVICES



Image: The earbuds and charging case displaying the VOLT+tech logo, indicating the fast 300 mAh charging case.



Image: A visual breakdown of key earbud features, including automatic Bluetooth pairing, smooth touch controls, IPX4 sweat resistance, ergonomic lightweight design, and enhanced super bass sound.

SETUP GUIDE

1. Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the USB-C charging cable to the charging case and a power source. The indicator lights on the case will show charging status. A full charge takes approximately 1 hour for both the earbuds and the case.



Image: The charging case with an indicator showing "Up to 24 Hrs Total Playback," highlighting its extended battery life.

2. Pairing with Your Device

- 1. Power On: Remove both earbuds from the charging case. They will automatically power on, indicated by a blue light.
- 2. **Automatic Sync:** The earbuds will automatically sync with each other. Wait for the voice prompt "Pairing, Left Channel, Right Channel" to confirm they are synced.
- 3. Bluetooth Connection: Go to the Bluetooth settings on your device (smartphone, tablet, laptop).
- 4. Search for Device: Search for new devices in the Bluetooth list. You should see "XG01" or a similar name.
- 5. **Connect:** Select "XG01" to connect. Once connected, both earbuds will flash blue every 8 seconds, indicating a successful connection.

The earbuds are compatible with a wide range of devices, including Samsung Galaxy M14, Windows, iOS, Mac, and Android systems.



Image: A graphic illustrating the wide compatibility of the earbuds with various devices such as iPhones, Samsung Galaxy phones, LG phones, Google Pixel phones, iPods, iPads, and other wireless-enabled devices.

OPERATING INSTRUCTIONS

Touch Controls

The earbuds feature multi-functional touch controls on both the left and right earbuds. Refer to the table below for common operations:

Action	Function
Single Tap (Left/Right Earbud)	Play/Pause Music, Answer/End Call
Double Tap (Right Earbud)	Next Track

Action	Function
Double Tap (Left Earbud)	Previous Track
Long Press (Left/Right Earbud)	Reject Call, Activate Voice Assistant (Siri, Google Assistant, Alexa)

Making and Receiving Calls

- Answer Call: Single tap either earbud.
- End Call: Single tap either earbud during a call.
- Reject Call: Long press either earbud.

Supports one of the Largest and Widest Variety of Apps, Devices, multiple functions and applications















Image: Demonstrates the versatility of the earbuds, showing users listening to music, cycling, and answering phone calls while driving, highlighting their practical use in different daily activities.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- Ear Tips: Remove and clean the ear tips periodically with mild soap and water, then ensure they are completely dry before reattaching.
- Storage: When not in use, store the earbuds in their charging case to protect them from dust and damage.
- Avoid Extreme Conditions: Do not expose the earbuds to extreme temperatures, humidity, or direct sunlight for prolonged periods.
- Water Resistance: While IPX6 water resistant, avoid submerging the earbuds in water. Dry them thoroughly if they get wet.

TROUBLESHOOTING

Problem	Possible Solution
Earbuds not pairing with device.	Ensure earbuds are fully charged. Turn off and on Bluetooth on your device. Forget the device in your Bluetooth settings and try pairing again. Ensure earbuds are close to the device.
Only one earbud is working.	Place both earbuds back into the charging case, close the lid, wait a few seconds, then remove them. This should re-sync them. Ensure both earbuds are charged.
Low volume or poor sound quality.	Adjust volume on both your device and the earbuds. Ensure ear tips are correctly sized and sealed in your ear. Clean any debris from the earbud speakers.
Earbuds not charging.	Ensure the charging cable is securely connected to both the case and power source. Check if the charging case itself has power. Clean the charging contacts on both the earbuds and the case.

SPECIFICATIONS

Feature	Detail
Model Name	XG01
Bluetooth Version	5.3
Wireless Communication Technology	Bluetooth
Connectivity Technology	Wireless, USB-C
Noise Control	Active Noise Cancellation
Sensitivity	103 dB
Headphones Jack	USBC

Feature	Detail
Charging Time (Earbuds & Case)	1 Hour
Battery Life (Music Playback)	10+ Hours (Earbuds), 24 Hours (with Charging Case)
Standby Time	240 Hours
Carrying Case Battery Capacity	300 Milliamp Hours
Bluetooth Range	33 Feet
Water Resistance Level	Water Resistant (IPX6)
Control Method	Touch
Item Weight	4 Ounces
Product Dimensions	1 x 1 x 1 inches
Material	Aluminum, Hi Strength Plastic, Metal
Color	Black
Audio Latency	6 Milliseconds
Audio Driver Size	28 Millimeters
Impedance	25.94 Ohm

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided with your purchase documentation or visit the official VOLT PLUS TECH website. Keep your proof of purchase for any warranty claims.

Return Policy: This product typically comes with a 30-day refund/replacement return policy from the date of purchase. Please check with your retailer for specific return terms.