

[Manuals.plus](#) /

› [YOTON](#) /

› YOTON MP3 Player YM06 User Manual

YOTON YM06

YOTON MP3 Player YM06 User Manual

Model: YM06

INTRODUCTION

Thank you for choosing the YOTON MP3 Player YM06. This device is designed to provide a versatile and enjoyable multimedia experience, featuring a 4-inch full-touchscreen, Bluetooth 5.0 connectivity, HiFi lossless sound, and extensive storage capabilities. This manual will guide you through the setup, operation, and maintenance of your new MP3 player.

SAFETY INFORMATION

Please read and follow these safety guidelines to ensure proper and safe use of your device:

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the device to strong impacts.
- Do not disassemble, repair, or modify the device yourself. Refer to qualified service personnel for any repairs.
- Use only the provided USB cable for charging to prevent damage.
- Avoid listening at high volume levels for extended periods to prevent hearing damage.
- Keep the device away from water and other liquids.

PACKAGE CONTENTS

Upon opening the package, please verify that all the following items are included:

- 1x YOTON MP3 Player YM06
- 1x 64GB TF Card (pre-installed in the device)
- 1x USB Data Cable
- 1x Wired Headset
- 1x Express Guide (User Manual)




Figure 1: Contents of the YOTON MP3 Player YM06 package.

PRODUCT OVERVIEW

The YOTON MP3 Player YM06 features a sleek design with a responsive touchscreen and essential physical buttons.



Figure 2: Front and side view of the YOTON MP3 Player YM06.

Key Features:

- **4-inch Full-Touchscreen:** High-resolution display for intuitive navigation and media viewing.
- **Bluetooth 5.0:** For stable and fast wireless connections to headphones and speakers.

- **80 GB Storage:** 16GB internal memory plus a 64GB TF card, expandable up to 128GB.
- **1000mAh Battery:** Provides extended playback time for music and videos.
- **Multi-functional:** Supports music, video, FM radio, e-books, voice recording, calculator, calendar, stopwatch, and notepad.

SETUP

1. Charging the Device

Before first use, fully charge the MP3 player.

1. Connect the small end of the USB data cable to the charging port on the MP3 player.
2. Connect the larger end of the USB data cable to a USB power adapter (not included) or a computer's USB port.
3. The battery indicator on the screen will show charging status. A full charge typically takes a few hours.

Ultra Long Life Battery

Gives you plenty of time to enjoy music and films



Figure 3: The YM06 features a 1000mAh battery for extended use.

2. Inserting/Managing TF Card

The device comes with a 64GB TF card pre-installed, providing 80GB total storage (16GB internal + 64GB TF card). You can replace or upgrade the TF card up to 128GB.

1. Locate the TF card slot on the side of the device.
2. To remove, gently push the card until it clicks and ejects.
3. To insert, align the card correctly and push it into the slot until it clicks into place.



Figure 4: The YM06 offers 80GB of storage, expandable up to 128GB with a TF card.

3. Connecting to a Computer for Data Transfer

You can transfer music, videos, pictures, and e-books from your computer to the MP3 player.

1. Connect the MP3 player to your computer using the provided USB data cable.

2. The player will appear as a removable disk drive (or two drives, one for internal storage and one for the TF card) on your computer.
3. Drag and drop your desired files into the appropriate folders on the player (e.g., "Music," "Videos," "Pictures").
4. Once transfer is complete, safely eject the device from your computer before disconnecting the cable.

OPERATING INSTRUCTIONS

1. Basic Navigation

The YM06 features a full-touchscreen for most operations.

- **Power On/Off:** Press and hold the power button on the side of the device.
- **Volume Control:** Use the dedicated volume buttons on the side.
- **Touchscreen:** Tap icons to open applications, swipe to navigate menus, and use gestures as indicated on-screen.




Figure 5: The YM06's main interface showing various functions.

2. Music Playback

The player supports various audio formats including DRM, WMA, OGG, APE, FLAC, and MP3.

1. From the main menu, tap the "Music" icon.
2. You can browse music by folders, artists, albums, or all songs.
3. Tap a song to start playback.
4. Playback modes include sequential, single repeat, repeat all, and shuffle.
5. The player supports displaying high-resolution lyrics if embedded in the music file.
6. Timed playback can be set for 10/20/30/60 minutes.




Figure 6: Music playback interface with various options.

3. Video Playback

The player supports video formats such as RM, AVI, MKV, VOB, MOV, FLV, ASF, DAT, MP4, 3GP, MPG, and MPEG,

with up to 720P (1280*720) resolution.

1. From the main menu, tap the "Videos" icon.
2. Select the video you wish to play.
3. The player will automatically play the next video in the folder after the current one finishes.

4. Bluetooth Connection

Connect your Bluetooth headphones or speakers for a wireless audio experience.

1. Go to "Settings" and select "Bluetooth."
2. Turn on Bluetooth. The player will search for available devices.
3. Ensure your Bluetooth device is in pairing mode.
4. Select your device from the list to connect.



Figure 7: Stable Bluetooth 5.0 connectivity for headphones and speakers.

5. FM Radio

Listen to FM radio stations. A wired headset must be connected to act as an antenna.

1. Connect the wired headset to the 3.5mm audio jack.
2. From the main menu, tap the "Radio" icon.
3. Perform an automatic station search to find available frequencies.

6. Audio Recording

The built-in microphone allows for voice recordings saved as MP3 files.

- Tap the "Recorder" icon.
- Adjust recording quality (Low, Medium, High) and microphone sensitivity in settings.
- For best results, keep the device within 2 meters of the sound source.

7. Image Viewing

View your photos on the device.

- Tap the "Pictures" icon.
- Options include rotating images, zoom in/out, and a slideshow function (5 seconds per image).

8. E-Book Reading

The player supports reading text files (.txt).

- Tap the "E-Books" icon.
- Adjust font size (small, medium, large) for comfortable reading.

9. Other Functions

The YM06 includes several utility applications:

- **Notepad:** Create simple text notes using the on-screen keyboard.
- **Calendar:** View monthly calendars and add short notes to specific dates.
- **Calculator:** A basic calculator for arithmetic operations.
- **Stopwatch:** Includes start/stop and lap timer functions.
- **Alarm:** Set up to three alarm times with specific weekday settings.

MAINTENANCE

Proper care will extend the life of your YOTON MP3 Player.

- **Cleaning:** Use a soft, dry cloth to clean the device. Do not use liquid cleaners or aerosols.
- **Battery Care:** To preserve battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.
- **Storage:** Store the device in a cool, dry place when not in use.

TROUBLESHOOTING

Problem	Possible Cause / Solution
Device does not turn on.	Battery may be depleted. Connect to charger and try again. If still unresponsive, perform a hard reset (refer to manual for specific button combination if available, otherwise contact support).
Cannot connect via Bluetooth.	Ensure Bluetooth is enabled on both devices and they are in pairing mode. Move devices closer. Try restarting both devices.
Files not recognized or playing.	Check if the file format is supported (e.g., MP3, FLAC for audio; MP4, AVI for video). Ensure files are placed in the correct folders. Corrupted files may not play.
Automatic shutdown despite settings.	Verify power-saving settings and auto-off timers. If the issue persists, ensure firmware is up to date or contact customer support for assistance.
Audiobook files play out of order.	The player sorts files alphabetically or numerically. Rename files with sequential numbering (e.g., 001_Chapter.mp3, 002_Chapter.mp3) to ensure correct playback order. Organize into separate folders for different audiobooks.
Device does not remember last playback position for audiobooks.	This model may not support automatic bookmarking for all media types. Manually note your last position if this feature is critical for your use case.

SPECIFICATIONS

Feature	Detail
Model Number	YM06
Brand	YOTON
Dimensions	10.3 x 6.5 x 1 cm
Weight	95 Grams
Display	4-inch Full-Touchscreen, LCD, 720P (1280x720 Pixel)
Internal Storage	16 GB
Included TF Card	64 GB
Max. TF Card Support	128 GB
Battery	1000mAh Lithium-Ion (included)
Connectivity	Bluetooth 5.0, USB
Supported Audio Formats	DRM, WMA, OGG, APE, FLAC, MP3
Supported Video Formats	RM, AVI, MKV, VOB, MOV, FLV, ASF, DAT, MP4, 3GP, MPG, MPEG
Special Features	Equalizer, FM Radio, Voice Recorder, E-Book Reader (TXT), Calendar, Calculator, Stopwatch, Notepad

WARRANTY AND SUPPORT

YOTON is committed to optimizing product quality and continuously improving the user experience.

- **Customer Service:** For any questions or issues during use, please contact the YOTON team.
- **Contact Information:** You can reach us via your Amazon order number or the customer service email provided with your purchase.
- **Warranty:** YOTON offers a reliable warranty and support even after the Amazon return period. Please provide your order number and describe the issue for prompt assistance.



Figure 8: YOTON's commitment to customer support and warranty.

© 2024 YOTON. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Can the sound be turned off on the YOTON YM06 MP3 player?

Yes, the sound on the YOTON YM06 can be adjusted or effectively turned off using the following methods:Physical Volume Buttons: Use the dedicated volume buttons located on the side of the device to lower...

[Read full answer](#)