

[manuals.plus](#) /› [AKORD](#) /› [Akord 4-Drawer Commode \(Model OP0LCL4BIA001\) Instruction Manual](#)

AKORD OP0LCL4BIA001

Akord 4-Drawer Commode Instruction Manual

Model: OP0LCL4BIA001

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Akord 4-Drawer Commode. Please read these instructions carefully before beginning assembly and retain them for future reference. Proper assembly and care will ensure the longevity and functionality of your furniture. The Akord 4-Drawer Commode is designed for versatile use, suitable for bedrooms, living rooms, or hallways. Its simple design and white finish allow it to blend seamlessly with various interior styles.

2. SAFETY INFORMATION

- **Adult Assembly Required:** This product contains small parts and requires adult assembly. Keep children away during assembly.
- **Stability:** To prevent tipping, always place the commode on a flat, stable surface. If possible, secure the commode to a wall using anti-tip hardware (not included, but recommended for child safety).
- **Weight Limit:** Do not overload drawers. Distribute weight evenly.
- **Handling:** Lift the commode when moving it; do not drag, as this may damage the base or floor.
- **Ventilation:** Ensure adequate ventilation when assembling in enclosed spaces.

3. PACKAGE CONTENTS

Before assembly, verify that all parts are present and undamaged. If any parts are missing or damaged, contact customer support.

- Commode panels (top, bottom, sides, back)
- 4 Drawer fronts
- Drawer sides and backs
- Drawer bottoms
- Roller drawer slides (for commode and drawers)
- Assembly hardware (screws, dowels, cam locks, etc.)

- Assembly instructions (this document)

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is required for this Akord 4-Drawer Commode. Follow the steps below carefully. It is recommended to have a second person assist with assembly.

- 1. Prepare Workspace:** Clear a spacious, clean area. Lay out all components and hardware.
- 2. Assemble the Main Frame:**
 - Attach the side panels to the bottom panel using the provided hardware (dowels and cam locks).
 - Slide the back panel into the grooves of the side panels.
 - Secure the top panel to the assembled frame.
- 3. Install Drawer Slides:**

Attach the roller drawer slides to the inner sides of the commode frame. Ensure they are level and correctly oriented for smooth drawer operation.



Image: Close-up of the roller drawer slides installed within the commode.

- 4. Assemble Drawers:**
 - Connect the drawer sides and back to the drawer front.

- b. Slide the drawer bottom into the grooves.
- c. Attach the corresponding roller drawer slides to the assembled drawer boxes.

5. **Insert Drawers:** Carefully align the drawer slides on the drawers with the slides in the commode frame and push the drawers in until they are fully seated.

6. **Final Check:** Ensure all screws are tightened and the commode is stable. Test each drawer for smooth operation.




Image: Dimensional diagram of the commode and a drawer, showing overall height, width, depth, and internal drawer measurements.

5. OPERATING INSTRUCTIONS

The Akord 4-Drawer Commode is designed for easy and functional use.

- **Drawer Use:** The commode features four drawers equipped with roller rails for smooth opening and closing. These drawers are suitable for storing clothing, household items, or personal belongings.
- **Versatile Placement:** This commode can function as a standalone storage unit, a bedside table, or be integrated with other furniture pieces like wardrobes or display cabinets.



Image: The commode with all four drawers partially extended, showcasing the roller mechanism.

6. MAINTENANCE

To ensure the longevity and appearance of your commode, follow these maintenance guidelines:

- **Cleaning:** Wipe the commode with a damp cloth. Avoid harsh chemicals or abrasive cleaners, as

these can damage the lacquered engineered wood surface and ABS edges.

- **Dusting:** Regularly dust with a soft, dry cloth.
- **Spills:** Clean spills immediately to prevent staining or damage to the material.
- **Drawer Slides:** Periodically check drawer slides for smooth operation. If they become stiff, a small amount of silicone lubricant can be applied.
- **Hardware:** Occasionally check and tighten any loose hardware to maintain structural integrity.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	<ul style="list-style-type: none">• Misaligned drawer slides.• Obstruction in the slide mechanism.• Loose hardware on slides.	<ul style="list-style-type: none">• Re-align drawer slides.• Check for and remove any debris.• Tighten all screws on drawer slides.• Apply silicone lubricant to slides if needed.
Commode is wobbly or unstable.	<ul style="list-style-type: none">• Loose assembly hardware.• Uneven floor surface.	<ul style="list-style-type: none">• Tighten all assembly screws and cam locks.• Move the commode to a level surface or use shims under the feet.• Consider securing to a wall with anti-tip hardware.
Parts missing or damaged upon arrival.	Manufacturing or shipping error.	Contact customer support immediately for replacement parts.

8. SPECIFICATIONS

Brand:	AKORD
Model Number:	OP0LCL4BIA001
Color:	White
Product Dimensions (L x W x H):	35 x 40 x 74 cm (13.8 x 15.7 x 29.1 inches)
Item Weight:	17.3 Kilograms (38.1 lbs)
Material:	Engineered Wood
Finish Type:	Lacquered
Number of Drawers:	4
Care Instructions:	Wipe with a damp cloth



Image: The Akord 4-Drawer Commode positioned as a bedside table in a modern bedroom.

9. WARRANTY AND SUPPORT

Information regarding specific warranty terms is not provided in this manual. For warranty claims, missing parts, or further assistance, please contact the retailer or manufacturer directly with your purchase details and model number (OP0LCL4BIA001).

Please refer to your purchase receipt or the product listing for specific warranty duration and contact information.

