

aiprotabket K12

aiprotabket K12 10-inch Android 13 Tablet User Manual

Model: K12

1. PRODUCT OVERVIEW

The aiprotabket K12 is a versatile 10-inch Android 13 tablet designed for productivity and entertainment. It features an 8GB RAM, 128GB ROM (expandable up to 1TB), a 1280x800 IPS display, and a 2.0GHz Quad-Core processor. This 2-in-1 tablet comes with a detachable keyboard and a stylus, enhancing its functionality for various tasks.

Key features include:

- **Operating System:** Android 13.0
- **Processor:** 2.0GHz Quad-Core
- **Memory:** 8GB RAM + 128GB ROM (expandable up to 1TB via microSD card)
- **Display:** 10.1-inch IPS, 1280x800 resolution
- **Connectivity:** Wi-Fi 6 (2.4G/5G), Bluetooth 5.0
- **Battery:** 6000mAh Li-Ion
- **Cameras:** 2MP Front, 5MP Rear
- **Accessories:** Includes 2-in-1 keyboard case, stylus, power adapter, and screen protector.

2. SETUP GUIDE

2.1 Unboxing and Initial Inspection

Carefully remove all components from the packaging. Ensure the following items are present:

- aiprotabket K12 Tablet
- 2-in-1 Keyboard Case
- Power Adapter
- Stylus
- Screen Protector (pre-applied or separate)
- User Manual (this document)

Inspect all items for any signs of damage. If any components are missing or damaged, please contact customer

support.

2.2 Charging the Tablet

Before first use, fully charge the tablet. Connect the provided power adapter to the tablet's USB Type-C port and plug it into a power outlet. The charging indicator will typically illuminate during charging.

2.3 Powering On/Off

- **To Power On:** Press and hold the Power button (usually located on the side) for a few seconds until the aiprotablet logo appears.
- **To Power Off:** Press and hold the Power button until a power-off menu appears on the screen. Select "Power off" and confirm.
- **To Restart:** From the power-off menu, select "Restart."

2.4 Connecting the Keyboard

The 2-in-1 keyboard connects via Bluetooth. Follow these steps:

1. Ensure the keyboard is charged (if it has a separate battery) and powered on.
2. On your K12 tablet, go to **Settings > Connected devices > Bluetooth**.
3. Turn Bluetooth **On**.
4. The tablet will search for available devices. Select the keyboard from the list (it may appear as "Bluetooth Keyboard" or a similar name).
5. If prompted, enter the pairing code displayed on the tablet screen into the keyboard and press **Enter**.
6. Once paired, the keyboard status will show as "Connected."

2.4G/5G WIFI 6

2 in 1 Foldable Case and Bluetooth 5.0 keyboard



Image: The aiprotab K12 tablet connected to its 2-in-1 foldable case and Bluetooth 5.0 keyboard, highlighting its wireless capabilities.

Android 13 OS

GMS-certified Android 13 tablet with more features and privacy security and faster fluidity.



Image: The aiprotab K12 tablet with its keyboard, showcasing the Android 13 OS during a video call, demonstrating its functionality for communication.

2.5 Connecting the Stylus

The stylus typically does not require Bluetooth pairing for basic touch input. Simply use it directly on the screen. If your stylus has advanced features requiring pairing, refer to the stylus's specific instructions. For general use, the stylus functions as a precise input tool for drawing, writing, and navigation.

2.6 Wi-Fi Setup

1. Go to **Settings > Network & internet > Internet**.
2. Turn Wi-Fi **On**.
3. Select your desired Wi-Fi network from the list.
4. Enter the network password if prompted and tap **Connect**.

3. OPERATING INSTRUCTIONS

3.1 Basic Navigation (Android 13)

- **Home Screen:** Swipe left or right to navigate between home screens.
- **App Drawer:** Swipe up from the bottom of the screen to access all installed applications.
- **Notifications & Quick Settings:** Swipe down from the top of the screen to view notifications and access quick settings toggles (Wi-Fi, Bluetooth, Brightness, etc.).
- **Back:** Tap the back arrow icon or swipe from the left/right edge (depending on navigation settings) to go back to the previous screen.
- **Recent Apps:** Swipe up from the bottom and hold, then release, to view recently opened applications.

3.2 Using the Keyboard

Once connected, the keyboard functions like a standard computer keyboard. You can use it for typing, navigating menus with arrow keys, and using shortcuts. Some common shortcuts include:

- **Ctrl + C:** Copy
- **Ctrl + V:** Paste
- **Ctrl + X:** Cut
- **Ctrl + Z:** Undo
- **Alt + Tab:** Switch between recent apps

3.3 Using the Stylus

The stylus provides a more precise input method than finger touch. It is ideal for:

- Drawing and sketching in compatible applications.
- Handwriting notes.
- Precise selection and editing of text or images.
- Navigating small interface elements.



Image: The aiprotab K12 tablet being used with its stylus to interact with a recipe application, demonstrating precise input capabilities.

3.4 Camera Usage

The tablet is equipped with a 2MP front camera and a 5MP rear camera. To use the camera:

1. Open the **Camera** application.
2. Tap the camera icon to switch between front and rear cameras.
3. Tap the shutter button to take a photo or start/stop video recording.
4. Access various modes (e.g., Photo, Video, Panorama) from the camera interface.

3.5 Storage Expansion

The tablet supports storage expansion up to 1TB using a microSD card. Locate the microSD card slot (usually on the side of the tablet), insert the card gently until it clicks into place. The tablet will recognize the new storage, which can be used for photos, videos, documents, and some applications.

8GB RAM + 128GB ROM

Max 1TB Expand



Image: The aiprotab K12 tablet showcasing various applications, representing its 8GB RAM, 128GB ROM, and the potential for 1TB expandable storage.

4. MAINTENANCE

4.1 Cleaning the Tablet and Accessories

- Use a soft, lint-free cloth (e.g., microfiber cloth) to clean the screen and body of the tablet.
- For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution. Avoid harsh chemicals.
- Clean the keyboard keys and stylus tip with a dry, soft cloth.
- Keep ports free of dust and debris.

4.2 Battery Care

The K12 tablet has a 6000mAh battery. To maximize battery life and longevity:

- Avoid extreme temperatures (hot or cold).

- Do not let the battery completely drain frequently.
- Avoid leaving the tablet plugged in for extended periods after it's fully charged.
- Use the provided power adapter for optimal charging.

6000mAh Long Lasting Battery

Type-C Fast Charge



 **16H**
Music

 **7H**
Web

 **6H**
Video

 **500H**
Standby

Image: An internal view diagram of the aiprotab K12 tablet, highlighting its 6000mAh long-lasting battery and Type-C fast charge capability.

4.3 Software Updates

Periodically check for system updates to ensure optimal performance and security. Go to **Settings > System > System update** to check for and install available updates.

5. TROUBLESHOOTING

5.1 Tablet Not Powering On

- Ensure the tablet is sufficiently charged. Connect it to the power adapter and wait a few minutes before attempting to power on again.

- Press and hold the Power button for 10-15 seconds to perform a forced restart.

5.2 Keyboard Not Connecting

- Ensure the keyboard is powered on and has sufficient battery.
- Verify Bluetooth is enabled on the tablet (**Settings > Connected devices > Bluetooth**).
- Forget the keyboard from the tablet's Bluetooth settings and attempt to pair it again (refer to Section 2.4).
- Restart both the tablet and the keyboard.
- Ensure the keyboard is within range of the tablet.

5.3 Wi-Fi Connection Issues

- Ensure Wi-Fi is enabled on the tablet.
- Check if other devices can connect to the same Wi-Fi network.
- Restart your Wi-Fi router.
- Forget the Wi-Fi network on your tablet and reconnect.
- Ensure you are entering the correct password.

5.4 Slow Performance

- Close unnecessary background applications.
- Clear cache data for frequently used apps (**Settings > Apps > Select App > Storage & cache > Clear cache**).
- Ensure you have sufficient free storage space. Consider moving large files to a microSD card or deleting unused apps.
- Restart the tablet.

6. SPECIFICATIONS

High Quality Display



10.1"
HD Screen

1280*800
FHD Resolution

16:10
Aspect ratio

Incell
Multi touch

Image: The aiprotab K12 tablet showcasing its high-quality 10.1-inch HD IPS display with 1280x800 resolution and 16:10 aspect ratio.

Feature	Specification
Brand	aiprotab K12
Model Name	K12
Operating System	Android 13
Processor	2.0GHz Quad-Core (Unisoc ARM Cortex RK3562)
RAM	8 GB
Internal Storage	128 GB
Expandable Storage	Up to 1 TB (microSD)
Screen Size	10.1 Inches

Display Resolution	1280x800 Pixels (IPS LCD)
Wi-Fi	2.4G/5G Wi-Fi 6
Bluetooth	5.0
Battery Capacity	6000mAh Lithium Polymer
Battery Life (Average)	6 Hours
Front Camera	2 MP
Rear Camera	5 MP
Charging Port	USB Type-C
Audio Jack	3.5 mm
Included Components	K12 Tablet, Keyboard Case, Power Adapter, Stylus

7. WARRANTY AND SUPPORT

Your aiprotab^{le}t K12 tablet is backed by a comprehensive warranty and dedicated customer support:

- **Return Policy:** 90-day extended return period.
- **Warranty:** 1-year limited warranty from the date of purchase.
- **Customer Service:** 7x24 customer service support team available to assist with any issues or questions you may encounter during use.

For warranty claims, technical assistance, or any product-related inquiries, please contact our customer support team through the contact information provided with your purchase or on the official aiprotab^{le}t website.

© 2024 aiprotab^{le}t. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question