

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

> [Vibemo](#) /

> Vibemo 10x10ft Beach Tent Sun Shade with UPF50+ UV Protection Instruction Manual

### Vibemo VB-SS01

# Vibemo 10x10ft Beach Tent Sun Shade Instruction Manual

Model: VB-SS01

## 1. INTRODUCTION

Thank you for choosing the Vibemo 10x10ft Beach Tent Sun Shade. This manual provides essential instructions for the proper setup, use, and maintenance of your sun shelter. Designed for ease of use and optimal sun protection, this tent is ideal for beaches, parks, camping, and backyard activities.



*Image: Vibemo 10x10ft Beach Tent Sun Shade providing ample shade on a sunny beach.*

## 2. PACKAGE CONTENTS

Please verify that all components are present before assembly:

- 1 x Carry Bag
- 1 x Beach Tent Fabric (10x10ft)
- 4 x Support Poles
- 4 x Bungee Cord Ties
- 2 x Sand Shovels
- 8 x Grass Pegs



*Image: Visual representation of all items included in the package.*

## 3. SETUP INSTRUCTIONS

Follow these steps for a quick and easy setup:


1. **Lay out the Tent:** Spread the beach tent fabric flat on your desired location.
2. **Fill Sandbags:** Fill all 8 sandbags (located at each corner and mid-point of the tent edges) with sand until they overflow. This ensures maximum stability. For grass, use the provided grass pegs.
3. **Assemble Poles:** Connect the sections of the support poles. The poles feature internal elastic cords for easy assembly.
4. **Position Poles:** Place 2 to 4 assembled poles under the tent, depending on the desired shade area and group size. Position the poles to create the desired height and angle for optimal shade.
5. **Secure Poles:** Tie the elastic cord from the tent fabric around the ball at the top of each pole. Ensure the fabric is taut.
6. **Adjust for Stability:** Continuously adjust the tension of the fabric and the angle of the poles to ensure stability, especially in windy conditions. Lean poles into the wind for better resistance.

## How to Set Up the Beach Pop Up Tent?

1 Lay out your tent



4 Insert the poles into the sand



2 Fill the sandbags with sand, or set in place with grass pegs



5 Dig a deep hole and bury the sandbag in the sand



3 Unfold poles, prop 2-4 under the tent depending on group size and tie the ball



6 Sit back, relax and enjoy the shade



*Image: Visual guide for setting up the Vibemo Beach Tent.*

### Setup Video

Your browser does not support the video tag. Please update your browser to view this content.

*Video: Official guide from VIBEMO Direct demonstrating how to set up the beach tent.*

## 4. USAGE GUIDELINES

- The 10x10ft size can accommodate up to 8 people, making it suitable for various outdoor activities.
- The high-stretch Lycra fabric provides UPF 50+ sun protection, shielding you from harmful UV rays.
- Utilize the 8 sandbags for enhanced stability, especially in windy conditions. For grass, use the provided pegs.
- The lightweight design (8.1 lbs) and travel bag make it easy to transport.

## 7 Points to Get A Stable Shelter



*Image: The versatile Vibemo Beach Tent in various outdoor settings.*

## 5. MAINTENANCE

- After each use, shake off any sand or debris from the tent fabric and poles.
- If cleaning is necessary, hand wash the fabric with mild soap and water. For deeper cleaning, some users have successfully machine washed on a delicate cycle with mild detergent. Always air dry completely before storing to prevent mildew.
- Store the tent and all components in the provided carry bag in a cool, dry place.
- Inspect poles and fabric for any damage before and after each use.

## 6. TROUBLESHOOTING

### Tent Instability in Wind:

- Ensure all 8 sandbags are completely filled and buried or secured with grass pegs.
- Angle the support poles into the direction of the wind to increase resistance.
- Adjust the tension of the fabric by repositioning the sandbags further out or closer in, creating a tighter canopy.



Image: Tips for achieving maximum stability for your beach tent.

### Difficulty Assembling Poles:

- The poles are designed with internal elastic cords for easy connection. Ensure each section is fully inserted into the next.
- If a pole is stuck, gently twist and pull. Avoid excessive force.

## 7. SPECIFICATIONS

Feature	Detail
Brand	Vibemo

Model Number	VB-SS01
Material	Lycra Fabric, Aluminum Poles
Color	Navy Blue
Dimensions	120"L x 120"W x 78"H (10ft x 10ft x 6.5ft)
Item Weight	8.1 lbs
UV Protection	UPF50+
Water Resistance Level	Not Water Resistant (fabric allows water to pass through)
Included Accessories	8 Sandbags, 4 Stability Poles, 2 Sand Shovels, 8 Grass Pegs, Carry Bag

## 8. SAFETY INFORMATION

### WARNING:

- Always follow the instructions provided with the product for proper setup and usage.
- Ensure the product is securely anchored and stable before use.
- Do not use in high winds or during severe weather conditions.
- Do not use this beach canopy as a permanent shelter.
- Do not use this beach canopy on steep inclines.
- Keep all flame and heat sources away from this canopy fabric.

## 9. WARRANTY AND SUPPORT

For any questions, concerns, or support needs regarding your Vibemo Beach Tent Sun Shade, please refer to the contact information provided at the point of purchase or visit the official Vibemo website. Please retain your proof of purchase for any warranty claims.