

TRALT TRALT+TRALT+YX001-2

TRALT Office Chair Instruction Manual

Model: TRALT+TRALT+YX001-2

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- Do not exceed the maximum weight capacity of **330 lbs**.
- Ensure proper assembly for safe use. Follow all assembly steps precisely.
- Use the chair only on **hard floor surfaces** to ensure smooth and silent wheel operation and prevent damage.
- Avoid standing on the chair or using it as a step stool.
- Keep children and pets away during assembly.

2. PRODUCT OVERVIEW

The TRALT Ergonomic Office Chair is designed to provide comprehensive support and comfort for extended periods of sitting. Featuring adjustable lumbar support, breathable mesh, and a sturdy construction, it is an ideal choice for home and office environments.



Figure 2.1: TRALT Ergonomic Office Chair (Black)

3. COMPONENTS LIST

Before assembly, please ensure all components are present and undamaged. Refer to the diagram below for identification.



Figure 3.1: Core Accessories for Safety and Comfort

- Seat Cushion (with integrated controls)
- Backrest (with mesh fabric and lumbar support mechanism)
- Armrests (pair, flip-up adjustable)
- Gas Lift Cylinder (SGS certified Level 3)
- Star Base (5-point metal base)
- Casters (silent rolling wheels)
- Assembly Hardware (screws, washers, Allen key)

4. SETUP AND ASSEMBLY

Assembly of the TRALT Office Chair is designed to be straightforward. Typically, assembly can be completed within 20-30 minutes by one person.

1. Unpack all components and verify against the components list.

2. Attach the casters to the star base by pushing them firmly into the holes.
3. Insert the gas lift cylinder into the center hole of the star base.
4. Attach the seat mechanism to the underside of the seat cushion using the provided screws.
5. Carefully place the assembled seat onto the gas lift cylinder.
6. Attach the backrest to the seat mechanism using the remaining screws.
7. Ensure all screws are tightened securely before use.

For detailed visual instructions, please refer to the assembly diagram included in your product packaging.

5. OPERATING INSTRUCTIONS

The TRALT Office Chair offers several adjustable features to customize your seating experience for optimal comfort and support.

5.1. Seat Height Adjustment

To adjust the seat height, locate the lever on the right side beneath the seat. While seated, pull the lever up to lower the seat. To raise the seat, stand up slightly and pull the lever up. Release the lever at the desired height.

5.2. Recline Function and Tilt Lock

The chair features a unique recline function allowing you to tilt the backrest between 90° and 120°.

- To recline, lean back gently. The chair will tilt back.
- To lock the recline position, push the lever on the left side (often labeled "KNEE LOCK" or similar) downwards.
- To unlock and allow recline, pull the lever upwards.

90° Flip-up Armrest

Saving space for more freedom




Figure 5.1: 90° Flip-up Armrest and Tension Knob

5.3. Lumbar Support Adjustment

The chair includes adaptable lumbar support to protect your spine and lower back. This can be adjusted to provide optimal comfort.

Adaptable Lumbar Support

Protect your spine and lower back



Figure 5.2: Adaptable Lumbar Support Adjustment

To adjust the lumbar support, locate the knob on the side of the backrest. Rotate the knob to extend or retract the lumbar support to your preferred position.

5.4. Armrest Adjustment

The armrests feature a 90° flip-up design, allowing for space-saving and increased freedom of movement.

- To flip up the armrests, simply lift them upwards until they lock into the vertical position.
- To lower them, gently pull them down.

The armrests also offer vertical adjustment. Locate the button or lever on the side of the armrest support. Press it and slide the armrest up or down to the desired height, then release to lock.

5.5. Tilt Tension Adjustment

The base knob beneath the seat adjusts the tension of the seat back, controlling how easily the chair reclines.

- Turn the knob clockwise to increase tension (making it harder to recline).

- Turn the knob counter-clockwise to decrease tension (making it easier to recline).

6. MAINTENANCE

Regular maintenance will prolong the life and appearance of your TRALT Office Chair.

- **Cleaning:** Wipe mesh and fabric surfaces with a damp cloth and mild soap. Avoid harsh chemicals. For the metal base, use a soft, dry cloth.
- **Casters:** Periodically check casters for hair or debris and clean as needed to ensure smooth rolling.
- **Hardware:** Every 6 months, check all screws and bolts to ensure they are tight. Re-tighten if necessary.
- **Storage:** Store the chair in a cool, dry place away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

If you encounter any issues with your TRALT Office Chair, refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Chair does not raise/lower	Gas lift cylinder malfunction or lever not engaged.	Ensure the height adjustment lever is fully engaged. If issue persists, the gas lift may need replacement.
Chair wobbles or feels unstable	Loose screws or uneven assembly.	Check and tighten all assembly screws. Ensure the chair is on a flat, even surface.
Casters not rolling smoothly	Debris (hair, lint) caught in casters or damaged casters.	Clean casters thoroughly. If damaged, consider replacing them.
Backrest does not recline or lock	Tilt lock engaged or tension too high.	Disengage the tilt lock. Adjust the tilt tension knob counter-clockwise to loosen.

If you are unable to resolve an issue using these tips, please contact TRALT customer support.

8. SPECIFICATIONS

Brand	TRALT
Model Number	TRALT+TRALT+YX001-2
Color	Black
Product Dimensions (D x W x H)	28.4" x 28.4" x 38.2"
Maximum Weight Recommendation	330 Pounds
Back Style	Mesh Back
Arm Style	Adjustable Flip-up Armrests
Seat Height	21.7 Inches
Fill Material	Foam
Surface Recommendation	Hard Floor

Reclining Position Count	2 (90° to 120°)
Item Weight	28 pounds
Date First Available	August 22, 2023

Product dimensions



Figure 8.1: Product Dimensions and Weight Capacity

9. WARRANTY AND SUPPORT

TRALT stands behind the quality of its products. For warranty information, technical support, or to order replacement parts, please contact our customer service team:

- **Website:** Visit the [TRALT Store on Amazon](#)
- **Email:** support@tralt.com (Example email, replace if actual contact info is available)
- **Phone:** 1-800-XXX-XXXX (Example phone, replace if actual contact info is available)

Please have your model number (TRALT+TRALT+YX001-2) and purchase date ready when contacting support.

© 2023 TRALT. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question