

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Lang](#) /

› [LANG Abundant Friendship™ 2025 Wall Calendar Instruction Manual](#)

**Lang 25991002005**

# LANG Abundant Friendship™ 2025 Wall Calendar Instruction Manual

Model: 25991002005

## INTRODUCTION

This manual provides essential information for the proper use and care of your LANG Abundant Friendship™ 2025 Wall Calendar. This calendar features beautiful artwork by Nicole Tamarin, showcasing flowers and birds with uplifting scripture quotes for each month. Designed for durability and aesthetic appeal, it includes full-color images, elegant linen-embossed paper, and a brass grommet for secure hanging.

## PRODUCT FEATURES

- **12 Full-Color Images:** Features unique artwork for each month from January to December 2025.
- **Elegant Linen-Embossed Paper Stock:** Provides a premium look and feel.
- **Brass Hanging Grommet:** Reinforces the hanging hole to prevent tearing and ensure longevity.
- **Matching Linen-Embossed Gift Jacket:** Ideal for gifting and protection.
- **12-Month Desktop Wallpaper Download:** Access to digital artwork for your devices.

## SETUP AND INSTALLATION

1. **Unpack the Calendar:** Carefully remove the calendar from its packaging and the matching gift jacket.
2. **Select a Location:** Choose a suitable wall space for hanging. Ensure the location is dry and away from direct sunlight or excessive humidity to preserve the calendar's quality.
3. **Prepare Hanging Point:** Use a nail, hook, or thumbtack securely fastened into the wall.
4. **Hang the Calendar:** Align the brass grommet at the top of the calendar with your chosen hanging point and carefully place it. The grommet is designed to prevent tearing.

5. **Adjust for Viewing:** Ensure the calendar hangs flat and is easily visible for daily use.




Image: The LANG Abundant Friendship 2025 Wall Calendar displayed on a wall, illustrating how it appears when hung in a living space.



Image: The calendar being placed into a decorative wooden frame, demonstrating an alternative display method.

## OPERATING INSTRUCTIONS

- Monthly Progression:** At the beginning of each month, gently turn the page to reveal the new month's artwork and calendar grid.
- Date Marking:** Use a pen or pencil to mark important dates, appointments, and events directly on the calendar grid. The linen-embossed paper is designed to accept various writing instruments.
- Artwork Enjoyment:** Take time to appreciate the unique full-color artwork and uplifting quotes provided for each month.
- Desktop Wallpaper:** Utilize the included 12-month desktop wallpaper download to extend the calendar's aesthetic to your digital devices. Instructions for download are typically found on the calendar's packaging or an insert.



FILL THE WORLD  
WITH

Kindness

January  
2025

SUNDAY	MONDAY	TUESDAY	WEDNESDAY	THURSDAY	FRIDAY	SATURDAY
<b>December 2024</b> S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31	<b>February 2025</b> S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28		1 New Year's Day	2 Day After New Year's Day (NZL)	3	4
5	6 Epiphany	7	8	9	10	11
12	13 Coming of Age Day (JPN)	14	15	16	17	18
19	20	21	22	23	24	25
26	27	28	29	30	31	



Image: A detailed view of the January 2025 calendar page, highlighting the monthly artwork and the spacious date squares for writing.

## CARE AND MAINTENANCE

- Handling:** Handle the calendar by its edges to avoid creasing or smudging the artwork and pages.
- Cleaning:** If necessary, gently wipe the surface with a clean, dry, soft cloth. Avoid using liquid cleaners or abrasive materials.
- Storage:** If storing the calendar before or after use, keep it flat in a cool, dry place, ideally in its original gift jacket or a protective sleeve, to prevent damage.
- Environmental Conditions:** Protect the calendar from direct sunlight, extreme temperatures, and high humidity, which can cause fading, warping, or damage to the paper.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Calendar not hanging straight.	Uneven hanging point or improper alignment.	Ensure the nail/hook is level. Re-align the brass grommet evenly on the hanging point.
Pages appear warped or faded.	Exposure to humidity, direct sunlight, or extreme temperatures.	Relocate the calendar to a dry area away from direct sunlight and heat sources.
Difficulty writing on pages.	Using an incompatible pen type (e.g., gel pens that smudge easily).	Use a ballpoint pen or pencil for best results on the linen-embossed paper. Allow ink to dry before touching.

## PRODUCT SPECIFICATIONS

**Brand:** Lang

**Model Number:** 25991002005

**Product Dimensions:** 13.4 x 13.4 x 0.1 inches (when closed)

**Item Weight:** 13.3 ounces

**Material:** Linen-embossed paper stock, brass grommet


**Calendar Duration:** January - December 2025 (12 months)

**Manufacturer:** The Lang Companies, Inc.

**UPC:** 726225136736

13.375"

24"



SUNDAY	MONDAY	TUESDAY	WEDNESDAY	THURSDAY	FRIDAY	SATURDAY
<b>December 2024</b> S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31	<b>February 2025</b> S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28		1 New Year's Day	2 Day After New Year's Day (NL)	3	4
5	6 Epiphany	7	8	9	10	11
12	13 Coming of Age Day (JP)	14 °	15	16	17	18
19	20	21 °	22	23	24	25



Image: A visual representation of the calendar's dimensions, showing its open size of 13.375 inches wide by 24 inches high.

## WARRANTY AND SUPPORT

For any questions regarding your LANG Abundant Friendship™ 2025 Wall Calendar, please refer to the manufacturer's official website or contact their customer support. Information regarding specific warranty terms, if applicable, can typically be found on the product packaging or the manufacturer's website.

Manufacturer: [The Lang Companies, Inc.](#)

© 2025 Lang. All rights reserved.