

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Actualia](#) /
- › [Actualia TRIMUI Smart PRO Handheld Game Console User Manual](#)

Actualia TRIMUI Smart PRO

Actualia TRIMUI Smart PRO Handheld Game Console User Manual

Model: TRIMUI Smart PRO

[Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Support](#)

INTRODUCTION

This manual provides essential instructions for setting up, operating, and maintaining your Actualia TRIMUI Smart PRO handheld game console. Please read this manual thoroughly before using the device to ensure proper function and longevity.




Image: Front view of the TRIMUI Smart PRO handheld game console.

1. SETUP

1.1 Package Contents

Verify that all items are present in the package:

- TRIMUI Smart PRO Game Console x 1
- Charging Cable x 1
- External Game Card x 1 (Pre-installed 256GB SD card)
- User Manual x 1 (This document)



Image: The TRIMUI Smart PRO console with its screen showing game details and storage capacity.

1.2 Charging the Device

Before initial use, fully charge the console. Connect the provided charging cable to the console's charging port and a compatible USB power adapter (not included). The charging indicator will illuminate.

- **Charging Time:** Approximately 3-4 hours for a full charge.
- **Battery Life:** Up to 5 hours of gameplay on a full charge.

1.3 Inserting the SD Card

The console comes with a pre-installed 256GB SD card. If you need to remove or re-insert it:

1. Locate the SD card slot on the side of the console.
2. Gently push the SD card until it clicks into place. To remove, push again until it springs out.

Caution: Ensure the console is powered off before inserting or removing the SD card to prevent data corruption.

1.4 Initial Power On

Press and hold the **Power** button (located on the side) for a few seconds until the screen illuminates and the system boots up.



Image: Side view of the console, highlighting the power button and USB-C port.

2. OPERATION

2.1 Basic Controls

Familiarize yourself with the console's buttons and controls:

- **D-Pad:** Directional input for navigation and gameplay.
- **Analog Joysticks:** Precise directional control.
- **A/B/X/Y Buttons:** Action buttons for gameplay.
- **L1/L2/R1/R2 Shoulder Buttons:** Additional action buttons.
- **START/SELECT Buttons:** Game-specific functions, often for pausing or menu access.
- **MENU Button:** Access system menu or in-game options.



Image: Close-up of the right-hand controls, including action buttons and analog stick.



Image: Close-up of the left-hand controls, including the D-pad and analog stick.

2.2 Navigating the Interface

Use the D-Pad or analog joysticks to move between menu options. Press the **A** button to select an option and the **B** button to go back.

2.3 Playing Games

1. From the main menu, navigate to the desired game emulator or game list.
2. Select a game from the list to launch it.
3. During gameplay, you can typically press the **MENU** button to access in-game options, such as saving or loading game states.
4. To save your progress, use the in-game save feature or the console's quick save/load function (if available via the system menu).
5. To exit a game, access the system menu (usually via the **MENU** button) and select the "Exit Game" option.

2.4 WiFi Connectivity and Multiplayer

The TRIMUI Smart PRO supports WiFi for online features and multiplayer gaming.

1. Go to **System Settings** and select **WiFi**.
2. Choose your desired network and enter the password if prompted.
3. Once connected, you can engage in WiFi multiplayer battles with compatible games or download additional games in supported formats.

The console also supports connecting two external controllers for local multiplayer. Refer to the system settings for controller pairing instructions.

2.5 System Settings

Access the system settings to customize various aspects of your console, including:

- Screen brightness and display options
- Audio volume
- WiFi settings
- Controller mapping
- Language settings
- System information and updates

3. MAINTENANCE

3.1 Cleaning

To clean the console, use a soft, dry cloth. For stubborn marks, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.

- Do not spray cleaning solutions directly onto the device.
- Keep the device away from excessive dust and moisture.

3.2 Battery Care

The console contains a built-in 5000mAh lithium battery. To prolong battery life:

- Avoid fully discharging the battery frequently.
- Store the device in a cool, dry place when not in use for extended periods.
- If the device will not be used for a long time, charge it to about 50% before storing.

3.3 Software Updates

Periodically check for system software updates through the console's settings menu (if available). Updates can improve performance, add features, and fix bugs.

4. TROUBLESHOOTING

Problem	Possible Cause	Solution
Console does not power on.	Low battery; System crash.	Charge the console for at least 30 minutes. If unresponsive, perform a hard reset by holding the power button for 10-15 seconds.

Problem	Possible Cause	Solution
Games are missing or corrupted.	SD card issues; Accidental deletion.	Ensure the SD card is properly inserted. If issues persist, the SD card may be corrupted and require reformatting or replacement. Back up important data regularly.
Battery drains quickly.	High screen brightness; WiFi active; Background processes.	Reduce screen brightness. Turn off WiFi when not in use. Close background applications. If the issue persists after power-off, consult support.
Controls are unresponsive or incorrect.	Incorrect game settings; Hardware issue.	Check in-game control settings. Verify system-wide controller mapping in settings. Restart the console.
Cannot connect to WiFi.	Incorrect password; Out of range; Router issue.	Double-check WiFi password. Move closer to the WiFi router. Restart your router.







5. SPECIFICATIONS

Feature	Detail
Model	TRIMUI Smart PRO
Screen Size	4.96 Inches IPS
Processor	Allwinner A133P (A133 Plus) 1.8GHz
Operating System	Linux System
Memory Storage	256 GB (via SD Card)
Battery	5000mAh Lithium Battery
Battery Life	Up to 5 Hours
Connectivity	WiFi, External Controller Support
Dimensions	7.08 x 3.14 x 0.66 inches
Weight	15.4 ounces
Material	Glass + ABS + Electronic Components

6. WARRANTY AND SUPPORT

For technical assistance, warranty information, or further inquiries, please contact Actualia customer support through the retailer where the product was purchased or visit the official Actualia website. Please retain your proof of purchase for warranty claims.

Related Documents - TRIMUI Smart PRO

	<p>TRIMUI BRICK TG3040 Handheld Game Console Instruction Manual</p> <p>Comprehensive instruction manual for the TRIMUI BRICK TG3040 handheld game console, covering UI operation, SD card setup, firmware updates, hotkeys, Wi-Fi connection, language settings, USB data transfer, and charging.</p>
	<p>TRIMUI SMART PRO Handheld Game Console: Operation Guide</p> <p>Explore the TRIMUI SMART PRO handheld game console with this comprehensive guide. Learn about setup, game management, netplay, firmware updates, and essential hotkeys for an enhanced gaming experience.</p>
	<p>TRIMUI SMART PRO Instruction Manual</p> <p>Comprehensive user guide for the TRIMUI SMART PRO handheld game console, detailing device operation, game management, network play, firmware updates, hardware features, and charging instructions.</p>
	<p>BOYHOM R43 Pro Handheld Game Console Instruction Manual</p> <p>Official instruction manual for the BOYHOM R43 Pro handheld retro video game console, covering appearance, hardware, functions, warranty, and safety warnings. Features open-source Linux system and TF card expansion.</p>
	<p>Trimui TG5040 Smart Pro Handheld Game Console Instruction Manual</p> <p>Instruction manual for the Trimui TG5040 Smart Pro handheld game console, covering unit overview, usage instructions, netplay setup, unit details, FCC warnings, and specifications.</p>
	<p>M15 Game Stick Pro: Instruction Manual and Hardware Specifications</p> <p>Comprehensive guide to the M15 Game Stick Pro, covering appearance, hardware functions, usage instructions, warranty information, and safety precautions. Supports multiple languages.</p>