Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- TOPK /
- > TOPK USB Desk Fan K51 Instruction Manual

TOPK K51

TOPK USB Desk Fan K51 Instruction Manual

Model: K51 | Brand: TOPK

1. Introduction

Thank you for choosing the TOPK USB Desk Fan K51. This portable mini fan is designed to provide personal cooling with strong airflow and quiet operation. It features three-speed settings, 360° rotation, and is conveniently powered via USB, making it ideal for various environments such as home, office, or on the go.



Figure 1: TOPK USB Desk Fan K51 (2-Pack)

2. SAFETY INFORMATION

- Ensure the fan is placed on a stable, flat surface to prevent tipping.
- Keep fingers and other objects away from the fan blades during operation.
- Do not immerse the fan in water or expose it to excessive moisture.
- Use only with a 5V USB power source.
- Unplug the fan when not in use or before cleaning.
- Keep out of reach of children.

3. PACKAGE CONTENTS

- 2 x TOPK USB Desk Fan K51 (Black)
- Integrated 1.2-meter USB cable (non-removable)

4. PRODUCT FEATURES

• Compact Design: Measuring 12x12x5.5 cm (4.7"x4.7"x2") and weighing 0.35 lbs, it is space-saving and portable.


- Three-Speed Settings: Adjustable wind speeds for personalized comfort (Low: 3.9m/s, Medium: 4.9m/s, High: 5.9m/s).
- 360° Rotatable Head: Allows for flexible direction of airflow.
- **USB Powered:** Compatible with any 5V USB output device (PC, laptop, power bank, USB wall charger, car charger).
- Quiet Operation: Equipped with a brushless motor and curved blades for low noise levels (40-50dB at highest speed).
- Stable Base: Features 2 anti-slip rubbers on the bottom to reduce vibration and prevent sliding.

Quality Upgraded

High-Speed Cooling Experience







Flame-Retardant Material





Figure 2: Key Features of the TOPK USB Desk Fan

360° Rotation

Enjoy the Freedom of Airflow



Figure 3: 360° Rotatable Design

5. SETUP

- 1. Placement: Place the fan on a stable, flat surface where you desire airflow.
- 2. **Power Connection:** Connect the integrated USB cable to a compatible 5V USB power source, such as a computer, laptop, power bank, or USB wall charger.




Figure 4: USB Power Connection

6. OPERATING INSTRUCTIONS

- 1. **Power On/Speed Adjustment:** Locate the push button on the back of the fan. Press the button repeatedly to cycle through the three-speed settings (Low, Medium, High) and to turn the fan off.
- 2. **Adjusting Airflow Direction:** Manually rotate the fan head 360 degrees vertically to direct the airflow to your desired angle.

Your browser does not support the video tag. Please update your browser.

7. MAINTENANCE

- Cleaning: Ensure the fan is unplugged before cleaning. Use a soft, dry cloth to wipe the exterior surfaces. For dust accumulation on the blades, use a duster or compressed air. Do not use liquid cleaners or abrasive materials.
- Storage: When not in use, store the fan in a cool, dry place away from direct sunlight.

8. TROUBLESHOOTING

• Fan does not turn on:

- Ensure the USB cable is securely plugged into both the fan and the power source.
- Verify that the USB power source is functional. Try plugging another device into the same port or using a different USB port/adapter.
- Press the power button on the back of the fan.

· Weak airflow:

- Ensure the fan is set to a higher speed setting by pressing the power button.
- Check for any obstructions around the fan blades or grilles.

Unusual noise:

- Ensure the fan is on a stable surface.
- Check for any foreign objects caught in the fan blades.


9. SPECIFICATIONS

Brand	ТОРК
Model Name	K51
Color	Black
Power Source	USB Powered
Voltage	5 Volts
Wattage	5 watts
Number of Power Levels	3
Wind Speed (Level 1)	3.9 m/s
Wind Speed (Level 2)	4.9 m/s
Wind Speed (Level 3)	5.9 m/s
Control Method	Push Button
Rotation	360° Vertical
Noise Level	Less than 50 Decibels (40-50dB at highest speed)
Product Dimensions	12 x 12 x 5.5 cm (4.7"D x 4.7"W x 2"H)

Item Weight	0.35 Pounds (160 Grams)
Motor Type	Brushless

Mini Size

Mini size,doesn't take up a lot of space






Figure 5: Compact Dimensions of the Fan

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact TOPK customer service through the retailer where the product was purchased.

© 2023 TOPK. All rights reserved.

Related Documents - K51

	TOPK K38 Foldable Handheld Fan User Manual and Product Information Comprehensive guide for the TOPK K38 Foldable Handheld Fan, covering product overview, instructions, safety warnings, cleaning, specifications, and package contents. Features USB charging and multiple speed settings.
	TOPK K31 Handheld Humidifying Fan User Manual Official user manual for the TOPK K31 Handheld Humidifying Fan. Learn about operating instructions, safety warnings, product parameters, and maintenance for your portable fan and humidifier.
	TOPK D56 Magnetic Car Phone Holder: User Guide and Installation Learn how to install and use the TOPK D56 magnetic car phone holder. This guide covers package contents, product overview, operating steps, and tips for adding magnetic attraction to your phone case.
\$12 manaza	TOPK Car Phone Holder User Manual: Installation & Operation Guide Comprehensive user manual for TOPK car phone holders. Learn about product features, package contents, installation steps, and usage guidelines for D35-D59 series models.
SZE MOROMAN	TOPK Magnetic Car Phone Holder User Manual and Product Overview Detailed guide for TOPK magnetic car phone holders, including package contents, product overview, and operating instructions for models like D37, D45, D48, D49, D50, D52, and D53.
SZZ-SCHOOLDE KERFE	TOPK Universal Car Phone Holder User Manual Comprehensive user manual for TOPK universal car phone holders, detailing installation, operation, and product overview for various series like D35, D36, D38, D39, D40, D41, D42, D43, D46, and D47.