



[Manuals.plus](#) /

> [odorpower](#) /

> odorpower Black Flush Mount Ceiling Light Fixture Instruction Manual

odorpower 0322B-CL BK

odorpower Black Flush Mount Ceiling Light Fixture

Model: 0322B-CL BK

[Introduction](#) [Safety Information](#) [What's in the Box](#) [Specifications](#) [Setup & Installation](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your odorpower Black Flush Mount Ceiling Light Fixture. This modern lighting solution is designed for various indoor and outdoor applications, featuring a durable metal frame and seeded glass shade.



Figure 1.1: Overview of the odorpower Black Flush Mount Ceiling Light Fixture.

2. SAFETY INFORMATION

Please read all safety instructions carefully before installation and operation. Failure to follow these instructions may result in electric shock, fire, or other hazards.

- Always turn off power at the circuit breaker before installing, cleaning, or servicing the fixture.
- Consult a qualified electrician if you are unsure about the installation process.
- Ensure all electrical connections comply with local codes and ordinances.
- Do not exceed the maximum wattage specified for the bulbs.
- Handle glass components with care to prevent breakage.
- This fixture is UL listed for safety.

3. WHAT'S IN THE BOX

Verify that all components are present before beginning installation:

- 1 x Ceiling Light Fixture (with metal frame and seeded glass shade)
- Mounting Hardware (screws, wire nuts, etc.)
- Instruction Manual

Note: Bulbs are not included and must be purchased separately.

4. SPECIFICATIONS

Feature	Detail
Brand	odorpower
Model Name	0322B-CL BK
Color	Black
Material	Metal, Plastic (Shade)
Style	Modern
Light Fixture Form	Ceiling (Flush Mount)
Product Dimensions	13"L x 13"W x 4.13"H
Indoor/Outdoor Usage	Indoor
Power Source	AC/DC
Voltage	120 Volts
Number of Light Sources	2
Bulb Base	E26 Standard Sockets
Max Wattage per Bulb	60W (Incandescent equivalent)
Compatible Bulb Types	CFL, Incandescent, LED, Halogen
Dimmable	Compatible with most standard dimmers
Certifications	UL Listed

PRODUCT DIMENSION



BULB NOT
INCLUDED



Figure 4.1: Detailed dimensions and compatible bulb types for the fixture.

5. SETUP & INSTALLATION

This flush mount ceiling light is designed for quick and easy installation. Follow these steps carefully:

1. Prepare for Installation:

- Turn off the power at the main circuit breaker to the junction box where you will be installing the light fixture.
- Ensure the power is completely off before proceeding.
- Gather necessary tools: screwdriver, wire strippers, electrical tape (not included).

2. Mount the Crossbar:

- Attach the mounting crossbar to the junction box using the provided screws. Ensure it is securely fastened.

3. Wire the Fixture:

- Connect the fixture's wires to the corresponding wires from the junction box using wire nuts:

- Connect the black wire (live) from the fixture to the black wire from the junction box.
 - Connect the white wire (neutral) from the fixture to the white wire from the junction box.
 - Connect the green or bare copper wire (ground) from the fixture to the ground wire from the junction box or the ground screw on the crossbar.
- Secure all wire connections with electrical tape if necessary.

4. Attach the Fixture to the Crossbar:

- Carefully tuck the wires into the junction box.
- Align the fixture with the mounting screws on the crossbar and secure it in place with the decorative nuts or screws provided.

5. Install Bulbs:

- Insert two E26 base bulbs (not included) into the sockets. Do not exceed 60W per bulb.
- The open-bottom design simplifies bulb replacement.

6. Restore Power:

- Turn the power back on at the circuit breaker.
- Test the light fixture to ensure it functions correctly.

PRODUCT DETAILS



Seeded Glass Shadee



Metal Frame Black Finish



E26 Bulb Base
(Bulb Not Included)



Figure 5.1: Key components for installation, including the seeded glass shade, metal frame, and E26 bulb base.

6. OPERATING INSTRUCTIONS

The odorpower flush mount ceiling light operates via a standard wall switch (not included). Simply toggle the switch to turn the light on or off.

- **Dimming Functionality:** If connected to a compatible dimmer switch, you can adjust the brightness of the light. Ensure that the installed E26 bulbs are also dimmable.



Figure 6.1: Visual representation of the light fixture in both ON and OFF states.

7. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your light fixture.

- **Cleaning:**

- Before cleaning, ensure the power to the fixture is turned off at the circuit breaker.
- Wipe the metal frame with a soft, dry cloth.
- For the glass shade, use a soft, damp cloth with a mild, non-abrasive cleaner if necessary. Dry thoroughly.
- The sealed design helps prevent bugs from entering the fixture, reducing the frequency of internal cleaning. However, occasional unscrewing of the glass may be required for thorough cleaning if dust or debris accumulates.

- **Bulb Replacement:**

- Ensure power is off before replacing bulbs.

- Allow old bulbs to cool before handling.
- Replace with E26 base bulbs, not exceeding 60W.

8. TROUBLESHOOTING

If you encounter issues with your light fixture, refer to the following common problems and solutions:

Problem	Possible Cause(s)	Solution
Light does not turn on.	<ul style="list-style-type: none"> • Power is off at the circuit breaker. • Loose wire connections. • Faulty bulb(s). • Faulty wall switch. 	<ul style="list-style-type: none"> • Check and reset the circuit breaker. • Turn off power, then check and tighten all wire connections. • Replace bulb(s) with new, working ones. • Test the wall switch; replace if necessary.
Light flickers.	<ul style="list-style-type: none"> • Loose bulb. • Incompatible dimmer switch or bulb. • Loose wire connection. 	<ul style="list-style-type: none"> • Tighten the bulb(s). • Ensure both dimmer and bulbs are compatible. • Turn off power, then check and tighten wire connections.
Fixture is difficult to mount.	<ul style="list-style-type: none"> • Mounting screws are too short. • Misalignment of fixture with crossbar. 	<ul style="list-style-type: none"> • Acquire longer mounting screws if necessary. • Carefully re-align the fixture with the crossbar.

9. WARRANTY & SUPPORT

Warranty: odorpower offers a two-year warranty on this ceiling light fixture, covering defects in materials and workmanship under normal use.

Customer Support: If you have any questions, concerns, or require assistance with your product, please contact odorpower customer service. Refer to the product packaging or the odorpower brand store on Amazon for contact details. You can visit the official odorpower store for more information: [odorpower Amazon Store](#)