

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Max Build More](#) /
- › [MAX Build More Fire Rescue Adventure Building Toy Set \(265 Pieces\) Instruction Manual](#)

### Max Build More 83166

# MAX Build More Fire Rescue Adventure Building Toy Set

MODEL: 83166

Instruction Manual

## 1. Introduction

This manual provides instructions for the MAX Build More Fire Rescue Adventure Building Toy Set, Model 83166. This set contains over 265 building pieces designed for children aged 6 years and older to construct fire rescue vehicles and figures.

### Important Safety Warning:

**CHOKING HAZARD - Small parts. Not suitable for children under 3 years.**

Adult supervision is recommended during assembly and play to ensure safe use of all components.

## 2. Components Overview

The MAX Build More Fire Rescue Adventure set includes 265 building pieces. These pieces allow for the construction of two primary vehicles and two character figures, along with accessory elements such as flames.

- Building blocks for a fire rescue truck.
- Building blocks for a fire rescue helicopter.
- Two firefighter character figures.
- Accessory pieces, including flame elements.

Refer to the packaging and the following images for a visual representation of the included components and the completed models.



Image 2.1: Overview of the MAX Build More Fire Rescue Adventure set, including packaging and assembled models.



Image 2.2: Assembled fire truck, helicopter, and flame accessories.

### 3. Assembly Instructions

The MAX Build More Fire Rescue Adventure set is designed for self-assembly. Detailed, easy-to-follow instructions are included within the product packaging to guide the construction process for both the fire truck and the helicopter.

1. **Unpack Components:** Carefully open the packaging and lay out all building pieces on a clean, flat surface.
2. **Identify Pieces:** Refer to the instruction booklet to identify the different types of blocks required for each step.
3. **Follow Step-by-Step Guide:** Assemble the fire truck and helicopter by following the sequential steps provided in the included instruction manual. Pay close attention to the diagrams for correct piece placement.
4. **Connect Pieces Securely:** Ensure all blocks are firmly connected to prevent models from falling apart during play.
5. **Assemble Figures:** Construct the firefighter character figures as per the instructions.

The building blocks are compatible with major brick brands, allowing for integration with existing collections.



Image 3.1: Detailed view of the assembled fire rescue truck.



Image 3.2: Detailed view of the assembled fire rescue helicopter.

#### 4. Operating and Play

Once assembled, the fire rescue truck and helicopter are ready for play. The set encourages creative play scenarios involving fire rescue operations.

- **Fire Truck:** The truck features rolling wheels for movement across flat surfaces.
- **Helicopter:** The helicopter includes articulated propellers that can be manually spun for realistic play.
- **Firefighter Figures:** Place the firefighter figures inside the vehicles or use them independently to enhance play.
- **Flame Accessories:** Use the flame pieces to simulate fire emergencies for the rescue team.



Image 4.1: Example of play with the assembled fire rescue set.

## 5. Care and Maintenance

To ensure the longevity of your MAX Build More Fire Rescue Adventure set, follow these simple care guidelines:

- **Cleaning:** Wipe the building blocks and assembled models with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the set in a cool, dry place away from direct sunlight to prevent material degradation and color fading.
- **Handling:** Handle pieces carefully during assembly and disassembly to avoid breakage.

## 6. Troubleshooting

If you encounter issues during assembly or play, consider the following:

- **Pieces Not Fitting:** Ensure you are using the correct pieces for each step as indicated in the instruction manual. Apply firm, even pressure when connecting blocks.
- **Loose Connections:** If assembled parts feel loose, carefully re-examine the connection points. Disassemble

and reassemble the section, ensuring each block is fully seated.

- **Missing Pieces:** In the rare event of missing pieces, please contact customer support for assistance.

## 7. Product Specifications

Feature	Detail
Brand	Max Build More
Model Number	83166
Product Dimensions (L x W x H)	28 x 5.6 x 22.8 cm
Item Weight	370 grams
Recommended Age	6 years and up
Educational Value	Creative Thinking
Number of Pieces	265
Assembly Required	Yes
Batteries Required/Included	No
Main Material	Plastic
Color	Fire Rescue
Theme	Firefighters

## 8. Warranty and Support

Specific warranty information for the MAX Build More Fire Rescue Adventure Building Toy Set is not provided in the product details. For any inquiries regarding product support, missing parts, or warranty claims, please contact the manufacturer, Max Build More, directly through their official customer service channels.