

## KRUPS EA 89 Z

# KRUPS EA 89 Z Classic Edition Espresso Machine User Manual

Model: EA 89 Z (Reference: 840737)

## 1. INTRODUCTION

Thank you for choosing the KRUPS EA 89 Z Classic Edition Espresso Machine. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read all instructions carefully before first use and keep this manual for future reference.

## 2. SAFETY INSTRUCTIONS

- Always ensure the machine is connected to a grounded power outlet.
- Do not immerse the appliance, power cord, or plug in water or any other liquid.
- Keep the appliance out of reach of children.
- Unplug the machine before cleaning and when not in use.
- Do not operate the machine if the power cord or plug is damaged. Contact authorized service for repair.
- Use only cold, fresh water in the water tank.
- Be cautious of hot surfaces and steam during operation.

## 3. PRODUCT OVERVIEW

Familiarize yourself with the components of your KRUPS EA 89 Z espresso machine.

- Control Panel with intuitive buttons for various drinks and functions.
- Coffee Bean Hopper.
- Water Tank.
- Coffee Spout.
- Milk Frother/Steam Nozzle (if applicable).
- Drip Tray and Coffee Grounds Collector.

## 4. SETUP

### 4.1 Unpacking and Placement

Carefully remove all packaging materials. Place the machine on a stable, flat, heat-resistant surface, away from water sources and direct sunlight. Ensure adequate space around the machine for ventilation and access.



Image: The KRUPS EA 89 Z espresso machine showing its dimensions: approximately 36.7 cm height, 38 cm depth, and 24 cm width. This helps in planning placement on a countertop.

### 4.2 Initial Cleaning

Before first use, wash the water tank, drip tray, and coffee grounds collector with warm water and mild detergent. Rinse thoroughly and dry.

### 4.3 Filling the Water Tank

Remove the water tank, fill it with fresh, cold water up to the MAX level indicator, and reinsert it securely into the machine.

## 4.4 Filling the Bean Hopper

Open the lid of the coffee bean hopper and pour fresh whole coffee beans into it. Do not fill above the MAX line.

## 4.5 First Use / Priming

Plug in the machine. Follow the on-screen prompts or indicator lights for the initial priming cycle. This typically involves flushing water through the system to prepare it for use.

# 5. OPERATING

---

## 5.1 Powering On/Off

Press the power button (usually indicated by a circle with a vertical line) to turn the machine on or off. The machine will perform a brief rinse cycle upon startup.

## 5.2 Control Panel and Drink Selection

The KRUPS EA 89 Z features an intuitive interface for easy drink selection.



PERSONALIZABLE

Ajusta la intensidad y el volumen del café a tu gusto

Image: A hand interacting with the intuitive control panel of the KRUPS EA 89 Z, showing clearly labeled buttons for Espresso, Coffee, Americano, Cappuccino, Latte Macchiato, Latte, Hot Water, and Clean functions.

This machine offers direct access to a variety of coffee and milk-based beverages.

# VERSÁTIL

Acceso directo a 8 bebidas  
con leche y sin leche



Image: The KRUPS EA 89 Z espresso machine on a countertop, surrounded by various coffee cups, illustrating its versatility and direct access to 8 different milk and non-milk beverages.

## 5.3 Making Espresso/Coffee

1. Place a cup under the coffee spout.
2. Select your desired drink (e.g., Espresso, Coffee, Americano) from the control panel.
3. The machine will automatically grind the beans, brew, and dispense the coffee.

## 5.4 Making Milk-Based Drinks

The machine features advanced milk technology for creamy beverages.



Image: Close-up of the KRUPS EA 89 Z espresso machine's milk frothing system, showing milk being dispensed into two glasses, highlighting its 'Advanced Milk Technology'.

1. Fill a container with fresh cold milk and connect the milk tube to the machine and the container.
2. Place a suitable cup under the coffee spout and milk nozzle.
3. Select your desired milk-based drink (e.g., Cappuccino, Latte Macchiato, Latte).
4. The machine will automatically froth the milk and brew the coffee.



Image: The KRUPS EA 89 Z espresso machine preparing two milk-based coffee drinks simultaneously, with a milk container connected via a tube, demonstrating its capability for multiple servings.

## 5.5 Customization

You can adjust the intensity and volume of your coffee to your preference.

# INTERFAZ INTUITIVA



Image: Three glasses of coffee, each with slightly different volumes and intensities, illustrating the customizable nature of the KRUPS EA 89 Z espresso machine's output.

Refer to the control panel for options to adjust coffee strength (e.g., mild, medium, strong) and cup volume. Your drinks will always be to your taste.

TUS BEBIDAS  
SIEMPRE A TU  
GUSTO



Image: The KRUPS EA 89 Z espresso machine on a kitchen counter, with two cups of espresso, emphasizing that the machine delivers personalized beverages to the user's taste.

## 5.6 Hot Water Function

To dispense hot water, select the 'Hot Water' option on the control panel. This is useful for tea or instant beverages.

## 6. MAINTENANCE

Regular cleaning and maintenance ensure optimal performance and longevity of your espresso machine.

### 6.1 Drip Tray and Coffee Grounds Collector

Empty and clean the drip tray and coffee grounds collector daily or when indicated by the machine. Wash with warm, soapy water and rinse thoroughly.

### 6.2 Water Tank Cleaning

Clean the water tank weekly with warm water and a soft brush. Do not use abrasive cleaners.

## 6.3 Milk System Cleaning

After preparing milk-based drinks, perform a quick rinse of the milk system as prompted by the machine. For a deeper clean, follow the dedicated milk system cleaning program using appropriate cleaning solutions.

## 6.4 Descaling

The machine will prompt you when descaling is required. Use only KRUPS descaling solution and follow the instructions provided with the solution and on the machine's display.

## 6.5 Brew Unit Cleaning

While the internal brew unit is generally self-cleaning, refer to the full manual for any specific instructions on periodic cleaning or maintenance of internal components.

# 7. TROUBLESHOOTING

---

If you encounter issues, consult this section before contacting customer service.

- No Coffee Dispensed:** Check water tank level, ensure coffee beans are present, and verify the coffee spout is not blocked.
- Weak Coffee:** Adjust coffee strength settings, ensure fresh beans are used, and check for proper descaling.
- Machine Not Turning On:** Ensure the power cord is securely plugged into a working outlet.
- Error Message on Display:** Refer to the full product manual or KRUPS support website for specific error code meanings and solutions.

# 8. SPECIFICATIONS

---

Feature	Specification
Brand	KRUPS
Model Number	840737
ASIN	B0CQK6DFFQ
Product Dimensions	49 x 39 x 29 cm (Depth x Width x Height)
Product Weight	7 kg (7000 Grams)
Material	Metal
Coffee Maker Type	Espresso Machine
Special Feature	Unique
Recommended Uses	Home Beverages, Espresso

# 9. WARRANTY AND SUPPORT

---

Your KRUPS EA 89 Z Classic Edition Espresso Machine is covered by a manufacturer's warranty. For detailed warranty

information, service, or technical support, please refer to the warranty card included with your product or visit the official KRUPS website. You can also find additional support and FAQs on the [KRUPS Brand Store on Amazon](#).

© 2023 KRUPS. All rights reserved.