



[Manuals.plus](#) /

> [Summit Appliance](#) /

> Summit Appliance 24-inch Wine Kegerator/Refrigerator Combo (Model SBC7BRS) User Manual

Summit Appliance SBC7BRS

Summit Appliance 24-inch Wine Kegerator/Refrigerator Combo (Model SBC7BRS) User Manual

Model: SBC7BRS

INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation, installation, and maintenance of your Summit Appliance 24-inch Wine Kegerator/Refrigerator Combo, model SBC7BRS. This versatile unit is designed for both residential and commercial use, offering the flexibility to dispense wine from two 1/6 (sixtel) kegs or function as a standard refrigerator.

Please read all instructions carefully before using the appliance to ensure proper function and to prevent injury or damage.

SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Ensure the appliance is properly grounded.
- Do not operate if the power cord is damaged.
- Keep ventilation openings clear of obstructions.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Unplug the appliance before cleaning or performing maintenance.

SETUP AND INSTALLATION

Unpacking

Carefully remove all packaging materials. Inspect the unit for any shipping damage. Report any damage immediately to the carrier and your dealer.

Placement

The SBC7BRS can be installed as a freestanding unit or recessed under counters. Ensure adequate ventilation around the unit, especially at the rear and sides.





Image: Front view of the Summit Appliance kegerator, showing the tap tower and optional caster wheels for mobility.

Adjustable Legs and Casters

The unit includes adjustable legs, allowing the height to be set between 33 1/2 inches and 34 1/2 inches for a perfect fit under counters. A black steel leg shield is provided for optional use if there is a gap between the front and floor when the unit is set at its maximum height. A set of casters (two locking) is also included for optional mobility if freestanding use is preferred.



Image: Close-up view of the base of the kegerator, highlighting the installed caster wheels.

Door Reversal

The stainless-steel door is user-reversible, allowing you to change the door swing direction to suit your installation needs. Refer to the detailed instructions in the separate door reversal guide (if provided) or contact customer support for assistance.

Kegerator Kit Assembly

This unit ships with a complete commercial-grade stainless steel twin tap kit. The kit includes:

- Twin tap tower with two faucets
- Empty CO2 tank
- CO2 regulator

- All necessary hoses and connectors for serving wine from two 1/6 (sixtel) kegs.

Follow the provided assembly instructions for the tap kit carefully to ensure proper and leak-free connection.



Image: The kegerator interior, showing two 1/6 (sixtel) wine kegs in place and the dual tap tower mounted on top.

Power Connection

Connect the appliance to a dedicated, grounded 115V AC electrical outlet. Do not use extension cords or adapter plugs.

OPERATING INSTRUCTIONS

Temperature Control

The unit features classic mechanical controls with a dial thermostat located behind the interior light switch. Turn the dial to adjust the internal temperature. Allow several hours for the unit to reach the desired temperature after initial setup or temperature adjustments.

Loading Kegs

Carefully place up to two 1/6 (sixtel) wine kegs onto the stainless-steel floor inside the unit. Ensure the kegs are stable and do not obstruct the door or internal components. Connect the tap kit components to the kegs as per the kit's instructions.

Serving Wine

Once the kegs are connected and the CO2 pressure is set, you can dispense wine by operating the faucets on the tap tower. Refer to the tap kit instructions for specific details on pressure settings and dispensing techniques.

Interior Light

The interior light is an LED and can be turned on or off using the rocker switch located behind the dial thermostat. This provides visibility inside the unit, especially when loading or unloading kegs or items.

Converting to a Refrigerator

When not used as a kegerator, the unit can be converted into a standard refrigerator. Remove the tap tower and kegs. The unit includes three adjustable glass shelves and one scalloped bottle rack for easy storage of bottles and other items. The black interior liner and stainless-steel floor provide added protection.



Image: The kegerator interior configured as a refrigerator, showing the glass shelves and bottle rack in place.

MAINTENANCE

Cleaning

Regular cleaning of your appliance will ensure optimal performance and hygiene.

- **Interior:** Unplug the unit. Clean the interior liner and stainless-steel floor with a mild detergent and warm water. Rinse thoroughly and dry.

- **Exterior:** Clean the stainless-steel door and exterior surfaces with a soft cloth and a mild, non-abrasive cleaner.
- **Tap Kit:** Regularly clean the tap tower, faucets, and beer lines according to the tap kit manufacturer's instructions to prevent bacterial growth and ensure proper taste.

Automatic Defrost

The unit features an automatic defrost system, which reduces user maintenance. Frost will periodically melt and drain into an evaporation pan. Ensure the drain is not blocked.

Long-Term Storage

If the unit will not be used for an extended period, unplug it, clean the interior thoroughly, and leave the door slightly ajar to prevent odors and mold growth.

TROUBLESHOOTING GUIDE

Before contacting service, please check the following common issues:

Problem	Possible Cause	Solution
Appliance does not operate	Not plugged in; Circuit breaker tripped; Power switch off	Ensure plug is secure; Reset circuit breaker; Check power switch.
Temperature is not cold enough	Door not closed properly; Excessive door openings; Thermostat set too warm; Unit located near heat source	Check door seal; Reduce door openings; Adjust thermostat to a colder setting; Relocate unit away from heat.
Excessive vibration	Unit not level; Loose parts	Adjust leveling legs or casters; Contact service if internal parts are loose.
No wine dispensing	CO2 tank empty; Regulator pressure too low; Keg empty; Tap line clogged	Check CO2 tank level; Adjust regulator pressure; Replace keg; Clean tap lines and faucets.
Water on floor	Drain pan overflowing; Drain hose blocked	Check and clear drain hose; Ensure unit is level.

SPECIFICATIONS

Feature	Detail
Brand Name	Summit Appliance
Model Info	SBC7BRS
Item Weight	137 pounds
Product Dimensions (D x W x H)	22.38 x 23.63 x 33.5 inches
Color	Wine (Interior: Black)
Voltage	115 Volts (AC)

Feature	Detail
Door Hinges	Left (User-reversible)
Door Material Type	Stainless Steel
Lighting	LED
Shelf Type	Glass
Number of Shelves	3 (for refrigerator conversion)
Material Type	Stainless Steel
Defrost Type	Automatic
Commercial Approval	ETL-S listed to NSF-7 standards

WARRANTY INFORMATION

For detailed warranty information, please refer to the warranty card included with your product or visit the official Summit Appliance website. Keep your purchase receipt as proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need to order replacement parts, please contact Summit Appliance customer support.

You can find more information and contact details by visiting the [Summit Appliance Store on Amazon](#) or their official website.