truke Clarity 6

truke Clarity 6 Wireless Earbuds User Manual

Model: Clarity 6 (S227)

1. Introduction

This manual provides detailed instructions for the operation and maintenance of your truke Clarity 6 Wireless Earbuds. Please read this guide thoroughly to ensure proper usage and to maximize your listening experience. The truke Clarity 6 earbuds feature advanced 6-Mic Environmental Noise Cancellation (ENC), dual-device pairing, 80 hours of total playtime, 13mm Titanium Drivers, 3 EQ modes, and 35ms ultra-low latency.

2. Package Contents

- truke Clarity 6 Wireless Earbuds (Left and Right)
- Charging Case
- USB Type-C Charging Cable
- User Manual

3. Product Overview

Familiarize yourself with the components of your truke Clarity 6 earbuds and charging case.



Image: truke Clarity 6 earbuds in their open charging case, showcasing the design and individual earbuds.



Image: The truke Clarity 6 earbuds resting in their charging case, with visible LED indicators on the case front.

4. Setup

4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Use the provided USB Type-C cable to connect the charging case to a power source. The LED indicators on the case will show the charging status.

- The charging case provides up to 80 hours of additional playtime.
- Earbuds offer up to 10 hours of playtime on a single charge.




Image: A visual representation highlighting the 80 hours of extended playtime offered by the truke Clarity 6 earbuds with their charging case.




Image: The truke Clarity 6 charging case connected via a Type-C cable, indicating its fast charging capability.

4.2 Initial Pairing

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. Enable Bluetooth on your device (smartphone, tablet, laptop).
3. Search for 'truke Clarity 6' in the list of available Bluetooth devices.
4. Select 'truke Clarity 6' to connect. A voice prompt will confirm successful pairing.

5. Operating Instructions

5.1 Power On/Off

- **Power On:** Open the charging case, and the earbuds will automatically power on.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically power off and begin charging.

5.2 Dual-Device Connectivity

The truke Clarity 6 earbuds support seamless dual-device pairing, allowing you to connect to two devices simultaneously.

1. Connect the earbuds to your first device following the initial pairing steps.
2. Disconnect the earbuds from the first device's Bluetooth settings.
3. Connect the earbuds to your second device.
4. Reconnect the earbuds to the first device from its Bluetooth settings. The earbuds should now be connected to both devices.

Note: The dual-pairing feature will automatically close if not connected with the second device within 3 minutes. To resume dual-pairing, tap either earbud four times, or place both earbuds back into the charging case and then take them out again.



Image: truke Clarity 6 earbuds demonstrating dual-connectivity, with an incoming call on a smartphone while a video plays on a laptop.

5.3 Touch Controls

The earbuds feature touch-sensitive controls on the outer surface for managing playback, calls, and EQ modes.

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap the right earbud.
- **Previous Track:** Double tap the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.
- **Activate Voice Assistant:** Triple tap on either earbud.
- **Switch EQ Modes:** Press and hold the right earbud for 3 seconds.

5.4 EQ Modes

The truke Clarity 6 offers three preset equalizer modes to customize your audio experience:

- **Dynamic Mode:** Balanced audio for general listening.
- **Movie Mode:** Enhanced vocals and sound effects for cinematic experiences.
- **Bass Boost Mode:** Amplified low frequencies for a powerful bass response.

To switch between these modes, press and hold the right earbud for 3 seconds.



Image: A close-up of a truke Clarity 6 earbud alongside a graphic illustrating the three preset equalizer modes: Dynamic, Movie, and Bass Boost.

5.5 Call Management (6-Mic ENC)

The earbuds feature 6-Mic Environmental Noise Cancellation (ENC) technology for clear conversations in noisy environments. This technology reduces background noise, focusing on your voice for superior call quality.



Image: A detailed view of a truke Clarity 6 earbud, emphasizing its 6-Mic Advanced ENC technology for crystal-clear conversations.

5.6 Gaming Mode (35ms Ultra-Low Latency)

Activate gaming mode for an ultra-low latency experience of 35ms, ensuring audio synchronization with on-screen action for competitive gaming.



Image: truke Clarity 6 earbuds positioned in front of a smartphone displaying a racing game, illustrating the 35ms ultra-low latency feature for gaming.

6. Maintenance

6.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Avoid using abrasive materials, solvents, or aerosol sprays.
- Ensure charging contacts on both earbuds and case are clean and dry.

6.2 Water Resistance

The truke Clarity 6 earbuds are rated IPX5 water resistant, meaning they can withstand splashes and sweat. They are not designed for submersion in water. Avoid exposing them to heavy rain or showering.

7. Troubleshooting

If you encounter issues with your truke Clarity 6 earbuds, refer to the following common solutions:

Issue	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Place them back in the case, close the lid, then open to re-enter pairing mode. Check your device's Bluetooth settings and try reconnecting.
Only one earbud working	Ensure both earbuds are charged. Try placing both back in the case, closing the lid, and then taking them out again. Re-pair with your device.
Dual-pairing not working	If not connected to the second device within 3 minutes, the feature closes. Tap either earbud four times or place both earbuds back into the charging case to resume dual-pairing.
Poor call quality	Ensure earbuds are properly seated in your ears. Check for obstructions around the microphones. The 6-Mic ENC should minimize background noise.
Low volume or distorted sound	Adjust volume on your connected device. Try switching between the 3 EQ modes. Ensure earbuds are clean and free of debris.
Earbuds not charging	Verify the charging cable is securely connected to both the case and power source. Ensure charging contacts on earbuds and case are clean.

8. Specifications

Feature	Specification
Model Name	Clarity 6
Item Model Number	S227
Connectivity Technology	Wireless (Bluetooth 5.3)
Audio Driver Type	13mm Titanium Dynamic Driver
Microphones	6-Mics with Environmental Noise Cancellation (ENC)
Total Playtime	Up to 80 Hours (with charging case)
Earbud Playtime	Up to 10 Hours (single charge)
Latency	35ms Ultra-Low Latency
Water Resistance Level	IPX5 (Water Resistant)
Control Type	Touch Control
Item Weight	48 Grams
Product Dimensions	5.8 x 5.8 x 2.9 cm
Material	Plastic
Included Components	Cable
Country of Origin	China

9. Warranty and Support

Your truke Clarity 6 earbuds come with a **12-month warranty**, ensuring quality and customer satisfaction. truke maintains a vast service network with over 350 active service centers for convenient and accessible support.



Image: A graphic detailing the 12-month warranty, 350+ active service centers, and customer care contact information for truke products.

Customer Support:

- **Contact Number:** +91 9354170767
- **Email ID:** support@eccentricindia.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question