

[manuals.plus](#) /› [INFANS](#) /› [INFANS 8-in-1 Convertible Baby High Chair Instruction Manual](#)**INFANS B0CQLK7G76**

# INFANS 8-in-1 Convertible Baby High Chair Instruction Manual

Model: B0CQLK7G76

## 1. INTRODUCTION

This manual provides essential information for the safe and effective use of your INFANS 8-in-1 Convertible Baby High Chair. This versatile product is designed to adapt to your child's growth, offering multiple configurations from infancy through toddlerhood. Please read these instructions carefully before assembly and use, and retain them for future reference.

The INFANS 8-in-1 high chair can be configured into the following modes:

1. Traditional Baby High Chair
2. Baby Feeding Chair
3. Toddler Booster Seat
4. Kids Table and Chair Set
5. Studying Table
6. Ordinary Stool
7. Toddler Chair
8. Building Block Table



## Suitable for Different Needs of Children

Suitable for kids of 6-36 Months



Figure 1: Overview of the 8-in-1 configurations.

## 2. SAFETY INFORMATION

Your child's safety is paramount. Always follow these safety guidelines:

- **Always use the 5-point harness:** Secure your child firmly in the seat using the adjustable 5-point harness with shoulder pads to prevent falls.
- **Fixed Safety Baffle:** Ensure the fixed safety baffle is properly engaged to prevent the child from sliding out.
- **Stable Placement:** Always place the high chair on a flat, stable surface. The pyramid structure with non-slip pads enhances stability.
- **Supervision:** Never leave your child unattended in the high chair.
- **Weight and Age Limits:** Recommended for ages 6-36 months with a maximum weight capacity of 55 lbs (25 kg).
- **Material Safety:** The product is made of non-toxic, food-grade PP material, free from BPA, PVC, Phthalates, Lead, Latex, and Formaldehyde. It has passed US. CPSIA & ASTM safety tests.
- **Check Connections:** Regularly inspect all connections and fasteners to ensure they are secure.

# Removable Tray with 3 Adjustable Positions



Figure 2: Safety features including the 5-point harness and fixed safety baffle.

## 3. PRODUCT FEATURES

### 3.1. 8-in-1 Convertible Design

The INFANS high chair offers unparalleled versatility, transforming to meet your child's evolving needs:

- **High Chair:** Standard configuration for feeding infants.
- **Booster Seat:** The seat can be detached and secured to an adult dining chair using adjustable straps, allowing your child to join family meals.
- **Low Chair:** Remove the extended legs to create a low-profile feeding or play chair.
- **Table and Chair Set:** The base converts into a small table, and the seat becomes a child-sized chair, ideal for drawing, studying, or playing.
- **Building Block Table:** The table surface includes a removable top that reveals a building block compatible surface for creative play.
- **Kids Stool:** The table base can be used as a standalone stool.

**infans**

## High Chair for Babies and Toddlers



Figure 3: The 8-in-1 functionality of the high chair.

### 3.2. Detachable & Adjustable Tray

The feeding tray features 3 adjustable positions, allowing you to customize the space for your child as they grow. It is made from durable, kids-friendly PP material and is easily detachable for cleaning.



Figure 4: Tray with 3 adjustable positions.

### 3.3. Easy to Clean

The high chair is designed for easy maintenance. The PU cushions are removable for cleaning, and the tray is dishwasher-safe, simplifying cleanup after meals.



Figure 5: Easy-to-clean features of the high chair.

## 4. SETUP AND ASSEMBLY

The INFANS high chair features a simple, buckle-connected assembly process. No tools are required for most configurations.

### 4.1. High Chair Assembly

1. Connect the long legs to the main seat unit and the table base. Ensure all connections click securely into place.
2. Attach the seat cushion and 5-point harness to the seat.
3. Slide the tray onto the seat's armrests until it locks into your desired position.

### 4.2. Converting to Table and Chair Set

1. Detach the main seat unit from the table base by pressing the release buttons.
2. The table base, with its short legs, functions as the child's table.
3. Remove the long legs from the seat unit and attach the shorter legs to convert it into a child's chair.

### 4.3. Converting to Booster Seat

1. Remove the seat unit from the table base.
2. Use the adjustable fixed straps located on the booster seat to securely attach it to an adult dining chair. Ensure the straps are tightened to prevent movement.

# Easy to Clean



Soft & Breathable Leather



BPA-Free



Waterproof & Wipeable Surface



Dishwasher-safe Tray



Double Cushion

Figure 6: Booster seat conversion and securing mechanism.

## 5. OPERATING INSTRUCTIONS

### 5.1. Securing Your Child

1. Place your child in the seat.
2. Fasten the 5-point harness by connecting the shoulder straps to the waist straps, then inserting the buckles into the central locking mechanism until you hear a click.
3. Adjust the straps to ensure a snug but comfortable fit for your child.

Your browser does not support the video tag.

Video 1: Demonstration of securing the 5-point harness and removing the tray.

### 5.2. Adjusting the Tray

To adjust the tray, locate the release levers on both sides of the tray. Squeeze the levers and slide the tray forward or backward to one of the three available positions. Release the levers to lock the tray in place.

### 5.3. Using the Building Block Table

When configured as a table, the top surface can be removed to reveal a building block compatible play area. Simply lift the top panel to access the block surface.

## Satisfy Different Feeding Needs



High Chair



Low Chair

Figure 7: Children using the high chair in building block table and drawing modes.

## 6. MAINTENANCE AND CLEANING

Regular cleaning ensures hygiene and extends the product's lifespan.

- **Tray:** The tray is dishwasher-safe. For manual cleaning, wash with warm soapy water and rinse thoroughly.
- **Cushions:** The PU cushions are removable and can be wiped clean with a damp cloth and mild soap. Allow to air dry completely before reattaching.
- **Frame:** Wipe down the plastic and metal components of the frame with a damp cloth. Avoid abrasive cleaners.
- **Harness:** The harness straps can be spot cleaned with mild soap and water. Ensure they are dry before use.

## 7. TROUBLESHOOTING

---

If you encounter any issues with your INFANS high chair, please refer to the following common solutions:

- **Difficulty with Assembly/Conversion:** Ensure all parts are aligned correctly and that you hear a 'click' when connecting components. Refer to the assembly diagrams in Section 4.
- **Tray not locking:** Check for any food debris or obstructions in the tray's locking mechanism. Ensure the release levers are fully disengaged when attempting to lock.
- **Harness not securing:** Verify that all buckle components are correctly inserted into the central locking mechanism. Adjust straps for a snug fit.
- **Instability:** Ensure the high chair is placed on a flat, level surface. Check that all legs are fully extended and securely locked.

For persistent issues or concerns not addressed here, please contact INFANS customer support.

## 8. SPECIFICATIONS

Feature	Detail
Product Dimensions	23"D x 23"W x 38.5"H (High Chair Mode)
Item Weight	17.5 Pounds (7.9 kg)
Maximum Weight Recommendation	55 Pounds (25 kg)
Recommended Age	6-36 Months
Material Type	Polypropylene (PP)
Style	8 in 1 Convertible
Safety Certifications	US. CPSIA & ASTM Approved
Tray Positions	3 Adjustable Positions
Portability	Not portable (designed for stationary use in various configurations)

# Safety Booster




Figure 8: Product dimensions in various configurations.

## 9. WARRANTY AND SUPPORT

INFANS is committed to providing quality and comfortable products. For warranty information, product registration, or customer support, please visit the official INFANS website or contact their customer service department. Product registration can often be completed at [www.costway.com/register](http://www.costway.com/register).