

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Blaupunkt](#) /

› [Blaupunkt 43QD7050 43-inch 4K Ultra HD QLED Google TV User Manual](#)

Blaupunkt 43QD7050

Blaupunkt 43QD7050 43-inch 4K Ultra HD QLED Google TV User Manual

Model: 43QD7050

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Blaupunkt 43QD7050 43-inch 4K Ultra HD QLED Google TV. Please read this manual thoroughly before using the television to ensure proper functionality and safety.




Image: Front view of the Blaupunkt 43QD7050 QLED Google TV, highlighting its display and features.

IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using this television to reduce the risk of fire, electric shock, and injury. Keep this manual for future reference.


- Do not expose the television to rain or moisture.
- Do not block ventilation openings.
- Ensure proper grounding for the power cord.
- Unplug the television during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

WHAT'S IN THE BOX


Verify that all components are present upon unpacking your television.



IN THE BOX




TV




Power
Cord



Base Stand



Stand Screw x 4



Wall Mount



REMOTE WITH
2 AAA BATTERIES

Wall Mount & Stand Options

(Provided Free During The Installation Process)

32"–65"
Fixed Wall Mount Bracket

Image: Diagram showing the items included in the product packaging: TV, remote control, wall mount, stand screws, power cord, and AAA batteries.

- 1 x Blaupunkt 43QD7050 LED TV

- 1 x Remote Control
- 1 x Wall Mount Bracket (for 32"-65" models)
- 2 x AAA Batteries (for remote control)
- 1 x Power Cord
- 1 x Base Stand Set (with 4 stand screws)
- User Manual (this document)


PHYSICAL OVERVIEW


Front View



Image: Front view of the television, showcasing the screen and minimal bezels.

Side View








Image: Side profile of the television, illustrating its slim design.

Rear View and Ports



Image: Rear view of the television, detailing the location of various input and output ports.

The rear panel of the TV includes various ports for connectivity:

- **HDMI Ports (x3):** For connecting devices like gaming consoles, set-top boxes, and Blu-ray players. One port supports eARC.
- **USB Ports (x2):** For connecting USB storage devices.
- **Ethernet Port:** For wired internet connection.
- **Antenna/Cable Input:** For connecting an antenna or cable TV.
- **Audio Out:** For connecting external audio systems.
- **Power Input:** For connecting the power cord.

SETUP GUIDE

1. Stand Installation (Optional)

If you choose to place the TV on a stand, follow these steps:

1. Carefully place the TV face-down on a soft, flat surface to prevent screen damage.
2. Align the base stands with the screw holes on the bottom of the TV.
3. Secure each stand with the provided screws.

2. Wall Mounting (Optional)

The TV comes with a wall mount bracket. Professional installation is recommended for wall mounting. Ensure the wall can support the weight of the TV.

- Refer to the wall mount bracket's instructions for specific installation details.
- Ensure adequate ventilation around the mounted TV.

3. Connecting Peripherals

Connect your external devices to the appropriate ports on the TV's rear panel.

- **HDMI:** Use HDMI cables to connect devices like set-top boxes, gaming consoles, or Blu-ray players.
- **USB:** Insert USB drives for media playback.
- **Ethernet:** Connect an Ethernet cable for a stable wired internet connection.
- **Power:** Connect the power cord to the TV's power input and then to a wall outlet.



Image: Visual representation of the TV's connectivity options including HDMI, Bluetooth, Dual Band Wi-Fi, and USB.

4. Initial Power On and Google TV Setup

1. Plug the TV into a power outlet.
2. Press the Power button on the remote control or the TV.
3. Follow the on-screen instructions to complete the initial setup, including language selection, network connection (Wi-Fi or Ethernet), and Google account sign-in.

OPERATING INSTRUCTIONS

Remote Control Functions



Image: Layout of the Blaupunkt TV remote control, showing buttons for power, navigation, volume, and quick access to streaming services.

The remote control allows you to navigate the TV's features:

- **Power Button:** Turns the TV on or off.
- **Navigation Pad (Up/Down/Left/Right/OK):** For menu navigation and selection.
- **Back Button:** Returns to the previous screen.
- **Home Button:** Accesses the Google TV home screen.
- **Volume Up/Down:** Adjusts the volume level.
- **Mute Button:** Mutes or unmutes the sound.
- **Quick Access Buttons:** Dedicated buttons for Netflix, Prime Video, YouTube, and other services.
- **Google Assistant Button:** Activates voice control.

Google TV Interface Navigation

Google TV organizes your content from various streaming services into a personalized home screen.




Image: Screenshot of the Google TV interface, displaying personalized movie and show recommendations and a unified watchlist.

- Use the navigation pad to browse through recommended content, apps, and settings.
- Select an item by pressing the **OK** button.
- Access the full list of installed apps from the "Apps" tab.

Smart Features

- **Voice Control (Google Assistant):** Press the Google Assistant button on your remote and speak commands to search for content, control smart home devices, or get information.
- **Screen Mirroring:** Cast content from your compatible smartphone or tablet to the TV using the built-in casting feature.
- **Apps & Games:** Access a wide range of applications and games from the Google Play Store.



10000+
APPS AND GAMES



AND MORE...

Image: Display of the TV screen showcasing a selection of over 10,000 available apps and games, including popular streaming services.

MAINTENANCE

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, use a screen cleaner specifically designed for televisions, applied to the cloth, not directly to the screen.
- **Cleaning the Cabinet:** Use a soft, dry cloth to wipe the TV cabinet. Do not use abrasive cleaners or solvents.
- **Software Updates:** The TV may receive automatic software updates. Ensure your TV is connected to the internet to receive these updates, which improve performance and add new features.

TROUBLESHOOTING

Refer to this section for solutions to common issues.

Problem	Possible Solution
No power	Ensure the power cord is securely plugged into both the TV and a working electrical outlet. Check the power indicator light on the TV.
No picture, but sound is present	Check the input source. Press the "Input" button on the remote to cycle through sources. Ensure external devices are powered on and connected correctly.

Problem	Possible Solution
No sound, but picture is present	Check the volume level and ensure the TV is not muted. Verify audio settings in the TV menu. If using external speakers, check their connections and power.
Remote control not working	Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor.
Poor picture quality	Check the cable connections. Adjust picture settings (brightness, contrast, sharpness) in the TV menu. For external devices, ensure they are outputting at the correct resolution.
Wi-Fi connection issues	Restart your router and modem. Go to the TV's network settings and reconnect to your Wi-Fi network. Ensure the TV is within range of your router.

SPECIFICATIONS

Detailed technical specifications for the Blaupunkt 43QD7050 QLED Google TV.




Image: Diagram illustrating the physical dimensions of the Blaupunkt 43QD7050 TV, including screen size, width, height, and depth.

Feature	Detail
Model	43QD7050
Screen Size	43 Inches (108 cm)
Display Technology	QLED
Resolution	4K Ultra HD (3840 x 2160)
Refresh Rate	60 Hz
Operating System	Google TV

Feature	Detail
Sound Output	60 Watts
Audio Features	Dolby Digital Plus, DTS TruSurround, CyberSound Gen2 Technology
Connectivity	Dual Band Wi-Fi, 3 HDMI ports (eARC support), 2 USB ports, Ethernet, Bluetooth
Special Features	4K HDR, Google Assistant, Screen Mirroring, HDR 10+
Memory (RAM/Storage)	2 GB RAM / 16 GB Storage
Product Dimensions (LxWxH)	97 x 10 x 55 cm (without stand)
Item Weight	5.9 kg
Model Year	2024




Image: Representation of the MediaTek MT9602 processor, highlighting its quad-core ARM Cortex A53 CPU and Mali-G52MC1 GPU for performance.

WARRANTY AND SUPPORT

Your Blaupunkt 43QD7050 television comes with a manufacturer's warranty.

- Product Warranty:** 1 year from the date of purchase.
- Remote Accessories Warranty:** 6 months from the date of purchase.
- Warranty Claim:** The brand warranty can be availed using the purchase invoice.
- Items Not Covered:** Light bleeding and dot issues (Mura issues) occurring within acceptable Mura Inspection standards (2% guideline) are not considered panel defects and are not covered.

For customer support, service requests, or further inquiries, please contact:

- Toll-Free Contact:** 1800-274-4342
- Email ID:** consumercare@blaupunkttv.in
- Manufacturer Address:** B-29,30,31, Phase-II, Noida, Gautam Buddha Nagar, Uttar Pradesh, 201301, India.

Please have your product model number (43QD7050) and purchase invoice ready when contacting support.



Related Documents - 43QD7050

<p>BLAUPUNKT</p> <p>Google TV</p> <p>Instruction Manual 50" QLED 4K Ultra HD Google TV - BP500USG98</p>  <p>Enjoy it.</p>	<p><u>Blaupunkt 50" QLED 4K Ultra HD Google TV BP500USG98 Instruction Manual</u></p> <p>Comprehensive instruction manual for the Blaupunkt 50" QLED 4K Ultra HD Google TV, model BP500USG98. Learn about setup, features, safety precautions, and troubleshooting.</p>
 <p>BLAUPUNKT</p> <p>USER'S MANUAL</p> <p>65MCG8000S, 75MCG8000S, 85MCG8000S, 100MCG8000S</p> <p>Enjoy it.</p>	<p><u>Blaupunkt 65MCG8000S, 75MCG8000S, 85MCG8000S, 100MCG8000S LED TV User Manual</u></p> <p>Comprehensive user manual for Blaupunkt LED TVs models 65MCG8000S, 75MCG8000S, 85MCG8000S, and 100MCG8000S, covering setup, operation, safety, troubleshooting, and specifications. Features Google TV.</p>
<p>BLAUPUNKT</p> <p>Instruction Manual 75" 4K Ultra HD Android TV - BP750USG9200</p>  <p>Enjoy it.</p>	<p><u>Blaupunkt 75-inch 4K Ultra HD Android TV BP750USG9200: Instruction Manual</u></p> <p>Get detailed instructions for your Blaupunkt 75-inch 4K Ultra HD Android TV (Model BP750USG9200). This manual covers setup, installation, remote control usage, features, troubleshooting, and technical specifications for optimal viewing experience.</p>
<p>BLAUPUNKT</p> <p>Instruction Manual 58" 4K Ultra HD Smart TV - BP58WOS</p>  <p>Enjoy it.</p>	<p><u>Blaupunkt BP58WOS 58" 4K Ultra HD Smart TV Instruction Manual</u></p> <p>Comprehensive instruction manual for the Blaupunkt BP58WOS 58-inch 4K Ultra HD Smart TV, covering setup, operation, features, settings, troubleshooting, and specifications.</p>
<p>BLAUPUNKT</p> <p>Instruction Manual 58" 4K Ultra HD Smart TV - BP5800AU9100</p>  <p>Enjoy it.</p>	<p><u>Blaupunkt 58" 4K Ultra HD Smart TV BP5800AU9100 Instruction Manual</u></p> <p>This instruction manual provides comprehensive guidance for the Blaupunkt 58-inch 4K Ultra HD Smart TV, model BP5800AU9100. It covers essential information on safety precautions, installation procedures, remote control operation, basic TV functions, menu settings, connectivity options, streaming services, troubleshooting FAQs, and technical specifications.</p>

● BLAUPUNKT

Instruction Manual

65" 1920x1080 4K Ultra HD Smart TV - BP6500AU9100



Enjoy it.

[Blaupunkt 65-inch 4K Ultra HD Smart TV BP6500AU9100 Instruction Manual](#)

Comprehensive instruction manual for the Blaupunkt 65-inch 4K Ultra HD Smart TV, model BP6500AU9100. It covers essential safety precautions, installation procedures, controls and connections, remote operation, basic functions, menu navigation, media playback, streaming services, frequently asked questions, and detailed technical specifications.