

G61

G61 Gaming Keyboard User Manual

Model: G61 | Brand: Generic

INTRODUCTION

Thank you for choosing the Generic G61 Gaming Keyboard. This 61-key mechanical keyboard features vibrant RGB backlighting and versatile dual-mode connectivity (2.4G wireless and Bluetooth), making it an ideal choice for PC and computer gaming. This manual provides detailed instructions on setting up, operating, maintaining, and troubleshooting your new keyboard to ensure optimal performance and longevity.

SAFETY INFORMATION

- Keep the keyboard away from water, moisture, and excessive heat.
- Do not attempt to disassemble or modify the keyboard. This may void the warranty and cause damage.
- Use only the provided charging cable or a certified equivalent.
- Avoid dropping or subjecting the keyboard to strong impacts.
- Clean the keyboard with a soft, dry cloth. Do not use liquid cleaners or aerosols.

PACKAGE CONTENTS

- G61 Gaming Keyboard (Pink)
- USB Wireless Receiver (2.4G)
- USB Charging Cable
- User Manual

PRODUCT OVERVIEW

The G61 is a compact 61-key mechanical keyboard designed for gaming and general use. Its layout optimizes space while retaining essential functions through function key combinations. The keyboard features customizable RGB backlighting and supports both 2.4G wireless and Bluetooth connectivity for versatile use across various devices.



Image: The G61 Gaming Keyboard in pink, showcasing its compact 61-key layout and sleek design.




Image: A detailed view of the G61 keyboard's 61-key layout, highlighting keycap legends and compact form factor.

SETUP

1. Charging the Keyboard

Before first use, fully charge the keyboard. Connect the provided USB charging cable to the keyboard's charging port and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The charging indicator light will show the charging status and turn off when fully charged.

2. Wireless Connection

2.1. 2.4G Wireless Mode

1. Locate the USB wireless receiver.
2. Plug the USB wireless receiver into an available USB port on your computer.
3. Turn on the keyboard. The keyboard should automatically connect to the receiver.



Image: The compact 2.4G USB wireless receiver, essential for wireless connectivity.

2.2. Bluetooth Mode

1. Ensure the keyboard is in Bluetooth pairing mode (refer to Operating Instructions for mode switching).
2. On your device (PC, laptop, tablet, phone), enable Bluetooth and search for new devices.
3. Select "G61 Keyboard" or a similar name from the list of available devices to pair.
4. Follow any on-screen prompts to complete the pairing process.

3. Compatibility

The G61 Gaming Keyboard is compatible with a wide range of operating systems, including Windows, Android, and iOS devices, ensuring broad usability across your platforms.

2.4G WIRELESS CONNECTION

V5.0, 2.4G wireless arbitrary switching



Image: Icons indicating compatibility with Windows, Android, and iOS operating systems.

OPERATING INSTRUCTIONS

1. Basic Key Functions

The G61 keyboard utilizes a compact 61-key layout. Many functions are accessed via the **Fn** key in combination with other keys. Refer to the keycap legends for specific **Fn** combinations (e.g., **Fn + 1-0** for F-keys, **Fn + P** for Print Screen).

2. RGB Backlight Control

The keyboard features dynamic RGB backlighting with multiple modes and colors. Use the following key combinations to control the lighting:

- **Fn + I**: Backlight ON/OFF
- **Fn + K**: Switch Light Mode (cycle through various lighting effects)
- Other **Fn** combinations may control brightness or specific color changes.

61 KEY GAMING KEYPAD

removable keyboard
Multi-use keyboard



2.4G wireless receiver

Image: Illustration showing the Fn + I and Fn + K key combinations for backlight control.

61-keys Wireless Keyboard

RGB 7-color illuminated keyboard



Desktop computer



Notebook computer



Tablet PC



Android phone



Phone

Image: Depiction of the keyboard with various RGB backlight colors, demonstrating the customizable lighting.

3. Dual Mode Switching

The G61 keyboard supports both 2.4G wireless and Bluetooth connectivity. To switch between modes, use the designated switch on the keyboard (usually on the back or side) or a specific **Fn** key combination. Ensure the correct mode is selected for your desired connection type.

MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to wipe the keyboard surface. For dust between keycaps, use compressed air. Do not spray liquid directly onto the keyboard.
- **Storage:** When not in use for extended periods, store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the keyboard frequently. Charge it when the low battery indicator appears.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Keyboard not responding	Low battery; Incorrect connection mode; Driver issue; Receiver not plugged in (2.4G)	Charge the keyboard; Switch to correct mode (2.4G/BT); Reinstall drivers; Plug in receiver securely.
Bluetooth pairing fails	Keyboard not in pairing mode; Device Bluetooth off; Interference	Ensure keyboard is in pairing mode; Turn on device Bluetooth; Move closer to device; Try pairing again.
Backlight not working	Backlight turned off; Software glitch	Press Fn + I to turn on; Restart keyboard.
Keys not registering	Dust/debris under keycap; Faulty switch	Clean under keycap with compressed air; If issue persists, contact support.

SPECIFICATIONS

Feature	Detail
Model	G61
Keys	61 Keys
Connectivity	Dual Mode (2.4G Wireless, Bluetooth)
Backlight	RGB (7-color illuminated)
Operation Style	Mechanical
Interface Type	Bluetooth
Application	Laptop, PC, Computer
Compatible Devices	Laptop
Operating System	Windows 7 and above, Android, iOS
Color	Pink
Material	Other
Recommended Use	Gaming

WARRANTY AND SUPPORT

The manufacturer commits to a 12-month warranty for this product. This warranty covers manufacturing defects and issues arising from normal use.

If you encounter any problems with your G61 Gaming Keyboard, such as damaged products or incorrect items received, please do not hesitate to contact customer support. We aim to reply to all inquiries within 24 hours to provide assistance and resolution.

For support, please refer to the contact information provided by your retailer or the product's packaging.

