

[Manuals.plus](#) /

› [charmast](#) /

› Charmast Portable Charger User Manual

charmast W1115

Charmast Portable Charger User Manual

MODEL: W1115

Introduction

Thank you for choosing the Charmast Portable Charger. This 10000mAh power bank is designed for convenience and efficiency, featuring built-in cables and a foldable wall plug for seamless charging on the go. This manual provides essential information for setting up, operating, and maintaining your device.

What's in the Box

- Portable charger with built-in cables
- User manual
- Mesh pouch

Product Features

Built-in Cables and Foldable Wall Plug

The Charmast portable charger integrates essential charging cables (Type-C, Lightning, Micro-USB) and a foldable AC wall plug, eliminating the need to carry extra accessories. This design ensures maximum portability and convenience.



Image: The Charmast portable charger showcasing its built-in cables and foldable wall plug.

10000mAh High Capacity

Equipped with a 10000mAh battery, this power bank provides multiple charges for most smartphones and tablets. For example, it can provide approximately 1.55 charges for an iPhone 15 or 1 charge for a Samsung Galaxy S23 Ultra.

6-in-1 Portable Charger



Wall Plug



USB A Port



USB C Port
(Recharge Only)



USB C & Micro



For iPhone



Image: The portable charger connected to and simultaneously charging an iPhone, AirPods, and an iPad.

Slim and Portable Design

Measuring just 5.95" x 2.76" x 0.72" and weighing only 0.5 lbs, this charger is designed to be ultra-slim and lightweight, making it an ideal travel companion that fits easily into any bag or pocket.

Ultra-Slim Portable Design



Image: A side-by-side comparison of the portable charger and a smartphone, highlighting its slim dimensions.

Digital Display

A clear digital display shows the exact remaining battery percentage, so you always know when it's time to recharge the power bank.

Multiple Safety Protection



Over-Discharge
Protection



Short-Circuit
Protection



Over Current
Protection



Over Voltage
Protection




Image: Close-up of the portable charger's digital display showing "100" percent battery.

Multiple Recharging Options

Recharge the power bank directly from a wall socket using its built-in foldable plug, or via a 5V-2.6A charger for flexibility.

Two Recharging Options

6 hrs

Buil-in Wall plug



5 hrs

5V-2.6A Charger



Image: The portable charger being recharged in two ways: directly plugged into a wall outlet and via a USB-C cable connected to a power adapter.

Travel Friendly

This portable charger is approved for carry-on bags on airplanes, making it an essential travel accessory. It is not permitted in checked bags.

Wake up, Ready to Go



Tips: The output of pass-through charging will be only 1A

Image: A person holding the portable charger with an airplane in the background, indicating its suitability for air travel in carry-on luggage.

Official Product Video

Watch this official product video from Charmast to see the portable charger in action, highlighting its built-in cables and plug, and its compact design for everyday use and travel.

Your browser does not support the video tag.

Video: Charmast Portable Charger with Built-in Cables and Plug. This video demonstrates the charger's features and ease of use.

Setup

Initial Charging of the Power Bank

Before first use, fully charge your Charmast Portable Charger. You can do this by:

1. **Using the Built-in Wall Plug:** Fold out the AC wall plug and insert it directly into a standard wall outlet. The digital display will show the charging progress.
2. **Using a USB-C Cable:** Connect a USB-C cable to the power bank's USB-C input port and plug the other end into a compatible USB wall adapter (not included).

The display will show "100" when fully charged.

Operating Instructions

Charging Your Devices

To charge your smartphone, tablet, or other compatible devices:

1. **Identify the Correct Built-in Cable:**
 - For Apple devices (iPhone, iPad): Use the built-in Lightning cable.
 - For Android devices (Samsung Galaxy, etc.) or other USB-C devices: Use the built-in USB-C cable.
 - For older Android devices or other Micro-USB devices: Use the built-in Micro-USB cable.
2. **Connect the Cable:** Gently pull out the appropriate built-in cable and plug it into your device's charging port.
3. **Start Charging:** The power bank will automatically begin charging your device. The digital display will show the remaining battery percentage of the power bank.
4. **Using External Cables:** You can also use your own USB-A or USB-C cables with the corresponding output ports on the power bank.

Recharging the Power Bank

When the power bank's digital display shows a low percentage, recharge it using one of the following methods:

1. **Wall Charging (Recommended):** Fold out the integrated AC wall plug and insert the power bank directly into a standard wall outlet.
2. **USB-C Input:** Connect a USB-C cable to the power bank's USB-C input port and to a USB wall adapter or computer USB port.

The digital display will flash during charging and show "100" when fully charged.

Maintenance

- Keep the power bank away from extreme temperatures, direct sunlight, and liquids.
- Do not disassemble or attempt to repair the device yourself.
- Clean the surface with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Store in a cool, dry place when not in use.

Troubleshooting

Problem	Possible Solution
Power bank not charging	Ensure the wall plug is fully inserted or the USB-C cable is properly connected to a working power source. Check the power source.
Device not charging from power bank	Ensure the power bank has sufficient charge. Check if the built-in cable is securely connected to your device. Try a different cable or port if using external cables.
Slow charging	Ensure your device supports fast charging. Some devices or cables may limit charging speed.
Digital display not working	Press the power button to activate the display. If it remains off, the battery might be completely depleted or there could be an internal issue.

Specifications

Feature	Detail
Model Number	W1115
Battery Capacity	10000mAh
Product Dimensions	5.95 x 2.76 x 0.72 inches
Item Weight	9.1 ounces
Input (AC Wall Plug)	5V-2.6A
Output (USB-A / USB-C)	Up to 5V-3A
Special Features	Digital Display, Slim, Built-in Wall Plug, Built-in Cables, Fast Charging
Connector Type	Built-in Cables (Lightning, USB-C, Micro-USB)

Warranty and Support

Charmast products come with a standard manufacturer's warranty. For detailed warranty information, product support, or technical assistance, please refer to the official Charmast website or contact their customer service directly. Keep your purchase receipt for warranty claims.

Contact Information: Please visit [Charmast Store on Amazon](#) for more details.