

Manuals.plus /
› **VEGER** /
› VEGER Portable Charger for iPhone with Built in Cables and Wall Plug, 10000mah Slim Fast Charging USB C Power Bank, Travel Essential Battery Pack Compatible with iPhone, iPad, Samsung etc(Navy) User Manual

VEGER V1115

VEGER Portable Charger User Manual

Model: V1115 | Brand: VEGER
Your essential travel companion for fast and versatile charging.

1. INTRODUCTION

Thank you for choosing the VEGER 10000mAh Portable Charger. This compact and versatile power bank is designed to keep your devices charged on the go, eliminating the need for multiple cables and adapters. With its built-in cables and wall plug, it offers unparalleled convenience for all your charging needs.



Image: The VEGER Portable Charger, highlighting its compact design and integrated charging solutions.

2. PRODUCT OVERVIEW

The VEGER Portable Charger is an all-in-one solution featuring a 10000mAh capacity. It includes:

- **Built-in Foldable AC Wall Plug:** For direct recharging of the power bank.
- **Built-in Cables:** Includes a USB-C cable and a Lightning cable for iPhone.
- **Additional Output Ports:** One USB-C output and one USB-A output for expanded compatibility.
- **Digital Display:** Shows the remaining battery percentage.

All in One Portable Charger



AC Plug

1



USB &
USB C

2



Type-C &
Micro USB

3



For iPhone

4



Image: Detailed view of the VEGA Portable Charger's integrated features and ports.

3. SETUP AND RECHARGING THE POWER BANK

Before first use, fully charge your VEGA Portable Charger. You have two convenient options for recharging:

1. **Using the Built-in AC Wall Plug:** Simply unfold the integrated wall plug and insert it directly into any standard wall outlet. The digital display will show the charging progress.
2. **Using the USB-C Input Port:** Connect a USB-C cable (not included) to the power bank's USB-C input port and a compatible USB wall adapter.

A full charge typically takes approximately 6 hours via the wall plug or 5 hours via the USB-C port.

Not Extra Adapter or Cables when Outside

VS



Your browser does not support the video tag.

Video: Official Veger demonstration of the portable charger's features, including its built-in cables and wall plug.

4. OPERATING INSTRUCTIONS: CHARGING YOUR DEVICES

The VEGER Portable Charger offers multiple ways to charge your electronic devices:

- **Using Built-in Cables:**
 - For iPhones: Use the built-in Lightning cable.
 - For USB-C devices: Use the built-in USB-C cable.
- **Using USB-A/USB-C Output Ports:** Connect your device's charging cable to the available USB-A or USB-C output ports on the power bank.

You can charge up to 4 devices simultaneously with fast charging speeds of up to 15W per cable and USB port output.

Simultaneously Charging 4 Devices

4
Devices



Image: Demonstrating the ability to charge multiple devices at once using the power bank's various outputs.

5. UNIVERSAL COMPATIBILITY

This portable battery charger is widely compatible with a broad range of devices, including but not limited to:

- All iPhone models (via built-in Lightning cable)
- iPad models
- Samsung smartphones (via built-in USB-C or external cable)
- Google Pixel phones (via built-in USB-C or external cable)
- Other Android smartphones and tablets
- Various other USB-C and USB-A powered devices

2 Options for recharging the power bank

6 hrs
By Wall Plug

5 hrs
By USB C Port



Image: Visual representation of the wide range of devices compatible with the VEGER Portable Charger.

6. SAFETY INFORMATION

The VEGER Portable Charger is equipped with comprehensive protection systems to ensure safe and reliable charging:

- **Short Circuit Protection:** Prevents damage from electrical shorts.
- **Over Current Protection:** Safeguards against excessive current flow.
- **Over Voltage Protection:** Protects devices from voltage surges.
- **Over Heat Protection:** Prevents overheating during operation.

Always use the device in a well-ventilated area and avoid exposing it to extreme temperatures or direct sunlight. Do not disassemble or attempt to repair the device yourself.

Comprehensive Protections



Short circuit
protection



Over current
protection



Over
voltage



Over heat
protection

Image: Visual representation of the multi-layered safety protections built into the power bank.

7. MAINTENANCE

To ensure the longevity and optimal performance of your VEGER Portable Charger:

- Keep the device dry and away from moisture.
- Clean the exterior with a soft, dry cloth. Avoid harsh chemicals.
- Store in a cool, dry place when not in use.
- Avoid dropping or subjecting the device to strong impacts.

8. TROUBLESHOOTING

If you encounter any issues with your VEGER Portable Charger, please try the following common troubleshooting steps:

- **Device not charging:** Ensure the power bank itself is fully charged. Check all cable connections for proper seating.
- **Slow charging:** Verify that your device supports fast charging and that the cables are correctly connected.
- **Digital display not working:** Press the power button briefly to activate the display. If it remains off, the power bank may be fully depleted or require service.

For persistent issues, please refer to the Warranty and Support section.

9. SPECIFICATIONS

Feature	Detail
Product Dimensions	5.9 x 2.7 x 0.72 inches
Item Weight	8 ounces
Model Number	V1115
Battery Capacity	10000 Milliamp Hours
Battery Type	1 Lithium Polymer batteries (included)
Connector Type	USB C, Lightning
Special Features	Built-in Cables, Built-in Wall Plug

10. WARRANTY AND CUSTOMER SUPPORT

Your VEGER Portable Charger comes with a worry-free **12-month guarantee**. We are committed to providing excellent customer service.

If you have any problems or questions, please do not hesitate to contact our friendly customer service team. We are available **7 days a week, 24 hours a day**, and will strive to resolve your issue within 12 hours.

For support, please visit the official VEGER website or contact us through your purchase platform.

For more information, visit the [VEGER Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CQMW5NLG>

More documents and user manuals: <https://manuals.plus/>