Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VEGER 10000mAh Portable Charger

VEGER 10000mAh Portable Charger User Manual

Model: 10000mAh Slim Fast Charging USB C Power Bank

Brand: VEGER

Introduction

This user manual provides essential information for the safe and efficient operation of your VEGER 10000mAh Portable Charger. Please read this manual thoroughly before using the device to ensure proper functionality and to prevent damage.



Image: Front and back view of the VEGER 10000mAh Portable Charger, highlighting its compact design, built-in USB-C and Lightning cables, and integrated foldable wall plug.

Product Features

- **Integrated Cables & Wall Plug:** Features built-in USB-C and Lightning cables, along with a foldable AC wall plug for convenient recharging.
- **Multi-Device Charging:** Equipped with 4 outputs (2 cable outputs, 1 USB-C port, 1 USB-A port) to charge up to 4 devices simultaneously.
- **High Capacity & Portability:** 10000mAh capacity in a slim, lightweight design (5.9 x 2.7 x 0.72 inches, 8oz).
- **Universal Compatibility:** Compatible with a wide range of devices including iPhones, iPads, Samsung, Google Pixel, and other tablets.
- **Fast Charging:** Delivers up to 15W fast charging speed per cable and USB port output.
- **Comprehensive Protections:** Built-in safeguards against short circuit, over current, over voltage, and over heat.

Setup

Initial Charging of the Power Bank

Before first use, it is recommended to fully charge your VEGER portable charger. There are two primary methods for recharging the power bank:

1. **Using the Built-in Wall Plug:**

   Extend the foldable AC wall plug from the side of the power bank. Insert the plug directly into a standard wall outlet. The digital display will show the charging progress. A full charge typically takes approximately 6 hours using this method.

2. **Using the USB-C Port:**

   Connect a USB-C charging cable (not included, but the power bank has a built-in USB-C output cable) to the USB-C input/output port on the power bank and the other end to a compatible USB wall adapter or computer USB port. A full charge typically takes approximately 5 hours using this method.



Image: The VEGER portable charger demonstrating its two recharging options: directly via the built-in foldable wall plug and via its USB-C port using an external cable.

The digital display will show the battery percentage, indicating the current charge level of the power bank.

Operating Instructions

Charging Your Devices

The VEGER portable charger offers multiple ways to charge your electronic devices:

- **Using Built-in Cables:**

  Locate the built-in USB-C cable or the built-in Lightning cable. Connect the appropriate cable directly to your device's charging port. The power bank will automatically begin charging your device.

- **Using USB-A or USB-C Ports:**

  For devices requiring other cable types or if you prefer to use your own cables, connect your device's charging cable to the USB-A output port or the USB-C input/output port on the power bank. Ensure the cable is securely connected to both the power bank and your device.

The power bank can charge up to four devices simultaneously. The digital display will show the remaining battery percentage of the power bank while charging devices.



Image: The VEGER portable charger connected to and simultaneously charging a tablet, two smartphones, and a pair of wireless earbuds, demonstrating its multi-device charging capability.

Compatibility

This power bank is designed for wide compatibility:

- **For iPhones/iPads series:** iPhone 13/12/11/Xs/X/8/SE, iPad Air, iPad Pro.
- **Type-C Devices:** Google Pixel series (P5/P4/P3), Samsung S21/S20/S10/S9/Z Fold2/Note20/Note10, and more.

- **Micro USB Devices:** Vivo Z5x/Z3x, and various other Micro USB compatible devices.
- **Other Devices:** Compatible with Apple AirPods Pro/AirPods and other small electronic devices.




Image: A visual representation of the VEGER portable charger's universal compatibility with different types of smartphones and tablets, including iPhones, iPads, and Android devices.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the surface of the power bank. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight, extreme temperatures, and humidity.
- **Battery Care:** To prolong battery life, fully charge the power bank at least once every three months if not in regular use. Avoid completely draining the battery frequently.
- **Handling:** Do not drop, disassemble, or attempt to repair the device yourself. This can void the warranty and cause damage.

Troubleshooting

Problem	Possible Cause	Solution
Power bank not charging	Wall plug not fully inserted; USB-C cable faulty or not connected properly; power bank battery completely depleted.	Ensure wall plug is securely inserted or USB-C cable is properly connected. Try a different wall outlet or USB-C cable. Allow a few minutes for the power bank to respond if deeply discharged.
Device not charging from power bank	Power bank battery is low or empty; device cable faulty or not connected properly; device is not compatible.	Recharge the power bank. Ensure the built-in cable or external cable is securely connected to both the power bank and your device. Try a different cable. Verify device compatibility.
Slow charging	Using a non-fast charging cable/adapter; multiple devices charging simultaneously; device's charging input limit.	Ensure you are using appropriate cables. Charging multiple devices simultaneously may reduce individual charging speeds. Check your device's charging specifications.
Power bank gets warm during use	Normal operation during charging/discharging.	This is normal. If it becomes excessively hot, disconnect immediately and contact customer service.

Specifications

Brand: VEGER

Model: 10000mAh Portable Charger

Battery Capacity: 10000 Milliamp Hours

Connector Type: USB C, Lightning (built-in cables), USB-A (output port)

Special Feature: Built-in Cables, Built-in Wall Plug

Dimensions: 5.9 x 2.7 x 0.72 inches

Weight: 8 oz

Max Output Speed: Up to 15W per port/cable

Color: Green (as per current product variant)



Image: A hand holding the VEGER portable charger, illustrating its ultra-compact size and portability.

Safety Protections

The VEGER portable charger is equipped with multiple safety features to ensure reliable and secure charging:

- Short Circuit Protection
- Over Current Protection
- Over Voltage Protection

- Over Heat Protection



Image: An abstract diagram representing the internal chip and comprehensive protection mechanisms of the VEGER power bank, including safeguards against short circuit, over current, over voltage, and over heat.

Warranty and Support

Your VEGER 10000mAh Portable Charger comes with a worry-free 12-month guarantee. For any issues or inquiries, please refer to the contact information provided on the product packaging or the included welcome guide. Our friendly

customer service team is available 7 days a week, 24 hours a day, and aims to resolve problems within 12 hours.

© 2024 VEGER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CQMZC8JX

More documents and user manuals: **https://manuals.plus/**