Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Blooy 3120150 + 3120151

Instruction Manual: Blooy Upper & Lower Knife Kit

Model: 3120150 + 3120151

Introduction

This instruction manual provides essential information for the installation, operation, and maintenance of the Blooy Upper and Lower Knife Kit. This kit is designed as a replacement part for specific Yamato flatbed (interlock) coverstitch sewing machines, ensuring precise fabric cutting during the sewing process. Proper installation and care are crucial for optimal performance and longevity of the knives.

Product Overview

The Blooy Knife Kit consists of two primary components:

- **3120150 Upper Knife (Fixed Knife):** This knife remains stationary and works in conjunction with the lower knife to cut fabric.
- **3120151 Lower Knife (Movable Knife):** This knife moves in a shearing action against the upper knife to perform the cut.




Figure 1: The Blooy Upper and Lower Knife Kit, showing both the fixed upper knife and the movable lower knife.

Individual Knife Components



Figure 2: Close-up view of the Blooy 3120150 Upper Knife, also known as the fixed knife.



Figure 3: Close-up view of the Blooy 3120151 Lower Knife, also known as the movable knife.

Compatibility

This knife kit is specifically designed to fit the following Yamato flatbed (interlock) coverstitch sewing machine models:

- Yamato VC2840P
- Yamato VC3845P

Ensure your machine model matches one of the listed compatible models before attempting installation.

Setup and Installation

Replacing sewing machine knives requires careful attention to detail. If you are unsure about any step, it is recommended to consult a qualified sewing machine technician or refer to your specific sewing machine's service manual.

Safety Precautions:

- **Always disconnect the sewing machine from the power supply** before performing any maintenance or installation.
- Knives are sharp. Handle them with extreme care to prevent injury.
- Keep small parts away from children.

General Installation Steps (Refer to your machine's manual for precise instructions):

1. **Prepare the Machine:** Turn off and unplug the sewing machine. Open the necessary covers to access the knife mechanism.
2. **Remove Old Knives:** Carefully loosen the screws holding the old upper and lower knives in place. Remove the old knives, noting their exact orientation and position.
3. **Clean the Area:** Use a brush or compressed air to clean any lint or debris from the knife area.
4. **Install New Knives:**
    - First, install the new **3120150 Upper Knife (Fixed Knife)**. Ensure it is seated correctly and tighten its retaining screws, but do not overtighten.
    - Next, install the new **3120151 Lower Knife (Movable Knife)**. Position it so that its cutting edge aligns properly with the upper knife.
5. **Adjust Knife Alignment:** This is a critical step. The lower knife must pass very closely to the upper knife to create a clean cut. Refer to your machine's manual for specific gap and overlap adjustments. Typically, there should be a minimal gap (often less than 0.1mm) between the cutting edges.
6. **Test the Cut:** Manually turn the handwheel to observe the knife action. Once satisfied with the alignment, close the machine covers and plug it back in. Perform a test sew on scrap fabric to verify clean cutting.

Operating Considerations

Once installed, the knives operate automatically as part of the coverstitch machine's fabric trimming mechanism. Ensure that:

- Only fabric is fed into the cutting path. Avoid sewing over pins, needles, or other hard objects, as this can dull or damage the knife edges.
- The machine is properly threaded and tensioned, as incorrect settings can sometimes affect fabric feeding and cutting.

Maintenance

Regular maintenance will extend the life of your knives and ensure consistent cutting performance:

- **Cleaning:** Periodically clean the area around the knives to remove lint and fabric dust. Use a small brush or vacuum cleaner attachment. Accumulation of debris can hinder knife movement and cutting efficiency.
- **Inspection:** Regularly inspect the knife edges for signs of dullness, nicks, or damage. A dull knife will result in frayed fabric edges or skipped cuts.
- **Replacement:** Knives are wear-and-tear parts. Replace them when they become dull or damaged, even after sharpening attempts. The frequency of replacement depends on usage and the types of fabric sewn.
- **Lubrication:** Refer to your sewing machine's manual for specific lubrication points around the knife mechanism. Proper lubrication ensures smooth operation of the movable knife.

Troubleshooting

If you experience issues related to fabric cutting, consider the following:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Fabric not cutting cleanly / Frayed edges	Dull knives, improper knife alignment, lint buildup.	Replace knives, adjust knife alignment (refer to machine manual), clean knife area.
Knives not moving smoothly	Lint or debris obstruction, lack of lubrication.	Clean the mechanism, apply appropriate sewing machine oil as per machine manual.
Loud noise from knife area	Improper installation, loose screws, damaged knives.	Re-check installation, tighten screws, inspect knives for damage and replace if necessary.

If troubleshooting steps do not resolve the issue, contact a professional sewing machine technician.

Specifications

Attribute	Detail
Brand	Blooy
Model Number	3120150 + 3120151
Part Codes	3120150 (Upper Knife), 3120151 (Lower Knife)
Compatibility	Yamato VC2840P, VC3845P Flatbed (Interlock) Coverstitch Sewing Machines
Color	Silver
Number of Items	2 (1 set of upper and lower knives)
Manufacturer	Blooy
ASIN	B0CQNMKYHR
Date First Available	20 December 2023

Warranty and Support

For information regarding warranty coverage or technical support for your Blooy Knife Kit, please refer to the purchase documentation or contact the seller directly. As this is a replacement part, warranty terms may vary. Always ensure you purchase genuine Blooy parts for optimal performance and compatibility.
For support related to your Yamato sewing machine, please consult the official Yamato service manual or contact an authorized Yamato service center.

© 2024 Blooy. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CQNMKYHR

More documents and user manuals: **https://manuals.plus/**