Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VONLUCE HCF1013GF

VONLUCE Semi Flush Mount Ceiling Light

Model: HCF1013GF

Instruction Manual

1. Product Overview

The VONLUCE Semi Flush Mount Ceiling Light is designed to provide elegant and ambient illumination for various indoor spaces. Featuring a captivating flower-shaped fabric shade and an antique brass canopy, this fixture adds a timeless charm suitable for contemporary minimalist to Art Deco interior styles. It supports three E26 base bulbs (not included) and is dimmer compatible, allowing for precise control over brightness. Its gentle light diffusion makes it ideal for bedrooms, living rooms, dining rooms, kitchen islands, or hallways.



Figure 1: VONLUCE Semi Flush Mount Ceiling Light.




Figure 2: The ceiling light fixture installed in a kid's room, bedroom, hallway, and living room, demonstrating its versatility.

2. Safety Information

Please read and understand all instructions before beginning installation and use. Failure to follow these instructions may result in electric shock, fire, or other injuries that could be hazardous or even fatal.

- **WARNING:** To avoid electric shock, ensure power is turned OFF at the circuit breaker or fuse box before installation, maintenance, or bulb replacement.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Contact a qualified electrician if you are unfamiliar with proper electrical wiring connections.
- Do not exceed the maximum wattage specified for the light bulbs (60W per bulb).
- This fixture is designed for indoor use only. Do not expose to water or moisture.
- Handle the fabric shade and glass components with care to prevent damage.
- Keep packaging materials away from children.

3. Package Contents

Carefully unpack your fixture and check that all parts are included. If any parts are missing or damaged, do not attempt to assemble or install the product. Contact customer service for assistance.

- VONLUCE Semi Flush Mount Ceiling Light Fixture (1)
- Mounting Hardware (1 set)
- Instruction Manual (1)

Note: Light bulbs are **NOT** included and must be purchased separately. The fixture requires three E26 base bulbs.

4. Setup & Installation

Installation of this ceiling light fixture is designed to be straightforward. However, if you are unsure about any steps, it is recommended to consult a qualified electrician.

Before You Begin:

1. **Turn off Power:** Locate the circuit breaker or fuse box that supplies power to the light fixture location. Turn off the main power switch. Verify the power is off by attempting to turn on the light switch for the fixture.
2. **Gather Tools:** You will need a screwdriver, wire strippers, electrical tape, and possibly a ladder.
3. **Inspect Components:** Ensure all components are present and undamaged.



Figure 3: Key components of the light fixture.

Installation Steps:

1. **Attach Mounting Bracket:** Secure the mounting bracket (included in hardware) to the electrical junction box in the ceiling using the provided screws. Ensure it is firmly attached.
2. **Connect Wires:** Carefully connect the electrical wires from the fixture to the corresponding wires from the junction box.
    - Connect the **black** wire (live) from the fixture to the**black** wire (live) from the junction box.
    - Connect the **white** wire (neutral) from the fixture to the**white** wire (neutral) from the junction box.
    - Connect the **ground** wire (bare copper or green) from the fixture to the**ground** wire from the junction box.

    Use wire nuts (included) to secure connections and wrap with electrical tape for added safety.
3. **Mount Fixture:** Carefully push the wired connections into the junction box. Align the fixture's canopy with the mounting bracket and secure it with the decorative nuts or screws provided.
4. **Install Bulbs:** Screw three E26 base light bulbs (not included) into the sockets. Ensure bulbs do not exceed 60W

each.

5. **Attach Shade:** Carefully place the fabric shade onto the fixture and secure it according to the specific design (usually by screwing a finial or ring at the bottom).
6. **Restore Power:** Once installation is complete and all components are securely in place, turn the power back on at the circuit breaker.

5. Operating Instructions

The VONLUCE Semi Flush Mount Ceiling Light is operated via a standard wall switch. For dimming functionality, ensure you use dimmable bulbs and a compatible dimmer switch (not included).

- **Turning On/Off:** Flip the wall switch connected to the fixture to turn the light on or off.
- **Dimming:** If using dimmable bulbs and a compatible dimmer switch, adjust the dimmer switch to control the light intensity.
- **Bulb Compatibility:** This fixture is compatible with CFL, LED, or incandescent light bulbs with an E26 base, rated up to 60W per bulb.




Figure 4: Light fixture in ON and OFF states.




Figure 5: Fixture dimensions and compatible bulb types.

6. Maintenance

Regular maintenance will help preserve the appearance and functionality of your light fixture.

- **Cleaning:** Before cleaning, ensure the power is turned off at the circuit breaker. Use a soft, dry cloth to wipe down the fixture. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish or fabric. For the fabric shade, a light dusting or gentle vacuuming with a brush attachment is recommended.
- **Bulb Replacement:** Always turn off the power before replacing bulbs. Allow bulbs to cool completely before handling. Unscrew old bulbs and screw in new E26 base bulbs, ensuring they do not exceed the maximum 60W wattage.

7. Troubleshooting

If you encounter issues with your light fixture, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connections. Faulty bulb(s).	Check the circuit breaker and wall switch. Turn off power, then check and tighten all wire connections. Replace bulb(s) with new ones.
Light flickers or dims unexpectedly.	Loose bulb. Incompatible dimmer switch or bulbs. Loose wire connections.	Tighten bulb(s). Ensure both bulbs and dimmer switch are compatible with dimming. Turn off power, then check and tighten all wire connections.
Light appears dull or yellow.	Incorrect bulb color temperature. Protective film on diffuser (if applicable).	Ensure bulbs with desired color temperature (e.g., "daylight" or "cool white") are used. Some diffusers may have a brown protective film that needs to be peeled off. Carefully inspect and remove if present.

If the problem persists after trying these solutions, please contact VONLUCE customer support.

8. Specifications

Feature	Detail
Brand	VONLUCE
Model Name	Ceiling Light Fixture
Item Model Number	HCF1013GF
Color	Gold (Fixture), White (Shade)
Material	Metal, Fabric
Style	Modern
Light Fixture Form	Close to Ceiling / Semi Flush Mount
Product Dimensions (L x W x H)	13"L x 13"W x 6"H (approx. 12.6" diameter)
Item Weight	3.01 pounds
Power Source	AC
Voltage	110 Volts
Number of Light Sources	3
Bulb Base	E26

Feature	Detail
Max Wattage per Bulb	60 watts
Light Source Type	LED, Incandescent, or CFL (not included)
Special Feature	Anti-Rust, Dimmable (with compatible bulbs/switch)
Indoor/Outdoor Usage	Indoor
Assembly Required	No (refers to main fixture assembly, installation is required)

9. Warranty and Support

For warranty information regarding your VONLUCE Semi Flush Mount Ceiling Light, please refer to the documentation provided with your purchase or visit the official VONLUCE website. Standard warranty terms typically cover manufacturing defects.

If you require technical assistance, have questions about installation, or need to report a missing/damaged part, please contact VONLUCE customer support directly. Contact details can usually be found on the product packaging or the official brand website.

VONLUCE Official Store: Visit VONLUCE Store on Amazon

© 2025 VONLUCE. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CQNPYPK7

More documents and user manuals: **https://manuals.plus/**