

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [WAMPAT](#) /

› [WAMPAT Oak Dresser and Nightstands with Charging Station User Manual](#)

WAMPAT W11F409ACx2+W11F4042C-D

WAMPAT Oak Dresser and Nightstands with Charging Station User Manual

Brand: WAMPAT | Model: W11F409ACx2+W11F4042C-D

1. PRODUCT OVERVIEW

This manual provides instructions for the assembly, operation, and maintenance of your WAMPAT Oak Dresser and Nightstands with Charging Station. This versatile furniture piece is designed for various rooms including bedrooms, living rooms, kids' rooms, and hallways.

The unit features a 4-in-1 multipurpose design, allowing it to be used as a large dresser, a TV stand for televisions up to 100 inches, or separated into three-drawer dressers and a set of two end tables. It offers extensive storage with 8 drawers and 2 storage cabinets, including an adjustable shelf. One of the end tables is equipped with a charging station for convenient device charging.



Figure 1: WAMPAT Oak Dresser and Nightstands with Charging Station.

2. SAFETY INFORMATION

To ensure safe use and prevent injury, please adhere to the following safety guidelines:

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use.
- Do not overload drawers or shelves.
- Use the provided anti-tipping kit to secure the dresser to a wall. This is crucial for preventing accidental tipping, especially in households with children or pets.
- Keep small parts away from children during assembly.

Anti-tipping Furniture Straps

Protect your kids and pets



Figure 2: Diagram illustrating the installation of anti-tipping furniture straps for enhanced safety.

3. ASSEMBLY INSTRUCTIONS

This product is shipped in 3 packages and requires assembly. Please ensure all parts are present before beginning. Follow the steps carefully. For visual guidance, refer to the assembly videos provided below.

3.1. Dresser Assembly

The following video demonstrates the general assembly process for a WAMPAT dresser. While the model shown may vary slightly, the fundamental steps for constructing the frame, drawers, and attaching legs are applicable.

Video 1: General assembly guide for a WAMPAT dresser. This video illustrates the process of screwing cam bolts, inserting dowels, securing panels, attaching legs, and sliding in back panels.

3.2. End Table with Charging Station Assembly

This video specifically guides you through the assembly of the end tables, including the integration of the charging station. Pay close attention to the steps for installing the electrical components.

Video 2: Assembly instructions for the WAMPAT end tables with integrated charging station. This video details the steps for assembling the end table structure and installing the power outlet module.

3.3. Key Assembly Steps and Features

- **Wooden Gourd Legs:** The solid wood round gourd furniture legs are attached to the base panels, providing stability and aesthetic appeal.
- **Smooth Metal Drawer Sliders:** The pre-assembled drawer glides ensure smooth opening and closing of the drawers.
- **Anti-Tipping Kit:** Always install the anti-tipping kit to secure the dresser to the wall, preventing accidental falls.



Figure 3: Detailed view of the wooden gourd legs, smooth metal drawer sliders, and the charging station connector.

4. OPERATING INSTRUCTIONS

4.1. Charging Station

One of the included end tables features a built-in charging station. This station is equipped with 2 standard AC outlets and 2 USB ports, allowing you to conveniently charge mobile phones, table lamps, and other electronic

devices. The power cable length is 6.5 ft.


- Plug the power cable into a standard wall outlet.
- Connect your devices to the AC outlets or USB ports as needed.
- Ensure devices are compatible with the 120V/12A output.



120V/12A
{2 AC Outlets}



120V/12A
{2 USB Ports}



6.5-Foot
{Power Cord}

Figure 4: Close-up of the integrated charging station, showing the AC outlets and USB ports.

5. MAINTENANCE

To maintain the appearance and longevity of your WAMPAT dresser, follow these simple maintenance tips:

- **Cleaning:** The smooth, waterproof surface can be easily cleaned with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Wipe up spills immediately to prevent staining or water damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Tighten Fasteners:** Periodically check and tighten all screws and fasteners to ensure structural integrity.

6. TROUBLESHOOTING

If you encounter any issues with your dresser, consider the following common solutions:

- **Drawers not sliding smoothly:** Ensure the metal drawer sliders are clean and free of debris. Check that the drawers are correctly aligned on their tracks.
- **Dresser feels unstable:** Verify that all assembly hardware is securely tightened. Confirm the anti-tipping kit is properly installed and anchored to the wall. Ensure the dresser is placed on a level surface.
- **Charging station not working:** Check if the power cable is securely plugged into both the unit and the wall outlet. Test the wall outlet with another device to ensure it is functional.

For persistent issues, please contact WAMPAT customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	WAMPAT
Model Name	W11F409ACx2+W11F4042C-D
Color	Oak
Product Dimensions	15.7"D x 100.8"W x 30.9"H
Material	Wood (P2 MDF)
Item Weight	78 Pounds
Assembly Required	Yes
Charging Station	2 AC Outlets, 2 USB Ports, 6.5 ft Power Cable

Display Personality

Comes With
3
Packages



Figure 5: Product dimensions and component breakdown.

8. WARRANTY AND SUPPORT

WAMPAT products are designed for quality and durability. For specific warranty information, please refer to the documentation included with your purchase or visit the official WAMPAT website.

If you require assistance with assembly, have questions about product features, or need to report a defect, please contact WAMPAT customer support. Have your model name and purchase information ready for faster service.

WAMPAT Customer Support: [Visit the WAMPAT Store on Amazon](#)