

[Manuals.plus](#) /

> [enya](#) /

> enya MS1 Magnetic Guitar Strap Instruction Manual

enya MS1

enya MS1 Magnetic Guitar Strap Instruction Manual

Model: MS1

INTRODUCTION

The enya MS1 Magnetic Strap is designed for musicians seeking a fast, secure, and comfortable solution for their guitar, bass, or ukulele. This manual provides detailed instructions for the proper setup, operation, and maintenance of your MS1 strap.

KEY FEATURES

- **Magnetic Quick Release:** Utilizes powerful magnets for fast and secure attachment and detachment.
- **Single-Hand Adjustment:** Allows for quick and easy length modification with one hand.
- **High Load Capacity:** Capable of supporting instruments up to 60kg (132lbs).
- **Comfortable Design:** Features a PU leathery material for enhanced friction and pressure dispersion on the shoulder.
- **Adjustable Length:** Length can be adjusted from 107cm (42.13 inches) to 124cm (48.82 inches).

SETUP INSTRUCTIONS

Attaching the Strap Pins

1. Identify the two magnetic strap pins. One pin may be slightly longer than the other.
2. Attach the longer magnetic strap pin to the instrument's strap button located near the neck.
3. Attach the shorter magnetic strap pin to the instrument's strap button at the bottom of the body.
4. Ensure both pins are securely fastened to the instrument's strap buttons.

Note: Incorrect placement of the pins (e.g., longer pin at the bottom) may cause clicking noises against the instrument body during use.



The enya MS1 strap securely attached to a guitar, illustrating the magnetic pin's integration with the instrument's strap button.

Connecting the Strap to the Pins

1. Hold the main strap with the magnetic buckles facing the strap pins on your instrument.
2. Bring the male buckle of the strap close to the corresponding magnetic strap pin. The magnets will automatically align and click into place, locking the strap securely.
3. Repeat for the second strap pin.



This image illustrates how to connect the magnetic strap buckle to the strap pin.

OPERATING INSTRUCTIONS

Quick Release Mechanism

To detach the strap, simply pull the magnetic buckle away from the strap pin by hand. The design ensures that the strap only detaches when intentionally pulled, preventing accidental release.

Single-Hand Length Adjustment

The MS1 strap features a convenient single-hand adjustment system. To adjust the length:

1. Locate the adjustment tab on the strap.
2. Pull the tab to either lengthen or shorten the strap to your desired position.
3. Release the tab to lock the strap at the new length.



The strap features a single-hand adjustment mechanism, allowing for quick length changes by pulling the tab.

MAINTENANCE

To ensure the longevity and appearance of your enya MS1 Magnetic Strap, follow these care instructions:

- **Cleaning:** The strap is made of a leathery texture material. It is recommended to **Dry Clean Only**. Do not machine wash or tumble dry.
- **Storage:** Store the strap in a cool, dry place away from direct sunlight. Rolling the strap can help maintain its shape and prevent creases.
- **Magnetic Components:** Keep the magnetic buckles and pins free from dirt and debris to ensure optimal connection strength.



The strap can be easily rolled for compact storage, demonstrating its flexible material.

TROUBLESHOOTING

- **Missing Parts:** If any components, such as the magnetic strap pins, are missing upon arrival, please contact your retailer or enya customer support immediately.
- **Clicking Noise from Strap Pins:** If you hear a clicking sound when the instrument moves, verify that the longer magnetic strap pin is attached to the neck-side strap button and the shorter pin is at the bottom of the instrument.
- **Strap Feels Too Long/Short:** Utilize the single-hand adjustment mechanism to fine-tune the strap length to your preference. The strap is adjustable between 107cm and 124cm.
- **Strap Not Attaching Securely:** Ensure the magnetic buckles and pins are clean and free from obstructions. Confirm that the pins are fully inserted into the instrument's strap buttons.

PRODUCT SPECIFICATIONS

Model	MS1
Material	PU Leathery Texture

Adjustable Length	107cm (42.13 inches) to 124cm (48.82 inches)
Strap Width	6cm (2.36 inches)
Weight Capacity	Up to 60kg (132lbs)
Care Instructions	Dry Clean Only
Origin	Made in China

WARRANTY AND SUPPORT

Specific warranty information for the enya MS1 Magnetic Strap is not provided in the product details. For warranty claims, technical support, or inquiries regarding missing parts, please contact enya customer service or your authorized retailer directly. Please retain your proof of purchase for any support requests.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question