

[Manuals.plus](#) /

› [VRURC](#) /

› VRURC Power Bank T2055 User Manual

VRURC T2055

VRURC Power Bank User Manual

Model: T2055 | Brand: VRURC

1. INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your VRURC T2055 20000mAh Portable Power Bank. Please read this manual thoroughly before using the device to ensure optimal performance and longevity.





Figure 1.1: VRURC T2055 Power Bank in hand, highlighting its portable design.

2. PACKAGE CONTENTS

Upon opening the package, please verify that all items listed below are present and in good condition:

- 1 x VRURC T2055 20000mAh Power Bank
- 1 x USB A-C Charging Cable
- 1 x User Manual (this document)

3. PRODUCT FEATURES

The VRURC T2055 Power Bank is designed for efficient and versatile charging, offering the following key features:

- **High Capacity:** 20,000mAh battery capacity for extended power.

- **Fast Charging:** Equipped with 22.5W USB-A and 20W USB-C ports supporting PD QC 3.0 technology for rapid device charging.
- **Multiple Ports:** Features 4 output ports and 3 input ports (USB-C, Micro, Lightning) for broad compatibility.
- **Simultaneous Charging:** Capable of charging up to 4 devices concurrently.
- **LED Digital Display:** Provides a precise percentage display of the remaining battery level.
- **Compact Design:** Small and lightweight for easy portability.
- **Advanced Safety:** Built-in protection against overheating, overvoltage, overcharging, and short circuits.



Figure 3.1: High-speed charging capability of the power bank.

3 Multiples
Inputs



4 Smart
Outputs

18W Max
Micro Input

12W Max
USB-A Output

22.5W FAST ⚡
USB-A Output

20W FAST ⚡
USB-C In/Out

12W Max
USB-A Output

18W Max
Lightning Input



Figure 3.2: Overview of the multiple input and output ports.

Universal Compatibility

Auto fit your device's power need



For iPhone

iPhone 15/14/.../SE/AirPods
all series



For Android

Samsung/Google/Xiaomi...
others Android



For Tablets

iPad/iPad Pro/Samsung
/Huawei... Tablets



For Heated Apparel

jackets/vests/pants
/hats/gloves



Figure 3.3: Universal compatibility with various devices.

4. SETUP & FIRST USE

4.1 Charging the Power Bank

Before initial use, fully charge your VRURC T2055 Power Bank. A full charge typically takes approximately 6 hours when using a 9V 2A cable and adapter (not included).

1. Connect the provided USB A-C cable to the USB-C input port on the power bank.
2. Connect the other end of the cable to a compatible USB wall adapter or computer USB port.
3. The LED display will show the charging progress, indicating the battery percentage.
4. Once the display shows 100%, the power bank is fully charged and ready for use.

The power bank supports three input methods for recharging:

- USB-C Input (18W Max)
- Lightning Input (18W Max)
- Micro USB Input (18W Max)

3-Ways for Recharge



Figure 4.1: Different input options for recharging the power bank.

5. OPERATING INSTRUCTIONS

5.1 Charging Your Devices

The VRURC T2055 Power Bank can charge a wide range of devices, including smartphones, tablets, and other USB-powered gadgets.

1. Identify the appropriate charging cable for your device.
2. Connect one end of your device's charging cable to one of the power bank's output ports (USB-A or USB-C).
3. Connect the other end of the cable to your device.
4. The power bank will automatically begin charging your device. The LED display will remain active, showing the power bank's remaining charge.

The power bank features four output ports:

- USB-A Output 1 (12W Max)
- USB-A Output 2 (22.5W Max)
- USB-C Output (20W Max)
- USB-A Output 3 (12W Max)




Figure 5.1: Charging up to four devices simultaneously.

6. LED DISPLAY GUIDE

The integrated LED digital display provides real-time information about the power bank's battery status. The percentage shown directly indicates the remaining charge level of the power bank (0-100%).




Figure 6.1: The LED display showing battery percentage.

7. SAFETY INFORMATION

To ensure safe operation and prevent damage to the device or injury, please adhere to the following safety guidelines:

- Do not expose the power bank to extreme temperatures (hot or cold), direct sunlight, or high humidity.
- Avoid dropping, hitting, or disassembling the device.
- Keep the power bank away from water or other liquids.
- Do not use the power bank if it is visibly damaged, swollen, or leaking.
- Use only certified charging cables and adapters.
- The power bank features automatic protection modes for overheating, overvoltage, overcharging, and short circuit. However, always monitor charging and disconnect once devices are fully charged.
- Keep out of reach of children.

8. MAINTENANCE

Proper maintenance will extend the lifespan of your power bank:

- Clean the power bank with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Store the power bank in a cool, dry place when not in use.
- If storing for an extended period, charge the power bank to approximately 50-70% every three months to maintain battery health.

9. TROUBLESHOOTING

If you encounter issues with your VRURC T2055 Power Bank, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Power bank not charging	Cable or adapter faulty; power bank fully discharged; input port issue.	Try a different charging cable and adapter. Ensure the cable is fully inserted into the input port. Allow a few minutes for the power bank to respond if completely drained.
Device not charging from power bank	Power bank is empty; cable faulty; device not compatible; output port issue.	Check power bank's charge level on the LED display. Try a different charging cable. Ensure your device is compatible with USB charging. Try a different output port on the power bank.
Slow charging	Cable or adapter not supporting fast charge; device's charging limit.	Ensure you are using a fast-charging compatible cable and adapter (for input) or cable (for output). Some devices have a maximum charging rate.
LED display not working	Device malfunction.	Try charging the power bank or connecting a device to it to see if the display activates. If it remains unresponsive, contact customer support.

10. SPECIFICATIONS

Specification	Detail
Model Number	T2055
Battery Capacity	20000 Milliamp Hours (mAh)
Product Dimensions	4.21 x 2.74 x 0.99 inches
Item Weight	10 ounces
Input Ports	USB-C (18W Max), Micro USB (18W Max), Lightning (18W Max)
Output Ports	USB-A (12W Max), USB-A (22.5W Max), USB-C (20W Max), USB-A (12W Max)
Special Features	22.5W Fast Charging, Digital Display, Pocket Size, Slim Design, Multi-Port Charging
Battery Type	Lithium Polymer

4.3 Charges
iPhone 15

2.5 Charges
Samsung S23

1.6 Charges
iPad Pro

26 Charges
AirPods Pro

20000

mAh



280g / 9.9 ounces



10.69 x 6.95 x 2.51 cm
4.21 x 2.74 x 0.99 inches



Figure 10.1: Capacity and dimensions overview.

11. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the specific warranty card or documentation included with your product package. You may also visit the official VRURC brand store for additional support and product

information:

[Visit the VRURC Official Store](#)

© 2024 VRURC. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question