Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Amazon Basics /
- Amazon Basics Portable and Flexible Tripod Instruction Manual

Amazon Basics WF-02SK

Amazon Basics Portable and Flexible Tripod Instruction Manual

Model: WF-02SK | Brand: Amazon Basics

1. Introduction

The Amazon Basics Portable and Flexible Tripod is designed to provide stable support for a variety of devices, including smartphones, GoPros, digital cameras, and webcams. Its flexible legs allow for versatile mounting options, while the included wireless remote enables convenient remote capture. This manual will guide you through the setup, operation, and maintenance of your new tripod.

2. WHAT'S IN THE BOX

- 1 x Flexible Tripod
- 1 x Smartphone Clamp
- 1 x Wireless Remote Control



Figure 2.1: Contents of the package, including the tripod, smartphone clamp, and wireless remote.


3. PRODUCT OVERVIEW

Versatile Tripod Stand Secure and adjustable Holds smartphones up Easily rotate side to 3.7 in / 9.3 cm wide knob for portrait or landscape mode Ideal for digital cameras Wireless remote range up to 1.1 lbs / 0.5 kg, of 30 ft / 9.1 m (without obstacle) action cameras or webcam


Figure 3.1: Key features of the tripod, highlighting the smartphone clamp, rotatable knob for orientation, and wireless remote.

Wide Usage Scenarios

Steady tripod for every occasion



Digital cameras up to 1.1 lbs / 0.5 kg



Smartphones



Webcam

Figure 3.2: The tripod offers universal compatibility with various devices, including digital cameras, smartphones, GoPro/action cameras, and webcams.

4. SETUP

4.1 Attaching Your Device

- 1. **For Smartphones:** Securely place your smartphone into the adjustable clamp. Ensure the phone is centered and held firmly.
- 2. **For Cameras/GoPros/Webcams:** Screw your device onto the standard 1/4-inch screw mount located at the top of the tripod. Tighten until secure.





Figure 4.1: The tripod can be held as a grip for handheld shooting with a camera attached.

4.2 Pairing the Wireless Remote

- 1. Ensure the wireless remote has a charged battery.
- 2. Turn on the remote control.
- 3. On your smartphone, enable Bluetooth and search for available devices.
- 4. Select the remote control (usually named 'AB Shutter3' or similar) from the list to pair.
- 5. Once paired, the remote can be used to trigger your device's camera shutter.

5. OPERATING INSTRUCTIONS

5.1 Adjusting the Tripod

- Flexible Legs: The tripod's legs are highly flexible and can be bent and wrapped around various objects like poles, branches, or railings to secure your device in unique positions.
- **Portrait/Landscape Mode:** Rotate the side knob on the smartphone clamp to instantly switch between portrait and landscape orientations without removing your device.




Figure 5.1: The tripod's flexible legs allow it to be mounted on irregular surfaces or objects for stable shots.



Figure 5.2: The tripod provides stable support for capturing moments on the go.



Figure 5.3: The tripod can also be used as a traditional tabletop stand.

5.2 Using the Wireless Remote

- After pairing, open your device's camera application.
- Press the corresponding button on the remote (iOS or Android) to take photos or start/stop video recording.
- The remote has a range of up to 30 feet (without obstacles), ideal for group shots or wide-angle scenes.

6. MAINTENANCE

- Clean the tripod and clamp with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- Store the tripod in a cool, dry place away from direct sunlight and extreme temperatures.
- Ensure the flexible legs are not excessively bent or twisted to prevent damage to the internal structure.

7. TROUBLESHOOTING

| Issue | Possible Cause | Solution |
|-----------------------------------|--|--|
| Wireless remote not pairing | Remote battery low; Bluetooth not enabled on device; remote not in pairing mode. | Replace remote battery; enable Bluetooth; ensure remote is turned on and discoverable. |
| Device not stable on tripod | Device not securely attached; tripod legs not properly positioned. | Ensure clamp/screw mount is tight; adjust legs for a wider, more stable base. |
| Tripod legs losing flexibility | Excessive bending or twisting over time. | Avoid over-bending; use within recommended limits. |

8. SPECIFICATIONS

| Feature | Detail |
|-------------------------------|---|
| Product Dimensions | 27.94 x 5.99 x 3.81 inches |
| Item Weight | 2.82 ounces (0.08 Kilograms) |
| Item Model Number | WF-02SK |
| Color | Black |
| Compatible Devices | Smartphones (up to 3.7 inches wide), GoPros, Digital Cameras, Webcams |
| Maximum Weight Recommendation | 500 Grams |
| Wireless Remote Range | 30 feet (without obstacle) |
| UPC | 840324414950 |

9. WARRANTY AND SUPPORT

For detailed warranty information, please refer to the official warranty document provided with your product or download it from the link below:

Download Warranty (PDF)

For further assistance or technical support, please visit the Amazon Basics official website or contact customer service through your purchase platform.

Related Documents - WF-02SK



Amazon Basics 64-inch Extendable Tripod User Manual

User manual for the Amazon Basics 64-inch Extendable Tripod, detailing its features for iPhones and smartphones in both selfie stick and tripod modes. Includes setup and usage instructions.







Electronic Keypad Entry Lever Door Lack Verrou de Parte à Levier pour Porte d'Entrée avec Clavier Electronique Cerradura de Puerta con Manija y Teclado Electrónico de Acceso 電子キーパッド エントリレバードプロック ROSLMATEKI. ROSLMHROV. ROSLMITATWI

Amazon Basics Electronic Keypad Entry Lever Door Lock: Safety and Use Manual

Comprehensive safety and use manual for the Amazon Basics Electronic Keypad Entry Lever Door Lock, covering installation, operation, programming, troubleshooting, and specifications.

amazon basics

User Manual Buseneth Writess on-Ear Buseneth Writess on Tar Buseneth Writess on Tar Buseneth Writess on Tar Buseneth Carlo Writess on Tar Buseneth Carlo Writess on Tar Buseneth Carlo Writess on Tar Buseneth Scholars of Parallel Space (San Handal Carlo Washelson of Manual Carlo Washelson of Manual Carlo Washelson of Manual Carlo Washelson on Autricularies Instalinhofees com Autricularies Instalinhofees com Gebruike enhandlelding Draadlose Bluet corth-koptelefoon, on-ear, xwart Instrukção obbstugi Besprzewodwe suchuwiki doussine Bluetostik, cambi Engraevalow suchuwiki doussine Bluetostik, vanite Buseneth, swarte Buseneth, swarte

Amazon Basics Bluetooth Wireless On-Ear Headphones User Manual

User manual for Amazon Basics Bluetooth Wireless On-Ear Headphones, Black. Provides instructions on setup, usage, troubleshooting, specifications, and legal notices.



Amazon Basics Mattress User Guide and Specifications

Comprehensive user guide and specifications for Amazon Basics mattresses, detailing setup instructions, important safety safeguards, cleaning and maintenance tips, warranty information, and product dimensions.

amazon basics





Amazon Basics 12" Wall Clock, Black - User Manual and Guide

Comprehensive user manual for the Amazon Basics 12-inch black wall clock. Learn about setup, mounting, time setting, maintenance, specifications, and disposal. Includes safety warnings and troubleshooting tips.



Protein A. Conditions Debundelines Fundos Charakter United: Nation Debundelinesis Charakter United: Nation Debundelinesis

Amazon Basics Portable Air Conditioner Dehumidifier Manual - Safety, Operation, Installation

User manual for Amazon Basics portable air conditioner and dehumidifier (models B07ZHQDF7B, B07ZHQFNX8, B07ZHQTBGS, B07ZHQV1GT). Includes safety guidelines, product features, operating instructions, and installation steps for various window types. Available in multiple languages.