

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TECKNET](#) /

› [TECKNET Wireless Keyboard and Mouse Combo Instruction Manual](#)

TECKNET X315

TECKNET Wireless Keyboard and Mouse Combo Instruction Manual

Model: X315

1. PRODUCT OVERVIEW

The TECKNET Wireless Keyboard and Mouse Combo (Model X315) offers a convenient and efficient solution for your computing needs. Utilizing 2.4GHz wireless technology, it provides a stable and lag-free connection up to 15 meters (49 feet). The compact design makes it ideal for home, office, or travel use, ensuring a quiet and comfortable user experience.



Figure 1: TECKNET Wireless Keyboard and Mouse Combo with USB receiver.

2. WHAT'S IN THE BOX

- 1 x TECKNET Wireless Keyboard (Model X315)
- 1 x TECKNET Wireless Mouse (Model KM001)
- 1 x 2.4GHz USB Nano Receiver (stored inside the mouse battery compartment)
- 1 x User Manual
- (Note: 4 x AAA batteries are required and not included)

3. SETUP GUIDE

3.1 Battery Installation

1. Open the battery compartment on the back of the keyboard. Insert two AAA batteries, ensuring correct polarity (+/-). Close the compartment.
2. Open the battery compartment on the bottom of the mouse. Insert two AAA batteries, ensuring correct polarity (+/-).
3. Locate the 2.4GHz USB Nano Receiver inside the mouse battery compartment. Carefully remove it.
4. Close the mouse battery compartment.



Figure 2: Battery installation and USB receiver location.

3.2 Connecting to Your Device

1. Plug the 2.4GHz USB Nano Receiver into an available USB port on your computer (PC, Laptop, Smart TV, etc.).
2. Turn on the keyboard using the ON/OFF switch located on its back.
3. Turn on the mouse using the ON/OFF switch located on its bottom.
4. Your computer should automatically detect and install the necessary drivers. The keyboard and mouse are now ready for use.

2-IN-1 USB RECEIVER

Keyboard and mouse share a receiver, plug and play



There is only one USB, and its storage location is here.

Figure 3: Connecting the USB receiver for plug-and-play functionality.

Your browser does not support the video tag.

Video 1: Official TECKNET demonstration of the Wireless Keyboard and Mouse Combo setup and use.

4. OPERATING INSTRUCTIONS

4.1 Keyboard Features

- **Scissor-Key Design:** Provides a comfortable, quiet, and responsive typing experience.
- **12 Multimedia Hotkeys:** Access common functions quickly by pressing the 'Fn' key in combination with the F1-F12 keys.
 - Fn+F1: Play/Pause
 - Fn+F2: Previous Track
 - Fn+F3: Next Track
 - Fn+F4: Volume Up
 - Fn+F5: Volume Down
 - Fn+F6: Mute/Unmute
 - Fn+F7: Homepage
 - Fn+F8: Search
 - Fn+F9: Browser Favorites
 - Fn+F10: Hibernate
 - Fn+F11: Insert
 - Fn+F12: Print Screen

12 MULTIMEDIA KEYS

- | | |
|------------------------|----------------------------|
| ▶/ FN+F1 Play/pause | 🏠 FN+F7 Homepage |
| ⏮ FN+F2 Previous Track | 🔍 FN+F8 Search |
| ⏭ FN+F3 Next Track | 📁 FN+F9 Browser Favorites |
| 🔊 FN+F4 Volume+ | 🔌 FN+F10 Hibernate |
| 🔊 FN+F5 Volume- | Insert FN+F11 Insert |
| 🔊 FN+F6 Mute/Unmute | Prt Sc FN+F12 Print Screen |



Figure 4: Keyboard layout highlighting multimedia hotkeys.



COMFORTABLE TYPING AND QUIET CLICKING

Figure 5: Demonstrating comfortable typing and quiet clicking.

4.2 Mouse Features

- **Ultra-Quiet Clicking:** Engineered for silent operation, ensuring minimal disturbance.
- **Adjustable DPI:** Cycle through 3 DPI levels (800/1200/1600) to adjust sensitivity for different tasks. The DPI button is located below the scroll wheel.

QUIET WORK ENVIRONMENT

Low noise keyboard and quiet mouse



Figure 6: Mouse features including quiet clicks and adjustable DPI.

5. POWER MANAGEMENT

The keyboard and mouse are designed with energy-saving features to extend battery life.

- **Automatic Sleep Mode:** If inactive for 10 minutes, both the keyboard and mouse will enter sleep mode to conserve power.
- **Wake-up:** To wake the devices, simply press any key on the keyboard or move/click the mouse.
- **ON/OFF Switch:** For prolonged periods of non-use, it is recommended to turn off the devices using their respective ON/OFF switches.




Figure 7: Power-saving features for extended battery life.

6. MAINTENANCE AND CARE

- Keep the devices away from liquids and extreme temperatures.
- Clean the keyboard and mouse with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Remove batteries if the devices will not be used for an extended period to prevent leakage.

7. TROUBLESHOOTING

Problem	Solution
Devices not responding.	<ol style="list-style-type: none">1. Ensure batteries are correctly installed and not depleted. Replace if necessary.2. Make sure the ON/OFF switches on both devices are in the 'ON' position.3. Verify the USB receiver is securely plugged into a working USB port on your computer. Try a different USB port.4. Restart your computer.
Lag or intermittent connection.	<ol style="list-style-type: none">1. Ensure the devices are within the 15-meter (49 feet) effective range of the USB receiver.2. Avoid using the devices on metal surfaces, which can interfere with the wireless signal.3. Move the USB receiver closer to the keyboard and mouse.4. Check for other 2.4GHz wireless devices nearby that might cause interference.
Mouse cursor erratic or not moving smoothly.	<ol style="list-style-type: none">1. Clean the optical sensor on the bottom of the mouse.2. Try using the mouse on a different surface (e.g., a mouse pad).3. Adjust the DPI setting using the DPI button on the mouse.

8. SPECIFICATIONS

- **Brand:** TECKNET
- **Model:** X315 (Keyboard), KM001 (Mouse)
- **Connectivity Technology:** 2.4GHz Wireless (via USB Nano Receiver)
- **Wireless Range:** Up to 15 meters (49 feet)
- **Keyboard Dimensions:** 292 x 125 x 19mm (11.22 x 4.72 x 0.79 inches)
- **Keyboard Weight:** 300g (12.7 ounces)
- **Mouse Dimensions:** 110 x 65 x 30mm (4.33 x 2.56 x 1.18 inches)
- **Mouse Weight:** 58g (2.05 ounces)

- **Mouse DPI Levels:** 800/1200/1600 (Adjustable)
- **Battery Type:** 4 x AAA (2 for keyboard, 2 for mouse - not included)
- **Compatibility:** Windows 11/10/8/7/2000/ME/XP/Vista, Android Smart TVs, PC, Laptop, Mac, Chrome OS

9. WARRANTY AND SUPPORT

TECKNET offers a 36-month warranty for this product (registration required). For any product issues, please contact TECKNET professional customer service for assistance.

Contact Information:

- Email: support@tecknet.co.uk
- Website: www.tecknet.co.uk

Related Documents - X315

	<p>TECKNET EWM01769 Wireless Mouse User Manual</p> <p>User manual for the TECKNET EWM01769 wireless mouse, providing setup instructions, product specifications, safety guidelines, warranty details, and regulatory compliance information.</p>
	<p>Tecknet TK-MS001 Wireless Rechargeable Silent Mouse User Manual</p> <p>Comprehensive user manual for the Tecknet TK-MS001 Wireless Rechargeable Silent Mouse, covering setup, connectivity (2.4GHz, Bluetooth), DPI adjustment, charging, sleep mode, safety instructions, warranty, and disposal information.</p>
	<p>TECKNET M002 Wireless Mouse User Manual</p> <p>User manual for the TECKNET M002 wireless mouse, covering system requirements, operation, troubleshooting, and technical specifications in multiple languages.</p>
	<p>TECKNET M006 Cordless Mouse User Manual</p> <p>User manual for the TECKNET M006 Cordless Mouse, providing setup instructions, technical specifications, features like Intelligent Power Saving and DPI switching, troubleshooting tips, safety guidelines, and warranty information.</p>
	<p>TeckNet EWM01002 Cordless Mouse User Manual and Safety Information</p> <p>User manual for the TeckNet EWM01002 Cordless Mouse, including button instructions, product specifications, setup guide, safety precautions, warranty information, and disposal instructions.</p>



[TECKNET M006 Wireless Mouse User Manual and Specifications](#)

Detailed user guide for the TECKNET M006 wireless mouse, covering setup, features, troubleshooting, warranty, and safety. Learn about DPI settings, battery life, and connectivity.